

FOREWORD

Thank you for purchasing GOWIN TKS-200 Serial Electronic Total Station. For the best performance of the instruments, please carefully read these instructions and keep them in a convenient location for future reference.

General Handling Precautions

Before use of this instrument. It is necessary to check and confirm that each function of this instrument is working normally.

Do not submerge the instrument into water.

The instrument can not be submerged underwater.

The instrument is designed based on the International Standard IP54, therefore it is protected from the normal rainfall.

Setting the instrument on a tripod.

When setting the instrument on the tripod, the wood tripod should be used as much as possible, since the metallic tripod will generate vibration, which will effect the measurement precision.

Installing the tribrach.

If the tribrach is not properly installed, the measurement accuracy will be effected; the adjustment screw on the tribrach should be frequently checked to ensure that the fixing lever is locked and the base fixing screws are tightened.

Guarding the instrument against shocks.

During general transportation process, the shocks should be alleviated as much as possible, since a serious shock would lead to damage of surveying function.

Carrying the instrument

Always carry the instrument by its handgrip.

Exposing the instrument to extreme heat.

Do not leave the instrument in extreme heat for longer than necessary. It could adversely affect its performance.

Sudden changes of temperature.

Any sudden change of temperature to the instrument or prism may result in a reduction of measuring distance range, i.e when taking the instrument out from a heated vehicle. Let instrument acclimate itself to ambient temperature.

Battery level check.

Confirm battery level remaining before operating.

Taking the battery out.

It is recommended not to take the battery or external battery out during the power is on. All the data stored is possible gone at that time. So please do your assembling or taking the battery out after the power is off.

Do not hold the lower part of display unit.



When you take out the instrument from a carrying case, or keep into the case, please hold the hand grip and base of the instrument, do not hold the lower part of display unit.

Handling of battery.

The battery should be handled safely, for power supply please use the recommended battery, if the battery we recommended is not used, which will result in damage to the instrument

Display for Safe Use

In order to encourage the safe use of GOWIN products and prevent any danger to the operator and others or damage to properties, important warnings are put on the products and inserted in the instruction manuals. We suggest that everyone understand the meaning of the following displays and icons before reading the Safety Cautions and use instructions.

Display	Meaning
 WARNING	Ignoring or disregard of this display may lead to the danger of death or serious injury.
 CAUTION	Ignoring or disregard of this display may lead to personal injury or physical damage.

•Injury refers to hurt, burn, electric shock, etc.

•Physical damage refers to extensive damage to buildings or equipment and furniture.

Safety Cautions

⚠ WARNING
·There is a risk of fire, electric shock or physical harm if you attempt to disassemble or repair the instrument by yourself. This is only to be carried out by GOWIN or an authorized dealer, only!
·Cause eye injury or blindness. Do not look at the sun through a telescope.
·High temperature may cause fire. Do not cover the charger while it is charging.
·Risk of fire or electric shock. Do not use damaged power cable, plug and socket.
·Risk of fire or electric shock. Do not use a wet battery or charger.
·May ignite explosively. Never use an instrument near flammable gas, liquid matter, and do not use it in a coal mine.
·Battery can cause explosion or injury. Do not dispose in fire or heat.
·Risk of fire or electric shock. Do not use any power voltage except the one given on manufacturers instructions.
·Battery can cause fire. Do not use any other type of charger other than the one specified.
·Risk of fire. Do not use a power supply cable that is not specified by the manufacturer.
·The short-circuit of a battery can cause a fire. Do not short circuit a battery when storing it.

CAUTION

- Do not connect or disconnect equipment with wet hands, you are exposed to electric shocks if you do like this!
- Risk of injury by overturn the carrying case.
Do not stand or sit on the carrying cases.
- Please note that the tips of tripod can be hazardous, be aware of this when setting or carrying the tripod.
- Risk of injury by falling down the instrument or case.
Do not use a carrying case with a damaged which belts, grips or latches .
- Do not allow skin or clothing to come into contact with acid from the batteries, if this does occur then wash off with copious amounts of water and seek medical advice.
- It could be dangerous if the instrument falls over, please ensure you attach a handle to the instrument securely.
- Ensure that you mount the Tribrach correctly, failing to do so may result in injury if the tribrach were to fall over.
·It could be dangerous if the instrument falls over, please check that you fix the instrument to the tripod correctly.
- Risk of injury by falling down a tripod and an instrument.
Always check that the screws of tripod are tightened.

User

- 1) This product is for professional use only!
The user is required to be a qualified surveyor or have a good knowledge of surveying, in order to understand the user and safety instructions, before operating, inspecting or adjusting.
- 2) Wear the required protectors (safety shoes, helmet, etc.) when operating.

Exceptions from Responsibility

- The user of this product is expected to follow all operating instructions and make periodic checks of the product's performance.
- The manufacturer, or its representatives, assumes no responsibility for results of any faulty or intentional usage or misuse including any direct, indirect, consequential damage, and loss of profits.
- The manufacturer, or its representatives, assumes no responsibility for consequential damage, and loss of profits by any disaster (earthquake, storms, floods etc.)
A fire, accident, or an act of a third party and/or a usage any other usual conditions.
- The manufacturer, or its representatives, assumes no responsibility for any damage, and loss of profits due to a change of data, loss of data, an interruption of business etc., caused by using the product or an unusable product.
- The manufacturer, or its representatives, assumes no responsibility for any damage, and loss of profits caused by extra usage that is not according to the user manual.
- The manufacturer, or its representatives, assumes no responsibility for consequential and profit loss caused by wrong movement, or action due to connecting with other products.

How to Use The Straps



1 Carry on the back



2 Carry in the hand

INDEX

1. NOMENCLATURE AND FUNCTIONS	10
1.1 Nomenclature	10
1.2 Display	12
1.3 Operating Key	13
1.4 Function Key (Soft Key)	14
1.5 Star key mode.....	16
1.6 Serial signal RS-232C connector	17
2. PREPARATION FOR MEASUREMENT	18
2.1 Setting Instrument Up For Measurement	18
2.2 Power Switch Key ON	20
2.3 Battery Power Remaining Display	21
2.4 Vertical Angle Tilt Correction	21
2.5 How to Enter Alphanumeric Characters	22
3. ANGLE MEASUREMENT	25
3.1 Measuring Horizontal Angle Right and Vertical Angle.....	25
3.2 Switching Horizontal Angel (Right/Left)	26
3.3 Measuring from the Required Horizontal Angle.....	27
3.3.1 Setting by Holding the Angle.....	27
3.3.2 Setting a Horizontal Angle from the Keys.....	27
3.4 Vertical Angle Percent Grade (%) Mode	28
3.5 Repetition Angle Measurement.....	28
3.6 Buzzer Sounding for Horizontal Angle 90° Increments	30
Compasses (vertical angle).....	31
4. DISTANCE MEASUREMENT	32
4.1 Setting of the Atmospheric Correction.....	32
4.2 Setting of the Correction for Prism Constant.....	32
4.3 Distance Measurement (Continuous Measurement)	32
4.4 Distance Measurement (N-time Measurement/Single Measurement)	33
4.5 Fine Mode/Tracking Mode/Coarse Mode	35
4.6 Stake Out (S.O)	36
4.7 Offset Measurement	37
4.7.1 Angle Offset.....	38
4.7.2 Distance Offset Measurement	41
4.7.3 Plane Offset Measurement	43
4.7.4 Column Offset Measurement	45
5. COORDINATE MEASUREMENT	48
5.1 Setting Coordinate Values of Occupied Point	48

5.2 Setting Height of the Instrument	49
5.3 Setting Height of Target (Prism Height)	50
5.4 Execution of Coordinate Measuring	50
6. SPECIAL MODE (MENU MODE)	52
6.1 Application measurement (program)	53
6.1.1 Remote Elevation Measurement (REM)	53
6.1.2 Missing Line Measurement (MLM)	56
6.1.3 Setting Z Coordinate of Occupied Point	59
6.1.4 Area Calculation	63
6.1.5 Point to Line Measurement	67
6.2 Setting the GRID FACTOR	70
6.3 Setting Illumination of Display and Cross Hairs	72
6.4 Setting Mode 1	73
6.4.1 Setting Minimum Reading	73
6.4.2 Auto Power Off	74
6.4.3 Tilt correction (TILT ON/OFF)	75
6.4.4 Setting RS-232C communication with external device	76
6.5 Setting Contrast of Display	78
6.6 ROAD	79
6.6.1 Input Start Point	80
6.6.2 Input Road Data	81
6.6.3 Search Data	85
6.6.4 Edit Data	85
6.6.5 Set OCC and BS	86
6.6.6 Road Layout	88
6.6.7 Select a File	90
6.6.8 Initialize ROAD data	90
7. DATA COLLECTION	91
7.1 Preparation	93
7.1.1 Selecting a File for Data Collection	93
7.1.2 Selection of Coordinate File for Data Collection	94
7.1.3 Occupied Point and Backsight Point	94
7.2 Operational Procedure of “DATA COLLECT”	98
7.3 Data Collection Offset Measurement Mode	101
7.3.1 Angle Offset Measurement	102
7.3.2 Distance Offset Measurement	104
7.3.3 Plane Offset Measurement	106
7.3.4 Column Offset Measurement	109

7.4 NEZ Auto Calculation.....	111
7.5 Point to Line Measurement	112
7.5.1 To change to the point to line measurement	112
7.5.2 Execute “Measurement from point to line”	113
7.6 EDIT PCODE LIBRARY [PCODE INPUT]	115
7.7 Setting Parameter of Data Collect [CONFIG.]	116
8. LAYOUT	118
8.1 Preparation	120
8.1.1 Setting the GRID FACTOR	120
8.1.2 Selecting Coordinate Data File	121
8.1.3 Setting Occupied Point.....	122
8.1.4 Set Backsight Point	124
8.2 Executing a Layout.....	126
8.2.1 Layout of Coordinates of Point to Line.....	129
8.3 Setting a New Point.....	130
8.3.1 Side Shot Method	130
8.3.2 Resection Method.....	133
9. MEMORY MANAGER MODE	139
9.1 Display Internal Memory Status	140
9.2 Searching Data	140
9.2.1 Measured Data Searching.....	141
9.2.2 Coordinate Data Searching	143
9.3 File Maintenance	145
9.3.1 Rename a File.....	146
9.3.2 Search the Data in the File	147
9.3.3 Deleting a File	148
9.4 Coordinate Data Direct Key Input	148
9.4.1 Coordinate data input	148
9.4.2 PTL(Point To Line) data input	150
9.5 Deleting the Coordinate Data in the File.....	152
9.6 Editing PCODE Library	153
9.7 Data Communications	154
9.7.1 Sending Data	154
9.7.2 Loading Data	155
9.7.3 Setting of Data Communication Parameters	157
9.8 Initialization	159
10. SET AUDIO MODE	160
11. SETTING THE PRISM CONSTANT VALUE.....	161


12. SETTING ATMOSPHERIC CORRECTION.....	162
12.1 Calculation of Atmospheric Correction	162
12.2 Setting of the Atmospheric Correction.....	162
13. CORRECTION FOR REFRACTION AND EARTH CURVATURE	167
13.1 Distance Calculation Formula	167
14. POWER SOURCE AND CHARGING	168
14.1 On-board Battery BT-L1W	168
15. DETACH/ATTACH OF TRIBRACH	169
16. SELECTING MODE	170
16.1 Items of the Selecting Mode.....	170
16.2 How to Set Seleting Mode	175
17. CHECKING AND ADJUSTMENT	177
17.1 Checking and adjusting of instrument constant	177
17.2 Checking the Optical Axis	178
17.3 Checking and adjusting of theodolite.....	179
17.3.1 Checking /Adjusting the Plate Level.....	180
17.3.2 Checking / Adjusting the Circular Level.....	182
17.3.3 Adjustment of the Vertical Cross-hair	182
17.3.4 Collimation of the Instrument	184
17.3.5 Checking / Adjusting the Optical Plummet Telescope	186
17.3.6 Adjustment of Vertical Angle 0 Datum	187
17.4 How to Set the Instrument Constant Value.....	188
17.5 Reference frequency check mode	189
18. PRECAUTIONS	190
19. SPECIAL ACCESSORIES	191
20. PRISM SYSTEM	193
21. ERROR DISPLAY	194
22. SPECIFICATIONS	197


Standard Supporting Equipment:

- | | |
|---|---|
| 1. TKS-200 serial(with lens cap) | 6. One tool pack (with one screwdriver, |
| 2. Plastic carrying box (with the belt) | One rod pin and hex key wrench-set) |
| 3. One on—board battery | 7. Silicon cloth |
| 4. One battery charger | 8. One Rain Cover |
| 5. One Instruction Manual | |

1. NOMENCLATURE AND FUNCTIONS

1.1 Nomenclature





The position of vertical motion clamp and Vertical tangent screw will differ depending on the market.

1.2 Display

·Display unit

The display uses a dot matrix LCD which has 4 lines and 20 characters per line. In general, the upper three lines display measured data, and the bottom line displays the soft key function which changes with the measuring mode.

·Contrast and illumination

The contrast and illumination of display window are adjusted. see Chapter 6 “SPECIAL MODE(Menu Mode)” or section 1.5 “Star key mode”.

·Example

V	:	90° 10' 20"	
HR	:	120° 30' 40"	
0SET	HOLD	HSET	P1↓

Angle measurement mode

V-angle: 90°10'20"
H-angle: 120°30'40"

HR :	120° 30' 40"		
HD*	65.432m		
VD :	12.345m		
MEAS	MODE	S / A	P1↓

Distance measurement mode

Horizontal angle : 120°30'40"
Horizontal distance: 65.432m
Relative elevation : 12.345m

Feet unit

HR :	120°30'40"		
HD*	123.45 f		
VD :	12.34 f		
MEAS	MODE	S / A	P1↓

Horizontal Angle : 120°30'40"
Horizontal distance:123.45ft
Relative elevation :12.34ft

Feet and inch unit


HR*	120°30'40"		
HD*	123.04.6 f		
VD :	12.03.4 f		
MEAS	MODE	S / A	P1↓

Horizontal Angle : 120°30'40"
Horizontal distance :123ft4in6/8in
Relative elevation :12ft3in4/8in

·Display marks

Display	Contents	Display	Contents
V%	V-angle	*	EDM working
HR	H-angle(Right)	m	Meter unit
HL	H-angle(Left)	f	Feet and inch unit
HD	Horizontal Distance		
VD	Relative elevation		
SD	Slope distance		
N	N Coordinate		
E	E Coordinate		
Z	Z Coordinate		

1.3 Operating Key



Keys	Name of Key	Function
★	Star Key	Star key mode is used for each setting or displaying as follows. 1 Contrast of the display 2 Back Light 3 Tilt correction 4 set audio mode
↖↗	Coordinate meas.key	Coordinate measurement mode.
↖	Distance meas.key	Distance measurement mode
ANG	Angle meas.key	Angle measurement mode
POWER	Power source key	ON/OFF of power source
MENU	Menu key	Switches menu mode and normal mode. To set application measurements and adjust in the menu mode.

ESC	Escape key	<ul style="list-style-type: none"> • Returning to the measurement mode or previous layer mode from the mode set. • To be DATA COLLECTION mode or LAYOUT mode directly from the normal measurement mode. • It is also possible to use as Record key in normal measurement mode. <p>To select function of Escape key, see Chapter 16 “SELECTING MODE”</p>
ENT	Enter key	Press at the end of inputting values.
F1-F4	Soft key (Function key)	Responds to the message displayed.

1.4 Function Key (Soft Key)

The Soft Key message is displayed at the bottom line of display. The functions are according to the displayed message.

Angle Measurement Mode

V : 90°10'20"			
HR : 120°30'40"			
0SET	HOLD	HSET	P1↓
<hr/>			
TILT	REP	V%	P2↓
<hr/>			
H-BZ	R / L	CMPS	P3↓
[F1]	[F2]	[F3]	[F4]

Distance Measurement Mode

HR : 120°30'40"			
HR*	[r]	<< m	
VD:		m	
MEAS	MODE	S / A	P1↓
<hr/>			
OFFSET	S.O	m / f / i	P2↓

Coordinates measurement mode

N: 123.456m			
E: 34.567m			
Z: 78.912m			
MEAS	MODE	S / A	P1↓
<hr/>			
R.HT	INSHT	OCC	P2↓
<hr/>			
OFFSET	---	m / f / i	P3↓

Angle measurement

Page	Soft key	Display mark	Functions
1	F1	0SET	Horizontal angle is set to 0°00'00"
	F2	HOLD	Hold the horizontal angle
	F3	HSET	Sets a required horizontal angle by entering numerals
	F4	P1↓	The function of soft keys is shown on next page (P2).
2	F1	TILT	Setting Tilt Correction If ON, the display shows tilt correction value.
	F2	REP	Repetition angle measurement mode
	F3	V%	Vertical angle percent grade(%) mode
	F4	P2↓	The function of soft keys is shown on next page (P3).
3	F1	H-BZ	Sets the buzzer sound for every horizontal angle 90° .
	F2	R / L	Switches R / L rotation of horizontal angle.
	F3	CMPS	Switches the COMPASS ON/OFF of vertical angle.
	F4	P3↓	shown on next page (P1).

Distance measurement mode

1	F1	MEAS	Start measuring
	F2	MODE	Sets a measuring mode, Fine/Coarse/Tracking
	F3	S/A	Select set audio mode
	F4	P1↓	The function of soft keys is shown on next page (P2).
2	F1	OFFSET	Select Off-set measurement mode
	F2	S.O	Select stake out measurement mode
	F3	m/f/i	Switches meter, feet or feet and inch unit.
	F4	P2↓	The function of soft keys is shown on next page (P1).

Coordinate measurement mode.

1	F1	MEAS	Start measuring
	F2	MODE	Sets a measuring mode, Fine/Coarse/Tracking
	F3	S/A	Select set audio mode
	F4	P1 ↓	The function of soft keys is shown on next page (P2).
2	F1	R.HT	Sets a prism height by input values.
	F2	INSHT	Sets an instrument height by input values.
	F3	OCC	Sets an instrument coordinate point by input values.
	F4	P2 ↓	The function of soft keys is shown on next page (P3).
3	F1	OFFSET	Select Off-set measurement mode
	F3	m/f/i	Switches meter, feet or feet and inch unit.
	F4	P3 ↓	The function of soft keys is shown on next page (P1).

1.5 Star key mode

Press the (★) to view the following instrument options.

1. Adjustment the contrast of the display (0 to 9) [▲ or ▼]
2. Turn the backlight of the display ON/OFF [F1]
3. Setting Tilt Correction [F2]
4. Set audio mode [F4]




Note: Star key mode does not function when the same function as the function assigned to the star key mode is performed from the main routine.

V :	77°42'30"
HR :	120°30'40"
0SET HOLD HSET P1↓	

↓ Press the star(★) key

V : 77° 42' 30"



F1		Turn the backlight of the display ON/OFF
F2		Set the tilt correction; if on, the display shows tilt correction value.
F4		The light acceptance quantity level for the EDM (SIGNAL), the atmospheric correction value (PPM) and correction value of prism constant (PSM) are displayed.
▲ or ▼		Adjust contrast of display (0~9 steps)

·Adjustment the contrast (0 to 9) of the display

Push up/down arrow key(▲ or ▼) can adjust contrast of display

·Turn the display back light ON/OFF

Press the [F1] key to switch the back light ON/OFF



·Set audio mode

The light acceptance quantity level (Signal level) is displayed in this mode.

When reflected light from the prism is received, a buzzer sounds. This function is good for easy collimation when the target is difficult to find.

Press the [F4] key to view the set audio screen.

(1) To stop the buzzer, refer to Chapter 16 “SELECTING MODE”.

(2) Also, it is possible to display the signal level in Distance Measuring Mode.

The temperature, pressure, PPM, and PSM can be viewed in set audio mode.

Refer to Chapter 10 “SET AUDIO MODE”, Chapter 11 “SETTING THE PRISM CONSTANT VALUE” and Chapter 12 “SETTING ATMOSPHERIC CORRECTION” , for further instructions.

1.6 Serial signal RS-232C connector

The serial signal connector is used for connecting the TKS-200 series with a computer or GOWIN Data Collector, which enables the computer to receive measured data from the TKS-200 series or to send preset data of horizontal angle, etc. to it.

·The following data will be output at each mode.

MODE	Output
Angle mode(V,HR or HL) V is expressed with a percentage)	V, HR (or HL)
Horizontal distance mode (HR, HD, VD)	V, HR, HD,VD
Slope distance mode (V,HR,SD)	V, HR, SD,HD
Coordinate mode	N, E, Z,HR (or V, HR, SD, N, E, Z)

·The display and the output at the coarse mode are the same as the contents above:

·Output at the tracking mode is displayed as distance data only.

The details necessary for the connection with the TKS-200 series are obtained from its Interface Manual which is optionally available. please refer to this manual.

2. PREPARATION FOR MEASUREMENT

2.1 Setting Instrument Up For Measurement

Mount the instrument to the tripod, level and center the instrument precisely, in order to obtain a best performance, the TOPCON wide-frame wooden tripod with a tripod screw of 5/8 in. diameter should be used.

Reference: Leveling and Centering the Instrument

1. Setting up the tripod


First, extend the extension legs to suitable lengths and tighten the screws on their midsections.

2. Attaching the Instrument on the Tripod Head

Place the instrument carefully on the tripod head and slide the instrument by loosening the tripod screw. If the plumb bob is positioned right over the center of the point, slightly tighten the tripod screw.

3. Roughly Leveling the Instrument by Using the Circular Level

- 1) Turn the leveling screws A and B to move the bubble in the circular level. The bubble is now located on a line perpendicular to a line running through the centers of the two leveling screws being adjusted.




- 2) Turn the leveling screw C to bring the bubble to the center of the circular level.

4. Centering by Using the Plate Level

- 1) Rotate the instrument horizontally by using the Horizontal motion/clamp screw and place the plate level parallel with the line connecting leveling screws A and B, and then bring the bubble to the center of the plate level by turning leveling screws A and B.
- 2) Rotate the instrument 90° (100g) around its vertical axis and turn the remaining leveling screw or C to center the bubble once more.




- 3) Repeat the procedures 1) and 2) for each 90° (100g) rotation of the instrument and check whether the bubble is correctly centered for all four points.



5. Centering by Using the Optical Plummet Telescope

Adjust the eyepiece of the optical plummet telescope to your eyesight.




Slide the instrument by loosening the tripod screw, place the point on the center mark, and then tighten the tripod screw. Sliding the instrument carefully not to rotate that allows you to get the least dislocation of the bubble.

6. Completely Leveling the Instrument

Leveling the instrument precisely in a similar way to 4. Rotate the instrument and check to see that the bubble is in the center of the plate level, then tighten the connection screw.

2.2 Power Switch Key ON

- 1. Confirm the instrument is leveled.
- 2. Turn the power switch ON (POWER key)




·Confirm the battery power remaining display. Replace with charged battery or charge when battery level is low or indicates “Battery empty”.

·Contrast adjustment


You can confirm prism constant value (PSM),atmospheric correction value (PPM) and you can also adjust the contrast of the display when the instrument is turned on.

To display this screen, see Chapter 16 “SELECTING MODE” ..



This enables you to adjust the brightness by pressing the [F1](↓) or [F2](↑) key. To memorize the setting value after powering off, press [F4](ENTER) key.

2.3 Battery Power Remaining Display



Note:

- 1)The battery operating time will vary depending on the environmental conditions such as ambient temperature, charging time, the number of times of charging and discharging etc.It is recommended for safety to charge the battery beforehand and prepare fully charged spare batteries
- 2)For general usage of the battery, see Chapter 14 "POWER SOURCE AND CHARGING".
- 3)The battery power remaining display shows the power level regarding to the measurement mode now operating.The safety condition indicated by the battery power remaining display in the angle measurement mode does not necessarily assure the battery's capacity to be used in the distance measurement mode.It may happen that the mode change from the angle mode to the distance mode will stop the operation because of insufficient battery power for the distance mode which consumes more power than angle mode.

2.4 Vertical Angle Tilt Correction

Under angle measurement mode, you can select the tilt ON/OFF function on Page 2, this setting is not memorized after power is OFF.

[Example] Setting X Tilt Correction OFF

Operating procedure	Option	Display
1 Press [F4] key to get the function page 2.	[F4]	<div>V : 90°10'20" HR : 120°30'40" 0SET HOLD HSET P1↓ ----- TILT REP V% P2↓</div>
2 Press [F1](TILT) key. In case ON is already selected, the display shows tilt correction value.	[F1]	<div>TILT SENSOR : [ON] X: - 0°00'25" TILT --- OFF ---</div>
3 Press [F3](OFF) key.	[F3]	<div>TILT SENSOR : [OFF] TILT --- OFF ---</div>
4 Press [ESC] key.	[ESC]	<div>V : 90°10'20" HR : 120°30'40" 0SET HOLD HSET P1↓</div>
The setting mode performed here will not be memorized after powering OFF. To set TILT correction in the initialized setting (it is memorized after powering OFF), see Section 6.4.3“Vertical Angle Tilt correction (Tilt ON/OFF)” .		

2.5 How to Enter Alphanumeric Characters


In this section, the entry of alphanumeric charcters is introduced, such as instrument height, prism height, occupied point and backsight point etc.

• How to select a item

[Example] Occupied point in the data collection mode.

The arrow indicates the entry to be entered

The arrow line moves up or down when the[↓] key or [↑] key is pressed.



• Enter characters

1 Move the arrow to enter a item using the [↓] or [↑] key.

PT#	→
ID	:
INS.HT	: 0.000m
INPUT	SRCH REC OCNEZ

2 Press[F1](INPUT)key,arrow(→)
Is changed into equal (=)

PT#	=
ID:	
INS.HT.:	0.000m
[NUM]	[SPC] [CLR] [ENT]

3 Press[F1][ALP]key. The instrument will switch to alphanumeric enter mode	<div>PT# =</div> <div>ID:</div> <div>INS.HT : 0.000m</div> <div>[NUM] [SPC] [CLR] [ENT]</div>
4 Enter letters of the alphabet by pressing the alphanumeric characters key.Example: [9] (GHI) key is pressed once.	<div>PT# =G</div> <div>ID :</div> <div>INS.HT : 0.000m</div> <div>[NUM] [SPC] [CLR] [ENT]</div>
5 to enter other alphanumeric characters with the same method	<div>PT# =GOWIN</div> <div>ID :</div> <div>INS.HT : 0.000 m</div> <div>[NUM] [SPC] [CLR] [ENT]</div>
6 Press the [F1] (NUM) key, again.The instrument switches back to numerical input mode.	<div>PT# =GOWIN</div> <div>ID :</div> <div>INS.HT : 0.000 m</div> <div>[ALP] [SPC] [CLR] [ENT]</div>
7 Enter numbers by pressing the alphanumeric characters key. Example: press[-],[1]key	<div>PT# =GOWIN-I</div> <div>ID :</div> <div>INS.HT : 0.000 m</div> <div>[ALP] [SPC] [CLR] [ENT]</div>
8 press[F4] (ENT)key,the arrow will move To next item Select next character in the same manner.	<div>PT# =GOWIN-I</div> <div>ID :</div> <div>INS.HT :0.000 m</div> <div>[NUM] [SPC] [CLR] [ENT]</div>


·To correct a character, move the cursor to correct character by pressing [←] or [→] key and enter again.

3. ANGLE MEASUREMENT

3.1 Measuring Horizontal Angle Right and Vertical Angle

Make sure the mode is in Angle measurement.

Operating procedure	Operation	Display
1 Collimate the first target A	Collimate A	<div>V : 90°10'20"</div> <div>HR : 120°30'40"</div> <div>0SET HOLD HSET P1↓</div>
2 Set horizontal angle of target A at 0° 00' 00". Press the [F1](0 set) key and press the [F3](YES) key.	[F1]	<div>H ANGLE 0 SET</div> <div>> 0K?</div> <div> <input type="checkbox"/> <input type="checkbox"/> [YES] [NO] </div>
	[F3]	<div>V : 90°10'20"</div> <div>HR : 0°00'00"</div> <div>0SET HOLD HSET P1↓</div>
3 Collimate the 2nd target (B).The required V/H angle to target B will be displayed.	Collimate target B	<div>V : 98°36'20"</div> <div>HR : 160°40'20"</div> <div>0SET HOLD HSET P1↓</div>
Reference : How to Collimate the target <div>1 Point the telescope toward the light. Turn the diopter ring and adjust the diopter so that the cross hairs are clearly observed.(Turn the diopter ring toward you first and then backward to focus)</div> <div>2 Aim the target at the peak of the triangle mark of the sighting collimator. Allow a certain space between the sighting collimator and yourself for collimating.</div> <div>3 Focus the target with the focusing knob.</div>		



*If parallax is created between the cross hairs and the target when viewing vertically or horizontally while looking into the telescope, focusing is incorrect or diopter adjustment is poor, which will effect the viewing precision, this adversely affects precision in measurement or survey, Eliminate the parallax by carefully focusing and using diopter adjustment.

3.2 Switching Horizontal Angel (Right/Left)

Make sure that it is under the Angle measurement mode.

Operating procedure	Operation	Display
1 Press[F4](↓)key twice to get the function on P3.	[F4] Twice	<div> V : 90°10'20" HR : 120°30'40" 0SET HOLD HSET P1↓ <hr/> TILT REP V% P2↓ <hr/> H-BZ R / L CMPS P3↓ </div>
2 Press[F2] (R / L)key. The mode Horizontal angle Right (HR) switches to Left (HL) mode.	[F2]	<div> V : 90°10'20" HL : 239°29'20" H-BZ R / L CMPS P3↓ </div>
3 measure as HL mode		
• Every time pressing the [F2](R/L) key, HR/HL mode switches.		

3.3 Measuring from the Required Horizontal Angle

3.3.1 Setting by Holding the Angle

Make sure the mode is Angle measurement

Operating procedure	Operation	Display
1 Set the required horizontal angle, using Horizontal tangent screw.	Display angle	V : 90°10'20" HR : 130°40'20" 0SET HOLD HSET P1↓
2 press[F2](HOLD)key	[F2]	H ANGLE HOLD HR = 130°40'20" >SET? <input type="checkbox"/> <input type="checkbox"/> [YES] [NO]
3 Collimate the target	Collimate	
4 press[F3](yes)key to finish holding horizontal angle.*1) ,the display turns back to normal angle measurement mode	[F3]	V : 90°10'20" HR : 130°40'20" 0SET HOLD HSET P1↓
*1) To return to the previous mode, press the [F4](NO) key.		

3.3.2 Setting a Horizontal Angle from the Keys

Make sure the mode is Angle measurement

Operating procedure	Operation	Display
1 Collimate the target	Collimate	V : 90°10'20" HR : 170°30'20" 0SET HOLD HSET P1↓
2 press[F3](HSET)key	[F3]	H ANGLE SET HR= <input type="checkbox"/> <input type="checkbox"/> [CLR] [ENT]
3 Input the required horizontal angle by using keys. *1) *1) such as: 70°40'20"	70.4020 [F4]	V : 90°10'20" HR : 70°40'20" 0SET HOLD HSET P1↓
Then normal measurement can be done from the required horizontal angle Refer to Section 2.5 “How to Enter Alphanumeric characters”		

3.4 Vertical Angle Percent Grade (%) Mode

Make sure the mode is Angle measurement

Operating procedure	Operation	Display
1 Press[F4](↓)key twice to turn to P2	[F4]	<div>V : 90°10'20"</div> <div>HR : 170°30'20"</div> <div>0SET HOLD HSET P1↓</div> <div>-----</div> <div>TILT REP V% P2↓</div>
2 Press[F3](V%)key *1)	[F3]	<div>V : - 0.30 %</div> <div>HR : 170°30'20"</div> <div>TILT REP V% P1↓</div>
<div>*1)Whenever press[F3](V%)key, the display mode will switch over alternatively.</div> <div>• When the measurement is carried out over ±45° (±100%) from the horizontal, the display shows<OVER>.</div>		

3.5 Repetition Angle Measurement

- Repetition angle measurement can be done by horizontal angle right measurement mode.

Make sure the mode is Horizontal Angle Right measurement.

Operating procedure	Operation	Display
1 Press[F4](↓)key to get the function on P2.	[F4]	<div>V : 90°10'20"</div> <div>HR : 170°30'20"</div> <div>0SET HOLD HSET P1↓</div> <div>-----</div> <div>TILT REP V% P2↓</div>
2 press[F2](REP)key.	[F2]	<div>REPETITION ANGLE</div> <div>>OK?</div> <div><input type="checkbox"/> <input type="checkbox"/> [YES] [NO]</div>
3 Press[F3](YES) key.	[F3]	<div>REP-ANGLE COUNT[0]</div> <div>Ht: 0°00'00"</div> <div>Hm:</div> <div>0SET V/H REL HOLD</div>

4 Collimate target A and press[F1] (0SET)key	Collimate A [F3]	<div>REPETITION ANGLE INITIALIZE >OK? --- --- [YES] [NO]</div>
5 press[F3](YES)key	[F3]	<div>REP-ANGLE COUNT[0] Ht : 0°00'00" Hm : 0SET V/H REL HOLD</div>
6 Collimate the target B using the horizontal clamp and tangent screw.Press the [F4](HOLD) key.	Collimate B [F4]	<div>REP-ANGLE COUNT[1] Ht : 45°10'00" Hm : 45°10'00" 0SET V/H REL HOLD</div>
7 Recollimate target A using the horizontal clamp and tangent screw, and press the [F3] (REL) key.	Collimate Target A [F3]	<div>REP-ANGLE COUNT[1] Ht: 45°10'00" Hm: 45°10'00" 0SET V/H REL HOLD</div>
8 Recollimate target B using the horizontal clamp and tangent screw, and press the [F4] (HOLD)key.	Collimate B [F4]	<div>REP-ANGLE COUNT[2] Ht : 90°20'00" Hm : 45°10'00" 0SET V/H REL HOLD</div>
9 Repeat 7 to 8 to measure the desired number of repetitions.		<div>REP-ANGLE COUNT[4] Ht: 180°40'00" Hm: 45°10'00" 0SET V/H REL HOLD</div>
10 To return to the normal angle mode, press the [F2](V/H) key or [ESC] key.	[ESC] Or [F2]	<div>REPETITION ANGLE Exit >OK? <input type="checkbox"/> <input type="checkbox"/> [YES] [NO]</div>
11 Press[F3](YES)key	[F3]	<div> <div>V : 90°10'20"</div> <div>HR : 170030'20"</div> <div>0SET HOLD HSET P1↓</div> </div>

- Horizontal angle can account to(3600°00'00"-minimum reading)(horizontal angle(right angle)))
In case of 5 second reading, horizontal angle can be accumulated up to +3599° 59'55".
- Error will be displayed when the results differ from first measurement by more than $\pm 30''$.

3.6 Buzzer Sounding for Horizontal Angle 90° Increments

When the horizontal angle falls in the range of less than $\pm 1^\circ$ of 0° , 90° , 180° or 270° , the buzzer sounds. Buzzer stops only when the horizontal angle is adjusted to $0^\circ 00' 00''$, $90^\circ 00' 00''$, $180^\circ 00' 00''$ or $270^\circ 00' 00''$.


This setting is not memorized after powering off. Refer to 16 "SELECTING MODE" to set the initial setting (memorized after powering off).

Make sure the mode is Angle measurement.

Operating procedure	Operation	Display
1 Press[F4](↓)key twice, enter enter P3 function	[F4] Twice	<div> V : 90°10'20" HR : 120°30'20" 0SET HOLD HSET P1↓ ----- H-BZ R / L CMPS P3↓ </div>
2 Press[F1](H-BZer)key, to show last setting status	[F1]	<div> H-ANGLE BUZZER [OFF] [ON] [OFF] --- ENTER </div>
3 Press the [F1](ON) key or [F2](OFF) key to select the buzzer ON/OFF.	[F1]Or[F2]	<div> H-ANGLE BUZZER [ON] [ON] [OFF] --- ENTER </div>
4 press[F4](ENTER)key	[F4]	<div> V : 90°10'20" HR : 170°30'20" 0SET HOLD HSET P1↓ </div>

Compasses (vertical angle)

Vertical angle is displayed as shown below.



Operating procedure	Operation	Display
1 Press the [F4](↓) key twice to get the function on page 3	[F4] Twice	<div>V : 98°10'20" HR : 170°30'20" 0SET HOLD HSET P1↓ ----- H-BZ R / L CMPS P3↓</div>
2 press[F3](CMPS)key *1	[F3]	<div>V : - 8°10'20" HR : 170°30'20" H-BZ R / L CMPS P3↓</div>
*1) Every time pressing the [F3](CMPS) key, the display mode switches.		

4. DISTANCE MEASUREMENT

4.1 Setting of the Atmospheric Correction



When setting atmospheric correction, the correction value can be acquired by measurement of temperature and air pressure,
Refer to 12.2 “setting of atmospheric correction value ”.

4.2 Setting of the Correction for Prism Constant

If the prism is of another manufacturer,the appropriate constant shall be set beforehand,Refer to 11 "Setting the prism constant value", even the power is off, The setting value is kept in the memory.

4.3 Distance Measurement (Continuous Measurement)

Make sure that it is under the angle measurement mode.

Operating procedure	Operation	Display
1 Collimate the center of prism.	Collimate P	<div>V : 90°10'20"</div> <div>HR : 120°30'40"</div> <div>0SET HOLD HSET P1↓</div>
2 Press the [] key. Distance measurement starts. *1), *2)		<div>HR : 120°30'40"</div> <div>HD* [r] <<m</div> <div>VD : m</div> <div>MEAS MODE S / A P1↓</div>
The measured distances are shown. *3)~*5)		<div>HR : 120°30'40"</div> <div>HD* 123.456m</div> <div>VD : 5.678m</div> <div>MEAS MODE S / A P1↓</div>
• Pressing the [] key again, the display changes to horizontal (HR) and vertical (V)angle and slope distance(SD). *6)		<div>V : 90°10'20"</div> <div>HR : 120°30'40"</div> <div>SD : 131.678m</div> <div>MEAS MODE S / A P1↓</div>

- *1)When EDM is working, the " * " mark appears in the display.
- *2)To change mode from Fine to Coarse or Tracking, refer to section 4.5 "Fine Mode/Tracking Mode/Coarse Mode".To set the instrument power supply that when it is on, it will enter distance measurement mode, refer to Mode 16"Selecting mode". "
- *3)The distance unit indicator "m" (for meter) , "f" (for feet or feet inch) appears and disappears alternatively with buzzer sounds at every renewal of distance data.
- *4)Measurement may repeat automatically in the instrument if the result is affected by shimmer etc.
- *5)To return to the normal measuring angle mode from a distance measuring mode, press the [ANG] key.
- *6)It is possible to choose the display order (HR, HD, VD) or (V, HR, SD) for initial measuring distance mode. Refer to Chapter 16 "SELECTING MODE".

4.4 Distance Measurement (N-time Measurement/Single Measurement)

When the number of times measurement is preset, the TKS-200 series measures the distance the set number of times. The average distance will be displayed.

When presetting the number of times as 1, it does not display the average distance, because of single measurement. Single measurement is set at the factory.

Make sure that it is under angle measurement mode.

Operating procedure	Operation	Display
1 Collimate the prism center	Collimate	V : 90°10'20" HR : 120°30'40" 0SET HOLD HSET P1↓
2 press [▲] key, continuous measurement starts.*1)	[▲]	HR : 120°30'40" HD* [r] <<m VD : m MEAS MODE S / A P1↓
3 Press [F1](MEAS) key while continuous measuring is exceeding. *2). The average value is displayed and "*" mark disappears.	[F1]	HR : 120°30'40" HD* [n] <<m VD : MEAS MODE S / A P1↓ ↓

<ul style="list-style-type: none"> While EDM is working, press [F1](MEAS) key again, the mode will be changed to continuous measuring mode. 		<div> HR : 120°30'40" HD : 123.456m VD : 5.678m MEAS MODE S / A P1↓ </div>
<p>*1) It is possible to set the measurement mode for N-times measurement mode or continuous measurement mode when the power is turned on. Refer to Chapter 16 “SELECTING MODE”.</p> <p>*2) For setting the number of times (N-times) in the measurement, refer to Chapter 16 “SELECTINGMODE”.</p>		

·Choose meter /feet / feet+inch unit by soft key

It is possible to change the unit for distance measurement mode by soft key.

This setting is not memorized after power off. Refer to 16 “SELECTING MODE” to set at the initial setting (memorized after power off).

Operating procedure	Operation	Display
1 Press[F4](↓)to skip to P2 function	[F4]	<div> HR : 120°30'40" HD*: 2.000m VD : 3.000m MEAS MODE S / A P1↓ ----- OFSET S.O m/f/i P2↓ </div>
2 Every time pressing the [F3](m/f/i) key, the display unit will be changed. • Every time pressing the [F3](m/f/i) key, the unit mode switches.	[F3]	<div> HR : 120°30'40" HD*: 6.560f VD : 9.845f OFSET S.O m/f/i P2↓ </div>

4.5 Fine Mode/Tracking Mode/Coarse Mode

This setting is not memorized after power is off. Refer to Chapter 16 "SELECTING MODE" to set at the initial setting (memorized after power is off).

- Fine Mode: This is a normal distance measuring mode.
The unit to be displayed: 0.2mm or 1mm. (0.001ft or 0.005ft)
Measurement time 0.2mm mode: approx. 2.8 sec.
1mm mode: approx. 1.2 sec.
- Tracking Mode: This mode measures in shorter time than in fine mode.
It is very useful when tailing the moving object or carrying out stake-out work.
The unit to be displayed: 10mm
Measuring time: approx. 0.4 sec.
- Coarse Mode : This mode measures in shorter time than in fine mode.
The unit to be displayed: 10mm or 1mm
Measuring time: approx. 0.7 sec.

Operating procedure	Operation	Display
1 Press the [F2](MODE) key from the distance measuring mode.*1) The initial character (F/T/C) of set mode is displayed . (F:Fine, T:Tracking, C:Coarse)	[F2]	<div>HR : 120°30'40"</div> <div>HD*: 123.456m</div> <div>VD : 5.678m</div> <div>MEAS MODE S/A P1↓</div>
2 Press the [F1](FINE) key, [F2](TRACK) key, or [F3](COARSE) key.	[F1]~[F3]	<div>HR : 120°30'40"</div> <div>HD*: 123.456m</div> <div>VD : 5.678m</div> <div>FINE TRACK COARSE F</div>
		<div>HR : 120°30'40"</div> <div>HD*: 123.456m</div> <div>VD : 5.678m</div> <div>MEAS MODE S/A P1↓</div>
*1)If want to delete the setting, press[ESC]key		

4.6 Stake Out (S.O)

The difference between the measured distance and the input stake out distance is displayed.

Measured distance - Stake out distance = Displayed value

In stake out operation, you can select either horizontal distance (HD), relative elevation (VD) and slope distance (SD)

Operating procedure	Operation	Display
<div><input type="checkbox"/> Press the [F4](↓) key in the distance measuring mode to get the function on page 2.</div> <div><input type="checkbox"/> Press the [F2](S.O) key. The data previously set is shown.</div> <div><input type="checkbox"/> Select the measuring mode by pressing the [F1] to[F3] key.</div> <div><input type="checkbox"/> Enter the distance for stake out. *1)</div> <div><input type="checkbox"/> Collimate the target (prism) measurement starts. The difference between the measured distance and the stake out distance is displayed.</div> <div><input type="checkbox"/> Move the target until the difference becomes 0m.</div>	[F4]	<div>HR : 120°30'40"</div> <div>HD*: 123.456m</div> <div>VD : 5.678m</div> <div>MEAS MODE S/A P1↓</div> <div>-----</div> <div>OFFSET S.O m/f/i P2↓</div>
	[F2]	<div>STAKE OUT</div> <div>HD : 0.000m</div> <div>HD VD SD ---</div>
	[F1]	<div>STAKE OUT</div> <div>HD : 0.000m</div> <div>--- [CLR] [ENT]</div>
	Enter data [F4]	<div>STAKE OUT</div> <div>HD : 100.000m</div> <div>INPUT --- Enter</div>
	Collimate P	<div>HR : 120°30'40"</div> <div>dHD* [r] 23.456m</div> <div>VD : 5.678m</div> <div>MEAS MODE S/A P1↓</div>
		<div>HR : 120°30'40"</div> <div>dHD* [r] 23.456m</div> <div>VD : 5.678m</div> <div>MEAS MODE S/A P1↓</div>
<div>1) Refer to section 2.5 “How to Enter Alphanumeric characters”.</div> <div>• To return to normal distance measurement mode, stake out distance to "0" m or turn the power off.</div>		

4.7 Offset Measurement

- There are four offset measurement modes in the Offset Measurement.
- Angle Offset
- Distance Offset
- Plane Offset
- Column Offset
- To show the offset measurement menu, press the [OFSET] soft key from distance or coordinate measurement mode.

Example:

Distance measurement

HR :	120°30'40"		
HD :	123.456 m		
VD :	5.678 m		
MEAS	MODE	S/A	P1↓

OFFSET	S.O	m/f/i	P2↓

↑
Press[F1](OFSET)key

Coordinate measurement

N:	123.456	m	
E:	34.567	m	
Z:	78.912	m	
MEAS	MODE	S/A	P1↓

R.HT	INSHT	OCC	P2↓

OFFSET	---	m/f/i	P3↓

↑
Press[F1](OFSET)key

Offset Measurement Menu

OFFSET	1/2
F1: ANG. Offset	
F2: DIST. Offset	
F3: PLANE Offset	P↓

↑
↓ [F4]

OFFSET	2/2
F1: COLUMN OFFSET	
	P↓

• Outputting the Measurement Data

The results of offset measurement can be output to external device.

Setting the function of the [ESC] key to (REC), the [F3] soft key which assigned (REC) will appear in measured result display.

Refer to Chapter 16 “SELECTING MODE” to set this option..

OFFSET-MEASUREMEN			
HR:	120°30'40"		
SD:	123.456m		
Next	---	REC	---

↑
[F3]

• Distance measurement mode in offset

measurement

Offset measurement will be done by N-time fine measurement mode.


For setting measuring times refer to Chapter 16 “SELECTING MODE”.

4.7.1 Angle Offset

This mode is useful when it is difficult to set up the prism directly, for example at the center of a tree. Place the prism at the same horizontal distance from the

instrument as that of point A0 to measure. To measure the coordinates of the center position, operate the offset measurement after setting the instrument height/prism height.

- When measuring coordinates of ground point A1 :Set the instrument height/prism height.








When sighting to A0, you can select one of two ways. One is to fix vertical angle to the prism position even updown the telescope position, and the other is to gear vertical angle to the updown of telescope movement. In case following the vertical angle to the movement of

- When measuring coordinates of point A0 : Set the instrument height only. (Set the prism height to 0).

telescope,SD(Slope Distance) and VD(Vertical Distance) will be changed according to the movement of telescope. To set this option, refer to Chapter 16


- Set the instrument height/prism height before proceeding to the offset measurement mode.
- When setting the coordinate value for the occupied station, refer to Section 5.1 “Setting Coordinate Values of Occupied Point”.

Operating procedure	Operation	Display
<input type="checkbox"/> Press the [F4](P1↓) key from distance measuring mode to get the function on page 2. <input type="checkbox"/> press F1(OFFSET)key <input type="checkbox"/> press F1 ANG.OFFSET key <input type="checkbox"/> Collimate prism P.press F1(MEAS)key The horizontal distance from the instrument to the prism will be measured.	[F4]	HR : 120°30'40" HD : 123.456 m VD : 5.678 m MEAS MODE S/A P1↓ ----- OFFSET S.O m/f/i P2↓
	[F1]	OFFSET 1/2 F1 ANG.OFFSET F2 DIST. OFFSET F3 PLANE OFFSET P1↓
	[F1]	OFFSET-MEASUREMENT HR : 120°30'40" HD : m MEAS --- --- ---
	Collimate[P] [F1]	OFFSET-MEASUREMENT HR : 110°30'40" HD* [n] <<m >Measuring.....
		OFFSET-MEASUREMENT HR : 110°20'30" HD* 56.789m >Measuring.....

<p>After measuring, the result added offset value will be shown.</p> <p><input type="checkbox"/> Collimate point A0 using the horizontal motion clamp and horizontal tangent screw.</p> <p><input type="checkbox"/> Show the relative elevation of point A0.</p> <p><input type="checkbox"/> Each time pressing the  key, horizontal distance, relative elevation and slope distance are shown in sequence.</p> <p><input type="checkbox"/> Show N coordinate of point A0 or A1.</p> <p>• Each time pressing  key, N,E and Z coordinate are shown in sequence.</p>	<p>Collimate A0</p> <p></p> <p></p> <p></p>	<div data-bbox="729 142 1216 329"> <p>OFFSET-MEASUREMENT</p> <p>HR : 110°20'30"</p> <p>HD : 56.789m</p> <p>NEXT --- --- ---</p> </div> <div data-bbox="729 411 1216 582"> <p>OFFSET-MEASUREMENT</p> <p>HR : 113°30'50"</p> <p>HD : 56.789m</p> <p>NEXT --- --- ---</p> </div> <div data-bbox="729 645 1216 816"> <p>OFFSET-MEASUREMENT</p> <p>HR : 113°20'30"</p> <p>VD : 3.456m</p> <p>NEXT --- --- ---</p> </div> <div data-bbox="729 870 1216 1058"> <p>OFFSET-MEASUREMENT</p> <p>HR : 113°20'30"</p> <p>SD: 56.894m</p> <p>NEXT --- --- ---</p> </div> <div data-bbox="729 1214 1216 1386"> <p>OFFSET-MEASUREMENT</p> <p>HR : 113°20'30"</p> <p>N: -12.345m</p> <p>NEXT --- --- ---</p> </div>
<p>• To return to procedure <input type="checkbox"/>, press [F1](NEXT) key.</p> <p>• To return to the previous mode, press [ESC] key.</p>		

4.7.2 Distance Offset Measurement

The measurement of a place apart from a prism is possible by inputting offset horizontal distance of front and back / right and left.





When measuring coordinates of ground point A1: Set the instrument height/prism height.

When measuring coordinates of point A0: Set the instrument height only.
(Set the prism height to 0).

- When setting coordinate values of occupied point, see Section 5.1 “Setting Coordinate Values of Occupied Point”

Operating procedure	Operation	Display
---------------------	-----------	---------

<p>□ Press the [F4](P1↓) key from distance measuring mode to get the function on page 2.</p>	<p>[F4]</p>	<div> HR : 120°30'40" HD* 123.456m VD : 5.678m MEAS MODE S/A P1↓ ----- OFFSET S.O m/f/i P2↓ </div>
<p>② press F1(OFFSET)key</p>	<p>[F1]</p>	<div> OFFSET 1/2 F1 ANG.OFFSET F2 DIST. OFFSET F3 PLANE OFFSET P1↓ </div>
<p>③ press[F2](DIST.OFFSET) key</p>	<p>[F2]</p>	<div> DISTANCE OFFSET HR : 80°30'40" HD : m >Measurement - - - </div>
<p>④ Enter Right and Left direction offset value, and press the [F4] (ENTER)key.</p>	<p>Enter HD [F4]</p>	<div> DISTANCE OFFSET INPUT RorL HD oHD= m --- [CLR] [ENT] </div>
<p>⑤ Enter a Forward direction offset value, and press the [F4] (ENTER) key.</p>	<p>Enter HD [F4]</p>	<div> DISTANCE OFFSET INPUT FORWARD HD OHD : m --- [CLR] [ENT] </div>
<p>⑥ Collimate prism P, and press the [F1](MEAS) key. Measuring will start. After measuring, the result added offset value will be shown.</p>	<p>Collimate P [F1]</p>	<div> DISTANCE OFFSET HR : 80°30'40" HD* [n] <<m >Measurement - - - </div>
<p>⑦ Show the relative elevation of point P0. Each time pressing</p>	<p></p>	<div> DISTANCE OFFSET HR : 80°30'40" HD* 10.000m NEXT --- --- --- </div>

the [] key, horizontal distance, relative elevation and slope distance are shown in sequence.

- Show coordinate of point P0.



DISTANCE OFFSET

HR : 80°30'40"

SD : 11.789m

NEXT --- --- ---

DISTANCE OFFSET

HR : 80°30'40"

VD : 11.789m

NEXT --- --- ---

N: 12.345m

E: 23.345m

Z: 1.345m


NEXT --- --- ---

- To return to procedure ④, press [F1](NEXT) key.
- To return to the previous mode, press [ESC] key.




4.7.3 Plane Offset Measurement

Measuring will be taken for the place where direct measuring can not be done, for example distance or coordinate measuring for a edge of a plane.

Three random prism points (P1, P2, P3) on a plane will be measured at first in the plane offset measurement to determine the measured plane. Collimate the measuring target point (P0) then the instrument calculates and displays coordinate and distance value of cross point between collimation axis and of the plane.




Operating procedure	Operation	Display
<input type="checkbox"/> Press the [F4](P1↓) key from distance measuring mode to get the function on page 2.	[F4]	<div> HR : 120°30'40" HD : 123.456m VD : 5.678m MEAS MODE S/A P1↓ ----- OFFSET S.O m/f/i P2↓ </div>
<input type="checkbox"/> press F1(OFFSET)key	[F1]	<div> OFFSET 1/2 F1 ANG.OFFSET F2 DIST. OFFSET F3 PLANE OFFSET P1↓ </div>
<input type="checkbox"/> press[F3](PLANE OFFSET)key	[F3]	<div> PLANE N001# SD: m MEAS --- --- --- </div>
<input type="checkbox"/> Collimate the center of the column (P1) and press the [F1](MEAS) key. N-time measuring will start.	Collimate P1 [F1]	<div> PLANE N001# SD* [n] <<m >Measurement - - - </div>
<input type="checkbox"/> carry out the measurement of 2nd and 3rd point with the same method	Collimate P2 [F1]	<div> PLANE N002# SD: m MEAS --- --- --- </div>
The instrument will compute and display the coordinate and distance value*1) *2)of cross point between collimation axis and plane	Collimate P3 [F1]	<div> Plane N003# SD: m MEAS --- --- --- </div>
		<div> ↓ <div> HR :80°30'40" HD : 54.321m VD : 10.000m EXIT </div> </div>

<p>□ Collimate plane edge(P0)*3)4)</p> <p>□ To show the slope distance (SD), press the [] key.</p> <ul style="list-style-type: none"> • Each time pressing the [] key, horizontal distance, relative elevation and slope distance are shown in sequence. • To show coordinate of point P0, press the [] key. <p>⑧ To escape the measuring, press the [F1](EXIT) key. The display returns to the previous mode.</p>	<p>Collimate P0</p>	<div data-bbox="753 165 1216 335"> <p>HR : 75°30'40"</p> <p>HD : 54.600m</p> <p>VD : -0.487m</p> <p>EXIT</p> </div> <div data-bbox="753 380 1216 550"> <p>V : 90°30'40"</p> <p>HR : 75°30'40"</p> <p>SD: 56.602m</p> <p>EXIT</p> </div>
<p>*1) In case the calculation of plane was not successful by the measured three points, error information displays. Start measuring over again from the first point.</p> <p>*2) Data display is the mode beforehand of offset measurement mode.</p> <p>*3) Error will be displayed when collimated to the direction which does not cross with the determined plane.</p> <p>*4) The reflector height of the target point P0 is set to zero automatically.</p>		





4.7.4 Column Offset Measurement

If it is possible to measure circumscription point (P1) of column directly, the distance to the center of the column (P0), coordinate and direction angle can be calculated by measured circumscription points (P2) and (P3). The direction angle of the center of the column equals to average value of the direction angle of circumscription points (P2) and (P3).



- When setting coordinate values of occupied point, refer to Section 5.1 "Setting Coordinate Values of Occupied Point"

Operating procedure	Operation	Display
① Press the [F4](P1↓) key from distance measuring mode to get the function on page 2.	[F4]	HR : 120°30'40" HD : 123.456m VD : 5.678m MEAS MODE S/A P1↓ ----- OFFSET S.O m/f/i P2↓
□ press[F1](OFFSET)key	[F1]	OFFSET 1/2 F1 ANG.OFFSET F2 DIST. OFFSET F3 PLANE OFFSET P1↓
③ press[F4](P↓)key	[F4]	OFFSET 2/2 F1: COLUMN OFFSET P↓
□ press[F1](COLUMN OFFSET) key	[F1]	COLUMN OFFSET Center HD : m MEAS --- --- ---

<p>⑤ Collimate the center of the column (P1) and press the [F1](MEAS) key. N-time measuring will start. After the measurement, angle measuring display of the left side (P2) will be shown.</p> <p>❑ Collimate the left side of the column (P2) and press the [F4](SET) key. after the measurement, angle measuring display of the right side (P3) will be shown.</p> <p>⑦ Collimate the right side of the column(P3) and press the [F4](SET) key.</p> <p>⑧ If you want to show vertical distance(VD), you can press  key, Each time pressing the  key, horizontal distance, relative elevation and slope distance are shown in sequence. To show coordinate of point P0, press the  key.</p> <p>⑨ To escape the measuring, press the [ESC] key. The display returns to the previous mode.</p>	<p>Collimate P1 [F1]</p> <p>Collimate P2 [F4]</p> <p>Collimate P3 [F4]</p> <p></p>	<div data-bbox="790 135 1227 306"> <p>COLUMN OFFSET Center HD* [n] <<m > Measurement - - -</p> </div> <p style="text-align: center;">↓</p> <div data-bbox="790 359 1227 531"> <p>COLUMN OFFSET Left HR : 120°30'40" --- --- --- SET</p> </div> <p style="text-align: center;">↓</p> <div data-bbox="790 597 1227 769"> <p>COLUMN OFFSET Right HR : 180°30'40" --- --- --- SET</p> </div> <p style="text-align: center;">↓</p> <div data-bbox="790 858 1227 1049"> <p>COLUMN OFFSET HR : 150°30'40" HD : 43.321m NEXT --- --- ---</p> </div> <p style="text-align: center;">↓</p> <div data-bbox="790 1239 1227 1410"> <p>COLUMN OFFSET HR : 150°30'40" VD : 2.321 m NEXT --- --- ---</p> </div>
---	---	---


5. COORDINATE MEASUREMENT

5.1 Setting Coordinate Values of Occupied Point

Set the coordinates of the instrument (occupied point) according to coordinate origin and the instrument automatically converts and displays the unknown point (prism point) coordinates following the origin.

It is possible to retain the coordinates of the occupied point after the power is off.

Refer to Chapter 16 “SELECTING MODE”.



Operating procedure	Operation	Display
<div> <input type="checkbox"/> Under coordinate measurement mode press[F4](↓)key,enter P2 function </div>	[F4]	<div> N: 123.456 m E: 34.567 m Z: 78.912 m MEAS MODE S/A P1↓ ----- R.HT INSHT OCC P2↓ </div>
<div> <input type="checkbox"/> Press[F3](OCC)key </div>	[F3]	<div> N= 0.000 m E: 0.000 m Z: 0.000 m --- --- [CLR] [ENT] </div>

<input type="checkbox"/> Enter N coordinate value *1) <input type="checkbox"/> Enter E and Z coordinate enter data with same method, the display backs to coordinate measurement show	Enter data [F4]	<div>N: -72.000 m E= 0.000 m Z: 0.000 m --- --- CLR] [ENT]</div> <div>N: 51.456 m E: 34.567 m Z: 78.912 m MEAS MODE S/A P1↓</div>
*1) Refer to 2.5 “How to Enter Alphanumeric characters”. • Input Range $-99999999.9990 \leq N.E.Z \leq +99999999.9990$ m $-99999999.999 \leq N.E.Z \leq +99999999.999$ ft $-99999999.11.7 \leq N.E.Z \leq +99999999.11.7$ ft+inch		

5.2 Setting Height of the Instrument

It is possible to retain the instrument height after the power is off. Refer to Chapter 16 “SELECTING MODE”.

Operating procedure	Operation	Display
① Under coordinate measurement mode press[F4](↓)key,enter P2 function	[F4]	<div>N: 123.456 m E: 34.567 m Z: 78.912 m MEAS MODE S/A P1↓ ----- R.HT INSHT OCC P2↓</div>
② Press the [F2](INSHT) key. The current value is displayed.	[F2]	<div>Instrument Height Enter INS.HT. 0.000m --- --- [CLR] [ENT]</div>
③ Enter instrument height*1)	Enter Inst.HT [F4]	<div>N: 123.456 m E: 34.567 m Z: 78.912 m MEAS MODE S/A P1↓</div>
*1)Refer to 2.5 “How to Enter Alphanumeric characters”. • Enter range $-999.9999 \leq \text{INS.HT.} \leq +999.9999$ m $-999.999 \leq \text{INS.HT.} \leq -999.999$ t $-999.11.7 \leq \text{INS.HT.} \leq +999.11.7$ ft+inch		

5.3 Setting Height of Target (Prism Height)

This mode can be used to obtain Z coordinate values . It is possible to retain the height of target after turning the power off. Refer to Chapter 16 “SELECTING MODE”.

Operating procedure	Operation	Display
<div>Under coordinate measurement mode press[F4](↓)key,enter P2 function</div>	[F4]	<div>N:123.456m E:34.567m Z:78.91 2m MEAS MODE S/A P1↓ ----- R.HT INSHT OCC P2</div>
<div>Press the [F1](R.HT) key. The current value is displayed.</div>	[F2]	<div>REFLECTOR HEIGHT INPUT R.HT= 0.000 m --- --- [CLR] [ENT]</div>
<div>Enter prism height*1)</div>	Enter R.HT [F4]	<div>N: 123.456 m E: 34.567 m Z: 78.91 2 m MEAS MODE S/A P1↓</div>
<div>*1) Refer to Section 2.5 “How to Enter Alphanumeric characters”.<ul style="list-style-type: none">Input Range -999.9999 ≤ Prism Height ≤ + 999.9999 m -999.999 ≤ Prism Height ≤ - 999.999 ft -999.11.7 ≤ Prism Height ≤ +999.11.7 ft+inch</div>		

5.4 Execution of Coordinate Measuring

Measure the coordinates by entering the instrument height and prism height, coordinates of unknown point will be measured directly.

- When setting coordinate values of occupied point, refer to Section 5.1 “Setting Coordinate Values of Occupied Point”
- To set the instrument height and target height, refer to 5.2 “Setting of instrument height” and 5.3 “Setting of target height (prism height)”.
- The coordinates of the unknown point are calculated and shown by following formula:
Coordinate of occupied point: (No,Eo,Zo)
Instrument Height :INS.HT
Prism height: R.HT

Vertical distance (Relative elevation) : z (VD)

Coordinates of the center of the prism,


originated from the center point of the instrument : (n,e,z)

Coordinates of unknown point : $(N1,E1,Z1)$

$$N1 = N_0 + n$$

$$E1 = E_0 + e$$

$$Z1 = Z_0 + \text{INS. HT} + z - \text{R.HT}$$




Operating procedure	Operation	Display
<input type="checkbox"/> To set the directional angle of known point A*1)	set directional angle	HR : 120°30'40" V : 90°10'20' 0SET HOLD HSET P1↓
<input type="checkbox"/> Collimate target B ③ press $\left[\begin{smallmatrix} \nearrow \\ \searrow \end{smallmatrix} \right]$ key, to start measurement The result will be shown.	Collimate P $\left[\begin{smallmatrix} \nearrow \\ \searrow \end{smallmatrix} \right]$	N*[r] << m E: m Z: m MEAS MODE S/A P1↓
		N: 123.456 m E: 34.567 m Z: 78.912 m MEAS MODE S/A P1↓

*1) Refer to 3.3 Setting of horizontal angle

- In case that the coordinate of occupied point is not entered, (0,0,0) will be the default occupied point coordinate;
- The instrument height will be calculated as 0 when the instrument height is not entered.
- The prism height will be calculated as 0 when the prism height is not set.

6. SPECIAL MODE (MENU MODE)


By pressing the [MENU] key, the instrument will be in MENU mode.
In this mode, special measuring , setting and adjustment are possible.



6.1 Application measurement (program)

6.1.1 Remote Elevation Measurement (REM)

To obtain elevation of the point at which setting the target prism is not possible, place the prism at any point on the vertical line from the target then carry out REM procedure as follows.



1) When there is prism height(h)input(example:h=1.5m)

Operating procedure	Operation	Display
<input type="checkbox"/> After pressing the [MENU] key, press the [F4](P↓) key to get the menu on page 2.	[MENU] [F4]	<div> menu 2/3 F1: Program F2: Grid Factor F3: Illumination P↓ </div>
<input type="checkbox"/> press[F1]key	[F1]	<div> PROGRAM 1/2 F1: REM F2: MLM F3: Z COORD. P↓ </div>

<div> <input type="checkbox"/> Press[F1](REM)key </div> <div> <input type="checkbox"/> press[F1]key </div> <div> <input type="checkbox"/> enter prism height*1 </div> <div> ⑥ Collimate the prism </div> <div> ⑦ press[F1](MEAS)key the measurement starts. </div> <div> Horizontal distance (HD) between the instrument and prism will be shown. </div> <div> <input type="checkbox"/> After measuring, the prism position will be decided. *2) </div> <div> <input type="checkbox"/> Collimate target K. Vertical distance (VD) will be shown. *3) </div>	<div>[F1]</div> <div>[F1]</div> <div> ENTER R.HT [F4] </div> <div> Collimate P [F1] </div> <div> Collimate K </div>	<div> REM F1: INPUT R.HT F2: NO R.HT </div> <div> REM-1 <STEP 1> R.HT = 0.000 m --- --- [CLR] [ENT] </div> <div> REM-1 <STEP 2> HD : m MEAS --- --- SET </div> <div> REM-1 <STEP 2> HD * [n] <<m Measurement ↓ </div> <div> REM-1 <STEP 2> HD* 123.456m Measurement..... </div> <div> REM-1 VD : 1.500 m --- R.HT. HD --- </div> <div> REM-1 VD : 10.456 m --- R.HT. HD --- </div>
<div> *1) Refer to Section 2.5 “How to Enter Alphanumeric characters”. </div> <div> *2) press[F2](R.HT.)key, back to Step ⑤: press[F3](HD)key, back to Step ⑥. </div> <div> *3) press[ESC]key, back to program menu. </div>		

2) Without prism height input

Operating procedure	Operation	Display
□press[MENU]key, press [F4],enter P2 menu	[MENU] [F4]	MENU 2/3 F1: PROGRAMS F2: GRID FACTOR F3: ILLUMINATION P ↓
□press[F1]key	[F1]	PROGRAM 1/2 F1: REM F2: MLM F3: Z COORD. P↓
□Press[F1](REM)key	[F1]	REM 1/2 F1: enter R.HT F2: R.HT. is unnecessary
□press[F2]key	[F2]	REM-2 <STEP-1> HD : m MEAS --- --- ---
□Collimate the prism	Collimate P [F1]	REM-2 <STEP-1> HD* [n] <<m > Measurement
□press[F1](MEAS)key measurement starts. to show the Horizontal distance (HD) between the instrument and prism will be shown.		REM-2 <STEP-1> HD* 123.456 m > Measurement
□After measuring, the prism position will be decided.		REM-2 <STEP-2> V : 604550 --- --- --- SET


<input type="checkbox"/> Collimate the ground point G <input type="checkbox"/> Press the [F4](SET) key. The position of point G will be decided. *1) <input type="checkbox"/> Collimate target K. Vertical distance (VD) will be shown.*2)	CollimateG	<div>REM-2 <STEP 2> V : 123°45'50" --- --- --- SET</div>
	[F4]	<div>REM-2 VD : 0.000 m --- V HD ---</div>
	Collimate K	<div>REM-2 VD : 10.456 m --- V HD ---</div>
<p>*1) To return to procedure <input type="checkbox"/>, press the [F3](HD) key. To return to procedure <input type="checkbox"/>, press the [F2](V) key.</p> <p>*2) To return to PROGRAMS Menu, press the [ESC] key.</p>		

6.1.2 Missing Line Measurement (MLM)

Measurement for horizontal distance (dHD), slope distance (dSD), elevation (dVD) and horizontal angle (HR) between two target prisms. It is possible to enter the coordinate value directly or calculate from coordinate data file.

MLM mode has two functions.

1. MLM-1 (A-B, A-C): measure A-B, A-C, A-D,
2. MLM-2 (A-B, B-C): measure A-B, B-C, C-D,





- must set the directional angle of instrument

[Example]MLM-1(A-B,A-C)

- Procedure of MLM-2 (A-B, B-C) mode is completely same as MLM-1 mode

Operating procedure	Operation	Display
□press[MENU]key,then press[F4]P1↓key to enter P2 menu	[MENU] [F4]	MENU 2/3 F1: PROGRAMS F2: GRID FACTOR F3: ILLUMINATION P↓
□press[F1]key	[F1]	PROGRAM 1/2 F1: REM F2: MLM F3: Z COORD. P↓
□Press[F2](MLM)key	[F2]	MLM F1: USE FILE F2: DON'T USE
□Press the [F1] or [F2] key to select using coordinate file. [Example:F2 : DON'T USE]	[F2]	GRID FACTOR F1: USE FILE F2: DON'T USE
□Press the [F1] or [F2] key to select using GRID FACTOR. [Example:F2 : DON'T USE]	[F2]	MLM F1: MLM-1(A-B,A-C) F2: MLM-2(A-B,B-C)
□Press[F1]key	[F1]	MLM-1 (A-B,A-C) <STEP 1> HD : m MEAS R.HT NEZ ---
□Collimate prism A, press[F1] (MEAS)key. (HD) between the instrument and prism A will be shown.	Collimate A [F1]	MLM-1(A-B, A-C) <STEP 1> HD*[n] <<m >Measurement...

<p>□ After measuring, the prism position will be decided.</p>		<div>MLM-1(A-B, A-C) <STEP 2> HD : m MEAS R.HT NEZ ---</div>
<p>□ Collimate prism B, press [F1] (MEAS) key. (HD) between the instrument and prism B will be shown.</p>	Collimate B [F1]	<div>MLM-1(A-B, A-C) <Step 2> HD*[n] <m MEAS R.HT NEZ ---</div>
<p>□ After measuring, the horizontal distance (dHD) and relative elevation (dVD) between prism A and B will be shown.</p>		<div>↓</div> <div>MLM-1(A-B, A-C) dHD : 123.456m dVD : 12.345m --- --- HD ---</div>
<p>11 To show slope distance (dSD) , press [] key.</p>	[]	<div>MLM-1 (A-B, A-C) dSD: 234.567 m HR : 12°34'40" --- --- HD ---</div>
<p>12 To measure the distance between points A and C, press the [F3](HD). *1)</p>	[F3]	<div>MLM-1(A-B, A-C) <Step 2> HD : m MEAS R.HT NEZ ---</div>
<p>13 Collimate point C (Prism C) and press the [F1](MEAS) key. Horizontal distance (HD) between the instrument and prism C will be shown.</p>	Collimate Prism C [F1]	<div>□ □ □ □ □</div>
<p>14 After measuring, the horizontal distance (dHD) and relative elevation (dVD) between prism A and C will be shown.</p>	[F4]	<div>MLM-1 (A-B, A-C) dHD: 234.567 m dVD: 23.456 m --- --- HD ---</div>

1) Setting occupied coordinate

[Example setting] Using coordinate data file.

Operating procedure	Operation	Display
<input type="checkbox"/> press[MENU]key, then press[F4](P)↓ Show main menu 2/3	[MENU] [F4]	<div> MENU 2/3 F1: PROGRAM F2: GRID FACTOR F3: ILLUMINATION P ↓ </div>
<input type="checkbox"/> press[F1]key	[F1]	<div> PROGRAMS 1/2 F1: REM F2: MLM F3: Z COORD. P↓ </div>
<input type="checkbox"/> Press[F3](Z COORD.)key	[F3]	<div> Setting Z COORD F1: input from OCC PT F2: datum point measurement </div>
<input type="checkbox"/> press[F1](use a file)key	[F1]	<div> OCC.PT FN: _____ INPUT LIST NEZ ENTER </div>
<input type="checkbox"/> [F1](INPUT)key, after enter the filename, ress[F4] onfirm	[F1] Input FN [F4]	<div> Setting of Coordinate Z F1: input from occupied point F2: datum point measurement </div>
<input type="checkbox"/> press[F1]key	[F1]	<div> OCC.PT PT# : _____ INPUT LIST NEZ ENTER </div>
<input type="checkbox"/> Press the [F1](INPUT) key and enter the Point number. Instrument height setting display will be shown.	[F1] Input PT# [F4]	<div> INSTRUMENT HEIGHT INPUT INS.HT = 0.000 m --- --- [CLR] [ENT] </div>

<input type="checkbox"/> Enter the height. The display returns to Z coordinate menu.	[F1] Input HT [F4]	<div> Setting of Coordinate Z F1: input from occupied point F2: datum point measurement </div>
• For data file details, refer to 9 “Memory Manager Mode”		

2) Z Coordinate Calculation from Known Point Measuring Data

[Example] use a coordinate data file

Operating procedure	Operation	Display
<input type="checkbox"/> After pressing [MENU] key, press [F4](P↓) key to get the menu on page 2.	[MENU] [F4]	<div> MENU 2/3 F1: PROGRAM F2: GRID FACTOR F3: ILLUMINATION P ↓ </div>
<input type="checkbox"/> press[F1]key	[F1]	<div> PROGRAMS 1/2 F1:REM F2:MLM F3:Z COORD. P↓ </div>
<input type="checkbox"/> Press[F3](Z COORD)key	[F3]	<div> Z COORD.SETTING F1: USE FILE F2: DON`T USE </div>
④press[F1](USE FILE)key	[F1]	<div> SELECT A FILE FN: _____ INPUT LIST --- ENTER </div>
⑤Press the [F1](INPUT) key and enter the File Name.	[F1] Input FN [F4]	<div> Z COORD.SETTING F1: OCC.PT INPUT F2: REF.MEAS </div>
⑥press[F2]key	[F2]	<div> N001# PT#: _____ INPUT LIST NEZ ENTER </div>

<p>⑦ Press the [F1](INPUT) key and enter the Point Number in coordinate data file.</p> <p><input type="checkbox"/> Press the [F3](YES) key and enter the Point Number in coordinate data file.</p> <p><input type="checkbox"/> Enter the height.</p> <p><input type="checkbox"/> Collimate a prism on the F3](YES) key. Measuring starts. *1)</p> <p>11 press[F4] (CALC)key*2) Z:Z coordinate dZ:standard deviation</p>	<p>[F1] Input PT# [F4]</p> <p>[F3]</p> <p>Inputs R.HT [F4]</p> <p>Collimate P [F3]</p> <p>[F4]</p>	<div data-bbox="753 154 1217 321"> N: 4.356m E: 16.283m Z: 1.553m >OK? [YES] [NO] </div> <div data-bbox="753 386 1217 554"> REFLECTOR HEIGHT INPUT: R.HT: 0.000m --- --- [CLR] [ENT] </div> <div data-bbox="753 599 1217 767"> REFLECTOR HEIGHT INPUT: R.HT: 0.000 m >Sight ? [YES] [NO] </div> <div data-bbox="753 793 1217 961"> HR :120°30'40" HD* [n] < <m VD : m >Measurement..... </div> <div data-bbox="753 988 1217 1155"> HR : 120°30'40" HD : 12.345 m VD : 23.456m NEXT --- --- CALC </div> <div data-bbox="753 1220 1217 1388"> Z COORD.SETTING Z: 1.234 m dZ: 0.002 m --- --- BS SET </div>
---	--	---

12 press[F4](SET)key*3), Z Coordinate of occupied point is set, to show backsight point measurement screen	[F4]	<div> BACKSIGHT HR : 120°30'40" >OK? [YES] [NO] </div>
13 press[F3](YES)key, the horizontal angle is set, the display will back to program menu 1/2	[F3]	<div> PROGRAM 1/2 F1: REM F2: MLM F3: Z COORD. P↓ </div>
*1) Measurement is Fine N-times measurement mode. *2) To measure other points, press the [F1](NEXT) key. *3) Pressing the [F3] key, the display will be changed alternately.		

6.1.4 Area Calculation

This mode calculates the area of a closed figure.

There are two methods for area calculation:

1) Area Calculation from Coordinate data file

2) Area Calculation from Measured data

- Area is not calculated correctly if enclosed lines cross each other.
- It is impossible to calculate with a mix of coordinate file data and measured data.
- If the coordinate data file does not exist, the area calculation from measured data is done automatically.
- The numbers of points used to calculate the area are not limited.

1) Area Calculation from Coordinate Data File

Operating procedure	Operatin	Display
□press[MENU]key, then press [F4](P↓)key to show main menu 2/3	[MENU] [F4]	<div> MENU 2/3 F1: PROGRAM F2: GRID FACTOR F3: ILLUMINATION P↓ </div>

<p>□ Press[F1]key</p> <p>□ press[F4] (P↓)key, to enter program menu 2/2</p> <p>□ press[F1](AREA)key</p> <p>□ press[F1](FILE DATA)key</p> <p>□ Press the [F1](INPUT) key and enter the File Name. Initial display will be shown.</p> <p>□ Press the [F4](NEXT) key. *1),2) The top of the file data (DATA-01) will be set and the second point number will be shown.</p>	[F1]	<div>PROGRAMS 1/2</div> <div>F1:REM</div> <div>F2:MLM</div> <div>F3:Z COORD. P↓</div>
		<div>PROGRAM 2/2</div> <div>F1: AREA</div> <div>F2:POINT TO LINE</div> <div>P↓</div>
	[F1]	<div>AREA</div> <div>F1: FILE DATA</div> <div>F2: MEASUREMENT</div>
	[F1]	<div>SELECT A FILE</div> <div>FN:_____</div> <div>INPUT LIST --- ENTER</div>
	[F1] Input FN [F4]	<div>AREA 0000</div> <div>m.sq</div> <div>NEXT#: DATA-01</div> <div>PT# LIST UNIT NEXT</div>
		<div>AREA 0001</div> <div>m.sq</div> <div>NEXT#: DATA-02</div> <div>PT# LIST UNIT NEXT</div>

<input type="checkbox"/> Repeat pressing the [F4](NEXT) key to set required number of points. When 3 or more points are set, the area surrounded by the points is calculated and the result will be shown.	[F4]	<div> AREA 0021 123.456 m.sq NEXT# : DATA-22 PT# LIST UNIT NEXT </div>
*1) To set specify point, press the [F1](PT#) key. *2) To show the list of the coordinate data in the file, press the [F2](LIST) key.		

2) Area Calculation from Measured data

Operating procedure	Operatin	Display
<input type="checkbox"/> press[MENU]key, then press [F4](P↓)key to show main menu 2/3	[MENU] [F4]	<div> MENU 2/3 F1: PROGRAM F2: GRID FACTOR F3: ILLUMINATION P ↓ </div>
<input type="checkbox"/> press[F1]key	[F1]	<div> PROGRAMS 1/2 F1:REM F2:MLM F3:Z COORD. P↓ </div>
<input type="checkbox"/> Press[F4] (P↓)key, to enter program menu 2/2	[F4]	<div> PROGRAM 2/2 F1: AREA F2:POINT TO LINE P↓ </div>
<input type="checkbox"/> press[F1](AREA)key	[F1]	<div> AREA F1: FILE DATA F2: MEASUREMENT </div>
<input type="checkbox"/> Press[F2](MEASUREMENT)k ey	[F2]	<div> AREA F1: USE G.F F2: DON'T USE </div>

<p>⑥Press the [F1] or [F2] key to select using GRID FACTOR. [Example:F2 : DON'T USE]</p>	[F2]	<div> <div>AREA0000m.sq</div> <div>MEAS --- UNIT ---</div> </div>
<p>⑦Collimate a prism and press the [F1](MEAS) key. Measuring starts. *1)</p>	Collimate P [F1]	<div> <div>N* [n] <<<m</div> <div>E: m</div> <div>Z: m</div> <div>>Measurement...</div> </div>
		↓
<p>⑧Collimate next point and press the [F1](MEAS) key.</p> <p>When 3 or more points are measured, the area surrounded by the points is calculated and the result will be shown.</p>	Collimate [F1]	<div> <div>AREA0001m.sq</div> <div>MEAS --- UNIT ---</div> </div> <div> <div>AREA003234.567m.sq</div> <div>MEAS --- UNIT ---</div> </div>
<p>*1) Measurement is Fine N-times measurement mode.</p>		

·To change the display unit


It is possible to change the displayed area unit.

Operating procedure	Operation	Display
<input type="checkbox"/> Press[F3] (UNIT) key	[F3]	<div> AREA 0003 100.000 m.sq MEAS --- UNIT --- </div>
<input type="checkbox"/> Select a unit by pressing the [F1] to [F4] key. Example: [F2](ha) key.	[F2]	<div> AREA 0003 100.000 m.sq m.sq ha ft.sq acre </div> <div> AREA 0003 0.010ha MEAS --- UNIT --- </div>
• m.sg: square meter ha: hectare ft.sg: square feet acre:acre		

6.1.5 Point to Line Measurement

This mode is used to obtain the coordinate data with the origin point A(0,0,0) and the line AB as N axis.

Place the 2 prisms at the points A and B on the line, and place the instrument at unknown point C. After measuring the 2 prisms, the coordinate data and the direction angle of the instrument will be calculated and restored.



Operating procedure	Operation	Display
□press[MENU]key, then press [F4](P↓)key to show main menu 2/3	[MENU] [F4]	MENU 2/3 F1: PROGRAM F2: GRID FACTOR F3: ILLUMINATION P ↓
□press[F1]key	[F1]	PROGRAMS 1/2 F1:REM F2:MLM F3:Z COORD. P ↓
③press[F4] (P↓)key, to enter program menu 2/2	[F4]	PROGRAM 2/2 F1: AREA F2:POINT TO LINE P ↓
□press[F2]key	[F2]	INSTRUMENT HEIGHT INPUT INS.HT.= 0.000 m --- --- [CLR] [ENT]
□Enters instrument height	Input INS.HT [F4]	REFLECTOR HEIGHT INPUT R.HT = 0.000 m --- --- [CLR] [ENT]
□Enter reflector A(P1) height.	Input R.HT [F4]	POINT TO LINE MEAS . P1 HD: m >Sight ? [YES] [NO]
□Collimate prism P1(origin point), press[F3](yes)key to carry out measurement *1)	Colimate P1 [F3]	POINT TO LINE MEAS . P1 HD* [n] << m >Measurement.....

<p>Input display of reflector B(P2) height will be shown.</p> <p><input type="checkbox"/> Enter reflector B(P2) height.</p> <p><input type="checkbox"/> Collimate prism B (P2) (Origin) and press the [F3](YES) key. Measuring starts. *1)</p> <p>The coordinate data and the direction angle of the instrument are calculated and restored. The result (The distance between A and B) will be displayed. dHD: Horizontal distance dVD: Vertical distance dSD: Slope distance *2) ,3)</p> <p><input type="checkbox"/> press[F1](NEZ)key, to measure Other target points</p>	<p>ENTER R.HT [F4]</p> <p>Collimate P2 [F3]</p> <p>[F1]</p>	<div data-bbox="803 148 1225 319"> REFLECTOR HEIGHT. INPUT R.HT = 0.000 m --- --- [CLR] [ENT] </div> <div data-bbox="803 367 1225 548"> POINT TO LINE MEAS . P2 HD* m >Sight ? [YES] [NO] </div> <div data-bbox="803 590 1225 742"> POINT TO LINE MEAS . P2 HD* [n] << m >Measurement..... </div> <div data-bbox="803 891 1225 1062"> DIST (PI-P2) 1/2 dHD : 10.000 m dVD : 0.000 m NEZ S.CO --- P↓ </div> <div data-bbox="803 1214 1225 1471"> N: 0.000 m E: 0.000 m Z: 0.000 m EXIT --- HT MEAS ----- >Measurement..... </div>
---	---	--

11 Collimate a prism and press [F4](MEAS) key. Coordinate measurement starts. *4) The result will be shown. *5)	Collimate P [F4]	<div> N: 3.456m E: 5.432m Z: 0.000m Exit --- HT MEAS </div>
*1) Measurement is Fine N-times measurement mode. *2) To show dSD, press [F4](P↓) key. *3) To show the new occupied data, press [F2](S.CO) key. *4) Measurement is Fine N-times measurement mode. *5) To return to previous mode, press [F1](EXIT) key.		

6.2 Setting the GRID FACTOR

GRID FACTOR can be reset under this mode

For details, refer to 8.1.1 “Setting the GRID FACTOR”

Grid Factor can be applied to the following applications

Can also choose”do not use” in the "Selecting mode" to cancel the setting of grid factor, the selection and setting of grid factor will be omitted.

●Data collection mode

When the NEZ automatic calculation (NEZ AUTO. CALC) is ON, Grid factor will be applied to the coordinate data (Including PTL data) recorded into a coordinate data file when the RAW data is measured and recorded.(In this case, Grid Factor is not applied to the RAW data recorded into the measured data file.)

●PTL (Point To Line measurement)

When executing PTL measurement mode, the NEZ Auto Calculation will be turned on compulsorily and Grid factor will be applied to the coordinate data.

●LAYOUT

During Layout (Including PTL measurement mode)

1. When displaying the difference (dHD) between grid horizontal distance to a layout point (HDg) on the projection plane and measured ground horizontal distance to a prism point (HD) Grid factor will be applied to grid distance (HDg) in order to reverse-convert grid distance to ground distance.

2. After completion of a layout point, the displayed coordinate data will be applied to grid factor in order to compare with surveying data and calculated data on the projection plane.

(NEW POINT-Side Shot)

In side shot mode, a new point coordinate data will be applied to grid factor and the new point coordinate data will be recorded into a coordinate data file.

(NEW POINT - Resection)

In resection method, when a new point calculated coordinate data is displayed or recorded, the new point coordinate data will be applied to grid factor and the coordinate data will be recorded into a coordinate data file.

●MLM (Missing Line Measurement)

When selecting grid factor "USE G.F.", measured data will be applied to grid factor.At this time, the horizontal distance(dHD) and slope distance(dSD) will be shown on the projection plane.

●AREA (Area measurement / Measurement mode)

When select grid factor"USE G.F",the measured data will be applied in the grid factor,then,the computed area will be shown on the projection plane.

Note:Calculation of Z coordinate is not influenced whether if it is applied to grid factor.

Operating procedure	Operation	Display
<div> <input type="checkbox"/>Press[MENU]key, then press [F4](P↓)key to show main menu 2/3 </div>	<div>[MENU] [F4]</div>	<div> <div>MENU2/3</div> <div>F1: PROGRAM</div> <div>F2: GRID FACTOR</div> <div>F3: ILLUMINATIONP↓</div> </div>
<div> <input type="checkbox"/>press[F2](GRID FACTOR)key </div>	<div>[F2]</div>	<div> <div>GRID FACTOR</div> <div>= 0.998843</div> <div>>MODIFY? [YES] [NO]</div> </div>

<input type="checkbox"/> Press[F3](YES)key <input type="checkbox"/> Enter Elevation. *1) Press the [F4](ENT) key. <input type="checkbox"/> Enter Scale Factor in the same way. Grid factor shows 1-2 seconds, the display backs to menu	<div> [F3] Input ELEV [F4] </div> <div> Input Scale [F4] </div>	<div> GRID FACTOR ELEV. = 1000 m SCALE: 0.999000 <input type="checkbox"/> <input type="checkbox"/> [CLR] [ENT] </div> <div> GRID FACTOR ELEV. = 2000 m SCALE: 1. 001000 <input type="checkbox"/> <input type="checkbox"/> [CLR] [ENT] </div> <div> GRID FACTOR =1.000686 </div>
*1) Refer to Section 2.5 “How to Enter Alphanumeric characters” • Input Range :Elevation : –9,999 to +9,999 meter (–32,805 to +3,2805 ft, ft+in) Scale Factor: 0.990000 to 1.010000		

6.3 Setting Illumination of Display and Cross Hairs

Set on/off for display LCD illumination

Operating procedure	Operation	Display
<input type="checkbox"/> press[MENU]key, then press [F4](P↓)key to show main menu 2/3 <input type="checkbox"/> press[F3]key,to show original setting status <input type="checkbox"/> press[F1]on,the backlight Illumination light on	<div>[MENU] [F4]</div> <div>[F3]</div> <div>[F3]</div>	<div> MENU 2/3 F1: PROGRAM F2: GRID FACTOR F3: ILLUMINATION P ↓ </div> <div> ILLUMINATION [OFF] F1: On F2: Off </div> <div> ILLUMINATION [ON] </div>

<input type="checkbox"/> press[F2]key,off, backlight illumination light off	[F2]	<div>ILLUMINATION [OFF]</div> <div>F1: On</div> <div>F2: Off</div> <div>F3: Contrast</div>
·press[ESC)key to back to previous mode		

6.4 Setting Mode 1

In this mode, the following settings are possible.

1. Minimum reading
2. Auto Power off
3. Vertical Angle Tilt Correction (Tilt ON/OFF)
4. Setting for RS-232C communication
 - this selection will be saved after power is off

6.4.1 Setting Minimum Reading

Select minimum display unit for angle measurement, coarse distance measurement mode.

Instrument type	Angle unit			Coarse mode Distance unit
	Degree	Gon(400 system)	MIL	
TKS-202	5"/1"			

[Example] Minimum angle : 5", Coarse : 1mm

Operating procedure	Operation	Display
<input type="checkbox"/> press[MENU]key, then press [F4](P↓)key twice to show main menu 3/3	<div>[MENU]</div> <div>[F4]</div> <div>[F4]</div>	<div> <div>MENU 3/3</div> <div>F1: PARAMETER 1</div> <div>F2: CONTRAST ADJ</div> <div>P ↓</div> </div>
<input type="checkbox"/> press[F1]key	[F1]	<div> <div>Parameter 1 1/2</div> <div>F1: Minimum reading</div> <div>F2: Auto Power off</div> <div>F3: TILE P↓</div> </div>

<input type="checkbox"/> press[F1]key	[F1]	<div>Minimum reading F1: Angle F2: Coarse</div>
<input type="checkbox"/> press[F1]key	[F1]	<div>Minimum angle [F1: 1"] F2: 5" Enter</div>
⑤press[F2] (5")key, then press[F4](Enter)key	[F2] [F4]	<div>Minimum reading F1: Angle F2: Coarse</div>
<input type="checkbox"/> press[F2]key	[F2]	<div>Coarse reading F1: 1 mm [F2: 10mm] Enter</div>
<input type="checkbox"/> press[F1] (1mm)key, then press[F4](Enter)key	[F1] [F4]	<div>Minimum reading F1: Angle F2: Coarse</div>
• press[ESC]key to back to previous mode		

6.4.2 Auto Power Off

If no key operation is given or no process of measurement is performed for 30 minutes (No change exceeding 30"has occurred during vertical angle measurement),The power will automatically turn off, If the instrument is set at distance measurement mode, (No change in distance exceeding 10cm has occurred during distance measurement), the mode changes to angle measurement automatically in case that the instrument does not operate for

approximately 10 minutes, the power will automatically turn off in the following 20 minutes.

Operating procedure	Operation	Display
<div> <input type="checkbox"/>press[MENU]key, then press [F4](P↓)key twice to show main menu 3/3 </div>	<div> [MENU] [F4] [F4] </div>	<div> <div>MENU3/3 F1: PARAMETER 1 F2: CONTRAST ADJ P↓</div> </div>
<div> <input type="checkbox"/>press[F1]key </div>	<div> [F1] </div>	<div> <div>PARAMETER 11/3 F1: Minimum reading F2: Auto Power off F3:TILT P↓</div> </div>
<div> <input type="checkbox"/>press[F2] to show original setting status </div>	<div> [F2] </div>	<div> <div>AUTOPOWEROFF[OFF] F1: ON F2: OFF Enter</div> </div>
<div> <input type="checkbox"/>press[F1] (ON)key or[F2](OFF)key,then press[F4](Enter)key </div>	<div> [F1]or[F2] [F4] </div>	

6.4.3 Tilt correction (TILT ON/OFF)

In case the instrument is used in an unstable situation, constant indexing of vertical and horizontal angle may be impossible; in this case, the function of tilt correction can be stopped by selecting TILT OFF, it has been set to TILT ON ex-works.

- This setting is memorized after powering off.

Operating procedure	Operation	Display
<div> <input type="checkbox"/>press[MENU]key, then press [F4](P↓)key twice to show main menu 3/3 </div>	<div> [MENU] [F4] [F4] </div>	<div> <div>MENU3/3 F1: PARAMETER 1 F2: CONTRAST ADJ P ↓</div> </div>

<input type="checkbox"/> press[F1]key	[F1]	<div> <div> PARAMETER 1 1/2 F1: Minimum reading F2: Auto Power off F3: TILT P↓ </div> </div>
<input type="checkbox"/> press[F3] to show tilt correction value if original setting status is ON	[F3]	<div> <div> TILT SENSOR: (On) X: 0°02'10" </div> <div> ON --- OFF Enter </div> </div>
<input type="checkbox"/> press[F1](ON) or[F3](OFF)key,then press[F4](Enter)key	[F1] - [F3] [F4]	

6.4.4 Setting RS-232C communication with external device

You can set the parameters for RS-232C communication with external device from parameters setting menu.

The specific set parameters is as follows:

Item	Selecting items
BaudRate	1200, 2400, 4800, 9600, 19200, 38400
Character bit/Parity	7/Even, 7/Odd, 8/None
Stop bit	1, 2
ACK mode	Standard , Omitted
CR.LF	ON, OFF
REC type	REC-A, REC-B
Factory setting	Baud rate:1200 baud, Character bit/Parity:7/Even, CRLF:OFF, REC type: REC-A, ACK:Standard

ACK mode,CR,LF,REC type are correlative each other,refer to Chapter 16 “Selecting mode”

EXAMPLE:STOP BIT = 2

Operating procedure	Operation	Display
<div>□press[MENU]key, then press[F4](P↓)twice</div>	<div>[MENU] [F4] [F4]</div>	<div>MENU3/3 F1: PARAMETER 1 F2: CONTRAST ADJ P↓</div>
<div>□press[F1]key</div>	<div>[F1]</div>	<div>Parameter 11/3 F1: Minimum reading F2: Auto Power off F3: TILT P↓</div>
<div>□Press[F4]twice</div>	<div>[F4] [F4]</div>	<div>Parameter Group 11/3 FI:RS-232C P1</div>
<div>□press[F1] to show previous setting value and previous setting status</div>	<div>[F1]</div>	<div>RS-232C 1/3 F1:Baud Rate F2: Character/parity F3: Stop bits P1</div>
<div>□press[F3]to select stop bit, to show previous equipment value</div>	<div>[F3]</div>	
<div>□press[F2]to select stop bit 2, then press[F4](Enter)</div>	<div>[F2] [F4]</div>	<div>Stop bit F1: 1 [F2: 2] Enter</div>


6.5 Setting Contrast of Display

Setting LCD's contrast level

Operating procedure	Operation	Display
<div>□press[MENU]key, press [F4](P↓)key twice to enter P3 menu</div>	<div>[MENU] [F4] [F4]</div>	<div>MENU3/3 F1: PARAMETER 1 F2: CONTRAST ADJ P↓</div>
<div>□press[F2]key</div>	<div>[F2]</div>	<div>Contrast Adjustment LEVEL: 5 ↓↑---ENTER</div>
<div>③press[F1](↓)key or [F2](↓)key, then press[F4] (Enter)key</div>	<div>[F1]or[F2] [F4]</div>	

6.6 ROAD

- Road menu operation



6.6.1 Input Start Point

To input the start point, carry out the following operating procedure:

Operating procedure	Operation	Display
<div><div><input type="checkbox"/>press[MENU]key, then press[F4](P↓),[F1],[F4]key to enter program menu page 2/2</div><div><input type="checkbox"/>press[F3],[F1],[F1]key</div><div><input type="checkbox"/>input coordinate N,E <input type="checkbox"/>press[ENT]key</div><div><input type="checkbox"/>input chain, interval <input type="checkbox"/>press[ENT]key</div></div>	<div><div>[MENU] [F4] [F1] [F4]</div><div> [F3] [F1] [F1]</div><div> Input coordinate [ENT]</div><div> Input data [ENT]</div></div>	<div><div>PROGRAMS2/2 F1: AREA F2: POINT TO LINE F3:ROADP↓</div><div> START POINT N = 0.000 m E : 0.000 m --- --- [CLR] [ENT]</div><div> Start point Chain> 0.000m Interval:100.000m <input type="checkbox"/> <input type="checkbox"/> [CLR] [ENT]</div><div> 〈SET!〉</div><div> INPUT DATA F1: START POINT F2: H ALIGNMENT</div></div>
<div><div>● For [ROAD], in addition to the “Start Point”and “Road Data” input files, other files necessary for the calculations are created; consequently, if the free area of the memory reaches 10% or less, a“MEMORY POOR”warning message is displayed.(at this moment the instrument is still operable)</div><div>● CHAIN and INTERVAL input range -50,000m≤ CHAIN ≤ +500,000m 0m<INTERVAL ≤ +5,000m</div></div>		

6.6.2 Input Road Data

[ROAD] is made up of four types of components: LINE, CURVE, SPIRAL and POINT. To input the required components, carry out the following operating procedure.

Operating procedure	Operation	Display
<div><input type="checkbox"/>press[MENU]key, then press[F4] (P↓),[F1],[F4]key to enter program menu page 2/2</div> <div><input type="checkbox"/>press[F3],[F1], [F2],[F1] key (refer to P71 “input road data”)</div>	[MENU] [F4] [F1] [F4]	<div>PROGRAMS2/2 F1:AREA F2:POINT TO LINE F3:ROADP↓</div>
	[F3] [F1] [F2] [F1]	<div>F1:LINE F2:CURVE F3:SPIRAL F4:POINT</div>
<div><div>●The amount of input data varies depending on the type of data, up to a maximum of 30. (In the case of POINT input only, the maximum is 9 points including end point)</div><div>●An error may occur when entering a combination of POINT and other components if the amount of data entered exceeds the maximum amount allowed for internal calculations. If this happens, please reduce the amount of input data.</div></div>		

● Input LINE data

Operating procedure	Operation	Display
<div><input type="checkbox"/>press[F1], to enter straight line input page*1</div> <div><input type="checkbox"/>input LENGTH <input type="checkbox"/>press[ENT]key</div>	[F1]	<div>F1:LINE F2:CURVE F3:SPIRAL F4:POINT</div>
	Input LENGTH [ENT]	<div>LINE01 L =0.000m AZ:0°00'00" --- --- [CLR] [ENT]</div>

<input type="checkbox"/> input AZIMUTH <input type="checkbox"/> press[ENT]key		<div> <SET!> </div>
*1) The number at the top right of the screen shows the amount of data currently entered.		

●Input CURVE data

Operating procedure	Operation	Display
<input type="checkbox"/> To input CURVE data, press the [F2] key. *1)	[F2]	<div> F1:LINE F2:CURVE F3:SPIRAL F4:POINT </div>
<input type="checkbox"/> input RADIUS <input type="checkbox"/> press[ENT]key	Input RADIUS [ENT]	<div> CURVE02 R =0.000 m L :0.000 m --- --- [CLR] [ENT] </div>
<input type="checkbox"/> input L(arc length) <input type="checkbox"/> press[ENT]key	input[ENT]	<div> CURVE02 TURN >RIGHT LEFT RIGHT --- ENTER </div>
<input type="checkbox"/> Select TURN(direction of turn): RIGHT or LEFT. <input type="checkbox"/> Press the [ENT] key.	[F1]or[F2] [ENT]	<div> <SET !> </div>

*1: CURVE cannot be input as the firs data.

●Input SPIRAL data

Operating procedure	Operation	Display
<div><input type="checkbox"/>To input SPIRAL data, press the [F3] key. *1)</div> <div><input type="checkbox"/>input RADIUS</div> <div><input type="checkbox"/>press[ENT]key</div> <div><input type="checkbox"/>input LENGTH</div> <div><input type="checkbox"/>press[ENT]key</div> <div><input type="checkbox"/>Select TURN(direction of turn): RIGHT or LEFT.</div> <div><input type="checkbox"/>press[ENT]key</div> <div><input type="checkbox"/>Select DIR(direction): IN(entrance) or OUT(exit).</div> <div><input type="checkbox"/>press[ENT]key</div>	[F3]	F1:LINE F2:CURVE F3:SPIRAL F4:POINT
	Input RADIUS [ENT]	SPIRAL 03 R = 0.000 m L : 0.000 m --- --- [CLR] [ENT]
	Input LENGTH [ENT]	SPIRAL 03 R: 0.000 m L : 0.000 m --- --- [CLR] [ENT]
	[F1]or[F2]	SPIRAL 03 TURN >RIGHT DIR : IN LEFT RIGHT --- ENTER
	[ENT]	SPIRAL 03 TURN >RIGHT DIR > IN IN OUT --- ENTER
	[F1]or[F2]	
	[ENT]	
		〈SET !〉
*1) : SPIRAL cannot be input as the first data.		

• Input POINT data

Operating procedure	Operation	Display
<input type="checkbox"/> To input POINT data, press the [F4] key.	[F4]	<div>F1:LINE F2:CURVE F3:SPIRAL F4:POINT</div>
<input type="checkbox"/> input N coord <input type="checkbox"/> press[ENT]key	Input N coord [ENT]	<div>POINT 04 N = 0.000 m E : 0.000 m --- --- [CLR] [ENT]</div>
<input type="checkbox"/> input E coord <input type="checkbox"/> press[ENT]key	Input E coord [ENT]	<div>POINT 04 N : 0.000 m E = 0.000 m --- --- [CLR] [ENT]</div>
<input type="checkbox"/> input RADIUS *1) <input type="checkbox"/> press[ENT]key	Input RADIUS [ENT]	<div>R > 0.000 m A1. 0.000 A2: 0.000 INPUT --- SKIP ENTER</div>
<input type="checkbox"/> Input parameter A1 *1) <input type="checkbox"/> press[ENT]key	Input parameter A1 [ENT]	<div>R : 100.000 m A1> 0.000 A2: 0.000 INPUT --- SKIP ENTER</div>
<input type="checkbox"/> Input parameter A2.*1) 11 press[ENT]key	Input parameter A2 [ENT]	<div>R> 100.000m A1: 80.000 A2> 0.000 INPUT --- SKIP ENTER</div> <div><SET!></div>

*1) If the data input is not required, press the [SKIP] key.

• When inputting POINT data, if the next data isn't point data, ROAD is calculated as a straight line irrespective of the values for RADIUS, A1 and A2.

6.6.3 Search Data

To search for input data, carry out the following operating procedure.

Operating procedure	Operation	Display
<div>□press[MENU]key, then press [F4](P↓),[F1],[F4]key to enter program menu page 2/2</div>	[MENU] [F4] [F1] [F4]	<div>PROGRAMS2/2 F1:AREA F2:POINT TO LINE F3:ROADP↓</div>
<div>□press[F3],[F1],[F2],[F2]key</div>	[F3] [F1] [F2] [F2]	<div>DATA SEARCH F1: THE FIRST DATA F2: LAST DATA</div>
<div>□To search from the first data, select [F1] (FIRST DATA).</div>	[F1]	<div>LINE01/30 L :100,000 m AZ :45°00'00" EDIT↓</div>
<div>□To switch to different data, press the [↓] or [↑] key.</div>	[↑]or[↓]	<div>..... Spiral30/30 R:200.000 m L:200.000 m EDIT↓</div>

6.6.4 Edit Data

To edit input data, carry out the following operating procedure.

Operating procedure	Operation	Display
<div>□in the data search page, press[F1]key</div>	[F1]	<div>LINE01/30 L :100.000 m AZ :45°00'00" EDIT↓</div>
<div>□edit the data</div>	Edit data	<div>LINE01 L =100.000 m AZ :45°00'00" --- --- [CLR] [ENT]</div>

6.6.5 Set OCC and BS

To set the Occupied Point and Backsight Point, carry out the following operating procedure.

Operating procedure	Operation	Display
<div>□press[MENU]key, then press[F4](P↓),[F1],[F4]key to enter program menu page 2/2</div>	<div>[MENU] [F4] [F1] [F4]</div>	<div>PROGRAMS 2/2 F1:AREA F2:POINT TO LINE F3:ROAD P↓</div>
<div>□press[F3],[F1],[F1]key</div>	<div>[F3] [F2] [F1]</div>	<div>OCC & BS F1: OCC & BS F2: RESECTION</div>
<div>□press[F1]key*1</div>	<div>[F1]</div>	<div>OCC & BS F1: COORD. DATA F2: ROAD DATA</div>
<div>□To input OCC. PT, press the [F1](COORD. DATA)or [F2](ROAD DATA) key. COORD. DATA: Choose the data from Coord Data and set the Occupied Point. ROAD DATA: Create the data from Road Data and set the Occupied Point. (Example : ROAD DATA)</div>	<div>[F2]</div>	<div>OCC.PT CHAIN = --- --- [CLR] [ENT]</div>
<div>□input OCC.PT, press[ENT]key</div>	<div>input OCC.PT [ENT]</div>	<div>Chain: 1000.00 >CENTER LEFT RIGHT --- ENTER</div>

6.6.6 Road Layout

To setout the road, carry out the following operating procedure.

Operating procedure	Operation	Display
<input type="checkbox"/> press[MENU]key, then press[F4](P↓),[F1],[F4]key to enter program menu page 2/2	[MENU] [F4] [F1] [F4]	<div>PROGRAMS 2/2</div> <div>F1:AREA</div> <div>F2:POINT TO LINE</div> <div>F3:ROAD P↓</div>
<input type="checkbox"/> press[F3],[F2],[F2]key	[F3] [F2] [F2]	<div>SETOUT ROAD</div> <div>CHAIN =</div> <div>--- --- [CLR] [ENT]</div>
<input type="checkbox"/> input data	Input data	<div>SETOUT ROAD</div> <div>CHAIN = 1200</div> <div>--- --- [CLR] [ENT]</div>
<input type="checkbox"/> press[ENT]key	[ENT]	<div>Chain: 1200</div> <div>>CENTER</div> <div>LEFT RIGHT ---ENTER</div>
<input type="checkbox"/> Select offset. Example: RIGHT)Press the [F2] key. *1)	[F2]	<div>CHAIN: 1200</div> <div>:RIGHT</div> <div>= m</div> <div>--- --- [CLR] [ENT]</div>
<input type="checkbox"/> input the offset value	Input offset Value [ENT]	
<input type="checkbox"/> Press the [ENT] key. The setout point coordinates are displayed.	[ENT]	<div>CHAIN: 1200</div> <div>N: 0.000 m</div> <div>E: 0.000 m</div> <div>>OK? [YES] [NO]</div>

<p>□press[F3]key The distance to the setout point and the backsight are displayed. HR: Calculated horizontal angle of the layout point HD: Calculated horizontal distance from the instrument to the layout point</p> <p>□Press the [F1](ANG) key. CHAIN: Layout point HR: Measured (Actual) horizontal angle. dHR: Horizontal angle to be turned to the layout point = Actual horizontal angle - Calculated horizontal angle. Correct direction when dHR = 0° 00'00"</p> <p>⑩Press the [F1](DIST) key. HD: Measuring (Actual) horizontal distance dHD: Horizontal distance to be turned to the layout point = Actual horizontal distance – Calculated horizontal distance.</p> <p>11 Press the [F3](NEZ) key. The coordinate data is shown.</p> <p>12 Press the [F4](NEXT) key to set next layout point.</p>	<p>[F3]</p> <p>[F1]</p> <p>[F1]</p> <p>[F3]</p> <p>[F4]</p>	<div data-bbox="848 258 1217 436"> CALCULATED HR=60° 00' 00" HD=100.000m ANG DIST --- --- </div> <div data-bbox="848 662 1217 839"> CHAIN:1200 HR: 60°00'00" dHR: 0°00'00" DIST --- NEZ --- </div> <div data-bbox="848 1054 1217 1247"> HD *: 100.000 m dHR : 0.000 m Mode Ang Nez Next </div> <div data-bbox="848 1346 1217 1530"> N: 70.000 m E: 50.000 m MODE ANG --- NEXT </div>
*1) If not choose displacement, press[ENT]key.		

6.6.7 Select a File

To set the coordinates to be used for the Occupied Point and Backsight Point, carry out the following operating procedure.

Operating procedure	Operation	Display
<input type="checkbox"/> Press[MENU]key, then press [F4] (P↓),[F1],[F4]key to enter program menu page 2/2	[MENU] [F4] [F1] [F4]	<div>PROGRAMS 2/2</div> <div>F1:AREA</div> <div>F2:POINT TO LINE</div> <div>F3:ROAD P↓</div>
<input type="checkbox"/> Press[F3],[F2]key	[F3] [F2]	<div>SETOUT</div> <div>F1: OCC & BS</div> <div>F2: SETOUT ROAD</div> <div>F3: SELECT A FILE</div>
<input type="checkbox"/> Press[F3]key <input type="checkbox"/> Enter the name of the file being used (or select it from the list). <input type="checkbox"/> Press[ENT]key	[F3] Select a file [ENT]	<div>SELECT A FILE</div> <div>FN: _____</div> <div>INPUT LIST --- ENTER</div>

6.6.8 Initialize ROAD data

To initialize the data, carry out the following operating procedure.

Operating procedure	Operation	Display
①press[MENU]key, then press[F4](P↓),[F1],[F4]key to enter program menu page 2/2	[MENU] [F4] [F1] [F4]	<div>PROGRAMS 2/2</div> <div>F1:AREA</div> <div>F2:POINT TO LINE</div> <div>F3:ROAD P↓</div>
②press[F3],[F3]key	[F3] [F3]	<div>INITIALIZE DATA</div> <div>ERASE ROAD DATA</div> <div>>OK? [NO] [YES]</div>

③When the [F4] (YES) key is pressed, all ROAD DATA with the exception of the coordinate data file is erased.	[F4]	
--	------	--

7. DATA COLLECTION

Measured data can be saved in the memory in TKS-200 serial

The internal memory is shared by the measured data files and the coordinate data files. Maximum 30 files can be generated.

- **Measured data**

The collected data is memorized into a measurement data file

- **The number of measurement points**

(In case not using the internal memory in layout mode)

MAX 24000 POINTS

Because the internal memory covers both data collection mode and layout mode, the number of measurement points will be decreased when the layout mode is used.


For relevant memory details refer to 9 "Memory Manager Mode".

- | |
|---|
| <p>1)When turning off the power, ensure that you are in the main menu screen or main angle measurement mode.
this ensures completion of the memory access process and avoids possible damage to the stored data.</p> <p>2)It is recommended for safety to charge the battery (BT-L1W) beforehand and prepare fully charged spare batteries.</p> |
|---|

• Data collection menu operation

By pressing the [MENU] key, the instrument will be in MENU 1/3 mode.

Press the [F1](DATA COLLECT) key, the menu of data collect 1/2 will be shown.



7.1 Preparation

7.1.1 Selecting a File for Data Collection

A file used by data collection mode must be selected at first.
Select a file before beginning data collection mode because selection screen of a file is displayed.
Selection of a file can be done data collection menu under this mode Operating procedure operation display

Operating procedure	Operation	Display
<div>□From main menu1/3 press [F1] (DATA COLLECT)key</div>	[F1]	<div>MENU1/3 F1: DATA COLLECT F2: LAYOUT F3:MEMORY MGR. ↓P</div>
<div>□Press [F2](LIST) key to display the list of file. *1)</div>	[F2]	<div>SELECT A FILE FN:_____ INPUT LIST --- ENTER</div>
<div>□Scroll file list by pressing [▲] or [▼] key and select a file to use. *2), *3)</div>	[▲]or[▼]	<div>AMIDATA /M0123 →*HILDATA /M0345 TOPDATA /M0789 --- SRCH --- ENTER</div>
<div>□Press [F4](ENTER) key. The file will be set and data collect 1/2 menu will be shown.</div>	[F4]	<div>TOPDATA /M0789 →RAPDATA /M0564 SATDATA /M0456 --- SRCH --- ENTER</div> <div>DATA COLLECT1/2 F1: OCC.PT# INPUT F2: BACKSIGHT F3: FS/SS P↓</div>

- *1) If you want to make a new file or input file name directly, press [F1](INPUT) key and enter a file name.
- *2) When a file has been selected already, * mark is indicated on left of current file name.
- *3) Data in a file shown with arrow can be searched by pressing [F2](SRCH) key.
 - It is possible to select a file from DATA COLLECT 2/2 menu in the same way.

DATA COLLECT	2/2
F1: Select a file	
F2: pcode input	
F3: config	P↓

7.1.2 Selection of Coordinate File for Data Collection

When coordinate data in a coordinate data file are used for occupied point or backsight point, select a coordinate file from the data collect menu 2/2 beforehand.

Operating procedure	Operation	Display
<div><input type="checkbox"/> From data collection menu 2/2 press[F1](select a file)fil</div>	[F1]	<div>DATA COLLECT 2/2 F1: SELECT A FILE F2: PCODE INPUT F3: CONFIG P ↓</div>
<div><input type="checkbox"/> Press[F2]coordinate data key</div>	[F2]	<div>SELECT A FILE F1: MEAS. DATA F2: COORD. DATA</div>
<div><input type="checkbox"/> Select a coordinate file as per the method introduced by 7.1.1”Selection of data collection file”</div>		<div>SELECT A FILE FN: _____ INPUT LIST --- ENTER</div>

7.1.3 Occupied Point and Backsight Point

The occupied point and direction angle in the data collect mode are linked with the occupied point and direction angle in normal coordinate measurement.

It is possible to set or change the occupied point and direction angle from the data collect mode

Occupied point can be set by two setting methods as follow:

- 1) Setting from the coordinate data stored in the internal memory:
- 2) Direct key input.

The following three setting methods for backsight point can be selected.

- 1) Setting from the coordinate data stored in the internal memory.
- 2) Direct key input of backsight coordinate
- 3) Direct key input of set direction angle.

Note: how to make the coordinate data to be memorized into internal memory, refer to 9.4”Direct key input of coordinate data”and 9.7.2”Loading data”

• **Example for setting the occupied point:**

In case of setting occupied point from the coordinate data stored in the internal memory.

Operating procedure	Operation	Display
<div> <input type="checkbox"/>Press the [F1](OCC.PT# INPUT) key from the data collect menu 1/2. The previous data is shown. </div>	[F1]	<div> PT# →PT-01 ID : INS.HT: 0.000 m INPUT Srch Rec OCNEZC </div>
<div> <input type="checkbox"/>press[F4](OCNEZ) key </div>	[F4]	<div> OCC.PT PT# : PT-01 INPUT LIST NEZ ENTER </div>
<div> <input type="checkbox"/>press[F1](INPUT)key </div>	[F1]	<div> OCC.PT PT# : PT-01 [ALP] [SPC] [CLR] [ENT] </div>

<div> <input type="checkbox"/> InputPT#, press[F4] (ENT)key*1) </div> <div> <input type="checkbox"/> Enter ID, INS.HT in the same way. *2),3) </div> <div> <input type="checkbox"/> Press[F3] (REC) key </div> <div> <input type="checkbox"/> Press[F3](YES)key The display returns to the data collect menu 1/2. </div>	<div>Input PT# [F4]</div> <div>Input ID, INS.HT [F3]</div> <div>[F3]</div>	<div> PT# : →PT-11 ID : INS.HT: 0.000 m INPUT Srch Rec OCNEZ </div> <div> PT# : →PT-11 ID : INS.HT→ 1.335 m INPUT Srch Rec OCNEZ ----- >REC? [YES][NO] </div> <div> DATA COLLECT 1/2 F1: OCC.PT# INPUT F2: BACKSIGHT F3: FS / SS P↓ </div>
<p>*1) Refer to Section 2.5 “How to Enter Alphanumeric characters”.</p> <p>*2) ID can be input by inputting a register number linked with PCODE Library.To show the list of PCODE library, press the [F2](SRCH) key.</p> <p>*3)Press the [F3](REC) key when you do not input the INS.HT.</p> <ul style="list-style-type: none"> • The data recorded in data collect is Point Number, ID and INS.HT. • If point is not found in internal memory, "PT# DOES NOT EXIST" is displayed. 		

•Example for setting the direction angle

The following is to memorize the data of the backsight after setting the backsight point from point number.

Operating procedure	Operation	Display
<p>□ Press the [F2] (BACKSIGHT) key from the data collect menu 1/2. The previous data is shown.</p> <p>□ press[F4](BS) key *1)</p> <p>□ press[F1](INPUT)key</p> <p>□ input PT4#, press[F4] (ENT)key*2), input PCODE, reflector height*3)4)</p> <p>□ press[F3](MEAS)key</p> <p>⑥ Collimate back sight point. Select one of the measuring mode and press the soft key.</p> <p>EXAMPLE : [F2](Slope Distance) key. Measuring starts. Horizontal circle is set to calculated direction angle. Measuring result is memorized and the display returns to the data collect menu 1/2.</p>	[F2]	<div>BS# → PCODE : R.HT : 0.000 m INPUT 0SET MEAS BS</div>
	[F4]	<div>BACKSIGHT PT# = INPUT LIST NE/AZ NET</div>
	[F1]	<div>BACKSIGHT PT# = [ALP] [SPC] [CLR] [ENT]</div>
	Input PT# [F4]	<div>BS# →PT-22 PCODE : R.HT: 0.000 m INPUT 0SET MEAS BS</div>
	[F3]	<div>BS# →PT-22 PCODE : R.HT: 0.000 m *VH SD NEZ ---</div>
	Collimate BS [F2]	<div>V : 90°00'0" HR : 0°00'0" SD * [n] <<<m >Measurement...</div>
		<div>DATA COLLECT 1/2 F1: OCC.PT# INPUT F2: BACKSIGHT F3: FS / SS P↓</div>

- *1) Pressing each time the [F3] key, the input method changes as Coordinate value, Angle, Coordinate point number alternatively.
- *2) Refer to Section 2.5 "How to Enter Alphanumeric characters".
- *3) PCODE can be input by inputting a register number linked with PCODE Library, to show the list of PCODE library, press the [F2](SRCH) key
- *4) Data collect sequence can be set to [EDIT→Measurement]. Refer to Section 7.6 "Setting Parameter of Data Collect [CONFIG.]".
 - If point is not found in internal memory, "PT# DOES NOT EXIST" is displayed.

7.2 Operational Procedure of "DATA COLLECT"

Operating procedure	Operation	Display
<input type="checkbox"/> Press the [F3](FS/SS) key from the data collect menu 1/2. The previous data is shown. <input type="checkbox"/> Press the [F1](INPUT) key and enter PT#. Press the [F4](ENT) key. *1) <input type="checkbox"/> Enter PCODE, R.HT in the same way. *2),3) <input type="checkbox"/> press[F3](measurement)key		<div>DATA COLLECT 1/2</div> <div>F1: OCC.PT# INPUT</div> <div>F2: BACKSIGHT</div> <div>F3: FS / SS P↓</div>
	[F3]	<div>PT# : = PT-01</div> <div>PCODE :</div> <div>R.HT : 0.000 m</div> <div>INPUT SRCH MEAS ALL</div>
	[F1] Input point number	<div>PT# : = PT-01</div> <div>PCODE :</div> <div>R.HT.: 0.000 m</div> <div>[ALP] [SPC] [CLR] [ENT]</div>
	[F4] [F1] Input PCODE	<div>PT# : = PT-01</div> <div>PCODE :</div> <div>R.HT : 1.200 m</div> <div>INPUT SRCH MEAS ALL</div> <div>-----</div> <div>VH *SD NEZ OFFSET</div>
	[F4] [F1] Inputs R.HT	
	[F4] [F3]	

● Searching record data

While executing the DATA COLLECT mode, you can search the recorded data.

Operating procedure	Operation	Display
<p>1 While executing the DATA COLLECT mode, press [F2] (SRCH) key. *1) The using file name will appear on the top of the right side of the display.</p> <p>2 Select one of three search methods by pressing [F1] to [F3] key. *2)</p>	<p>[F2]</p> <p>[F1] to [F3]</p>	<div> PT# → PT-02 PCode: R.HT : 1.200 m INPUT SRCH MEAS ALL </div> <div> SEARCH [GOWIN] F1: FIRST DATA F2: LAST DATA F3: PT# DATA </div>
<p>*1) It is possible to see the PCODE list when the arrow is located beside PCODE or ID.</p> <p>*2)The operation is same as the "SEARCH" in the MEMORY MANAGER mode, the details refer to 9.2 "Searching data".</p>		

● Entering PCODE / ID using PCODE Library

While executing the DATA COLLECT mode, you can enter PCODE /ID from PCODE Library.

Operating procedure	Operation	Display
<p>Move the arrow to the PCODE or ID in the DATA COLLECT mode, press the [F1](INPUT) key.</p> <p>□Enter a register number linked with PCODE library and press the [F4] (ENT)key Example: registration number, 32=GOWIN</p>	<p>[F1]</p> <p>Input registration number [F4]</p>	<div> PT# → PT-02 PCode: R.HT : 1.200 m INPUT SRCH MEAS ALL </div> <div> Point Number: PT-02 Code = 32 R.HT : 1.200m [ALP] [SPC] [CLR] [ENT] </div> <div> PT# → PT-02 PCode: GOWIN R.HT : 1.200 m INPUT SRCH MEAS ALL </div>

● Entering PCODE / ID from the list of PCODE

You can input PCODE / ID with PCODE list


Operating procedure	Operation	Display
<p>□ Move the arrow to the PCODE or ID in the DATA COLLECT mode, press the [F2](SRCH) key.</p> <p>□ By pressing the following keys, the register number will increase or decrease. [▲]or[▼]:Increasing or Decreasing one by one [▶]or[◀]:By ten Increasing or Decreasing. *1)</p> <p>□ press[F4](Enter)key</p>	[F2]	Point Number: PT-02 Code: → R.HT.: 1.200m Enter Search Measure same with previous
		→001:PCODE01 002:PCONE02 Edit Clear Enter
		031:PCODE31 →032:GOWIN 033:HILTOP Edit - - - Clear Enter
	[F4]	Point Number: PT-02 Code: GOWIN R.HT.→ 1.200m Enter Search Measure same with previous
<p>*1) To edit the PCODE library, press the [F1](EDIT) key. To delete the PCODE registered shown by an cursor, press the [F3](CLR) key. PCODE can be edited in DATA COLLECT menu 2/2 or MEMORY MANAGER menu 2/3.</p>		

7.3 Data Collection Offset Measurement Mode

This mode is useful when it is difficult to set up the prism directly, for example at the center of a tree. Data Collect . Offset Measurement has four measuring methods.

- Angle offset measurement
- Distance offset measurement
- Plane offset measurement
- Column offset measurement

7.3.1 Angle Offset Measurement






Place the prism at the same horizontal distance from the instrument as that of point A0 to measure.

When measuring coordinates of ground point A1: Set the instrument height/prism height.

When measuring coordinates of point A0: Set the instrument height only. (Set the prism height to 0).

When sighting to A0, you can select one of two ways. One is to fix vertical angle to the prism position even up down the telescope position, and the other is to gear vertical angle to the up down of telescope movement. In case following the vertical angle to the movement of telescope, SD (Slope Distance) and VD (Vertical Distance) will be changed according to the movement of telescope. To set this option, refer to Chapter 16 “SELECTING MODE”.

Operating procedure	Operation	Display
<div>□ Press[F3](MEAS) key</div>	<div>[F3]</div>	<div>PT# : →PT-11 PCODE : GOWIN R.HT : 1.200 m INPUT SRCH MEAS ALL ----- VH *SD NEZ P1↓ ----- OFSET PTL P2↓</div>

<p><input type="checkbox"/> Press[F4](P1↓)key, [F1](OFFSET)key</p> <p><input type="checkbox"/> Press[F1]key</p> <p><input type="checkbox"/> Collimate the prism</p> <p>⑤ Press[F3](yes)key to carry out Continuous measurement</p> <p><input type="checkbox"/> Collimate point A0 using the horizontal motion clamp and horizontal tangent screw.</p> <p><input type="checkbox"/> Show the horizontal distance of A0</p> <p><input type="checkbox"/> Show the relative elevation of point A0 ·Each time press[] Key, can show horizontal distance, relative elevation and slope distance in turn</p>	<p>[F4] [F1]</p> <p>[F1]</p> <p>Collimate P</p> <p>[F3]</p> <p>Collimate A0</p> <p>[]</p> <p>[]</p>	<div data-bbox="806 171 1216 338"> <p>OFFSET 1/2 F1:ANG. OFFSET F2:DIST. OFFSET F3:PLANE OFFSET P ↓</p> </div> <div data-bbox="806 405 1216 573"> <p>OFFSETMEASUREMENT HR :120°30'40" HD : m >Sight ? [YES] [NO]</p> </div> <div data-bbox="806 609 1216 776"> <p>OFFSETMEASUREMENT HR :120°30'40" HD*[n] <m >Measurement...</p> </div> <div data-bbox="806 820 1216 988"> <p>↓</p> <p>OFFSETMEASUREMENT HR : 120°30'40" SD* 12.345 m >OK? [YES][NO]</p> </div> <div data-bbox="806 1031 1216 1199"> <p>OFFSETMEASUREMENT HR :120°30'40" SD: 12.345 m >OK? [YES][NO]</p> </div> <div data-bbox="806 1254 1216 1422"> <p>OFFSETMEASUREMENT HR :120°30'40" HD: 6.543 m >OK? [YES][NO]</p> </div> <div data-bbox="806 1509 1216 1677"> <p>OFFSETMEASUREMENT HR :120°30'40" VD: 0.843 m >OK? [YES][NO]</p> </div>
---	---	--


Operating procedure	Operation	Display
<input type="checkbox"/> press[F3](MEAS)key	[F3]	PT# → PT-11 PCODE : GOWIN R.HT : 1.200 m INPUT RCH MEAS ALL <hr/> VH *SD NEZ P1↓ <hr/> OFSET PTL P2↓
②press[F4](P1↓)key, [F1](OFSET)key	[F4] [F1]	OFFSET 1/2 F1: ANGLE OFFSET F2: DIST OFFSET F3: PLANE OFFSET P ↓
<input type="checkbox"/> press[F2]key	[F2]	DISTANCE OFFSET INPUT R or L HD oHD : 0.000 m --- --- [CLR] [ENT]
<input type="checkbox"/> Enter Right and Left direction offset value.*1)	Input HD [F4]	DISTANCE OFFSET INPUT FORWARD HD oHD : 0.000 m --- --- [CLR] [ENT]
<input type="checkbox"/> Enter Forward direction offset value. *1)	Input HD [F4]	PT# : PT-11 PCODE : GOWIN R.HT : 1.200 m --- *SD NEZ ---
⑥Collimate the prism ⑦press[F2]or[F3] Key Example:[F3][NEZ] key To carry out measurement	Collimate P [F3]	N * [n] <<<m E : m Z : m >Measurement..... <hr/> >Calculating.....

<p>Measurement data is recorded into next target point Measurement display</p>		<div style="border: 1px solid black; padding: 5px;"> <p>PT# → PT-12 PCODE : GOWIN R.HT : 1.200 m INPUT RCH MEAS ALL</p> </div>
--	--	---




*1) To skip entering, press the [F3](SKP) key.

7.3.3 Plane Offset Measurement

Measuring will be taken for the place where direct measuring can not be done, for example distance or coordinate measuring for a edge of a plane. three random prism points (P1, P2, P3) on a plane will be measured at first in the plane offset measurement to determine the measured plane. Collimate the measuring target point(P0).then the instrument calculates and displays coordinate and distance value of cross point between collimation axis and of the plane.




Operating procedure	Operation	Display
<div> <input type="checkbox"/> press[F3](MEAS)key </div>	[F3]	<div> PT# → PT-11 PCODE : GOWIN R.HT : 1.200 m INPUT SRCH MEAS ALL <hr/> VH *SD NEZ P1↓ <hr/> OFFSET PTL P2↓ </div>
<div> <input type="checkbox"/>press[F4](P1)key, [F1](OFSET)key </div>	<div> [F4] [F1] </div>	<div> OFFSET 1/2 F1: ANGLE OFFSET F2: DIST OFFSET F3: PLANE OFFSET P ↓ </div>
<div> <input type="checkbox"/>press[F3](PLANE OFFSET) key </div>	[F3]	<div> PLANE N001 # : SD : m >Measurement..... </div>
<div> <input type="checkbox"/>collimate prism P1, press[F1] (MEAS)key to start After it is finished, the display prompts for 2nd point measurement </div>	<div> Collimate P1 [F1] </div>	<div> PLANE N001 # : SD* [n] <<m >Measurement..... ↓ </div>
<div> <input type="checkbox"/>Measure 2nd point and 3rd point with same method,the display changes into plane offset measurement down </div>	<div> Collimate P2 [F1] </div>	<div> PLANE N002 # : SD: m MEAS --- --- --- ↓ </div>
	<div> Collimate P3 [F1] </div>	<div> PLANE N003 # : SD : m MEAS --- --- --- ↓ </div>

<p>The display changes to PT# input in the plane offset measurement. *1) Input point number if necessary.</p> <p><input type="checkbox"/> Press the [F4](MEAS) key. The instrument calculates and displays coordinate and distance value of cross point between collimation axis and of the plane. *2)</p> <p><input type="checkbox"/> Collimate the edge (P0) of the plane. *3), 4)</p> <p><input type="checkbox"/> If want to show slope distance (SD), press[]key · Each time pressing the [] key, horizontal distance, relative elevation and slope distance are shown in sequence. To show coordinate value of point P0, press the [] key.</p> <p><input type="checkbox"/> press[F3](YES)key. The measured data will be recorded and the next offset point number will be displayed.</p> <p><input type="checkbox"/> To escape the measuring, press the [ESC] key. The display returns to the next point number in data collect mode.</p>	<p>[F4]</p> <p>Collimate P0</p> <p>[F3]</p> <p>[ESC]</p>	<div data-bbox="807 180 1240 352"> PLANE PT# → PT-11 PCODE : GOWIN INPUT SRCH --- MEAS </div> <div data-bbox="807 396 1240 567"> HR : 80°30'40" HD : 54.321m VD : 10,000m >OK? [YES] [NO] </div> <div data-bbox="807 611 1240 782"> HR : 75°30'40" HD : 54.600 m VD : -0.487 m >OK? [YES] [NO] </div> <div data-bbox="807 849 1240 1020"> V : 90°30'40" HR : 75°30'40" SD: 54.602 m >OK? [YES] [NO] </div> <div data-bbox="807 1068 1240 1239"> PLANE PT# → PT-12 PCODE : GOWIN INPUT SRCH --- MEAS </div> <div data-bbox="807 1287 1240 1458"> PT# → PT-12 PCODE : GOWIN R.HT : 1.200 m INPUT SRCH MEAS ALL </div>
<p>*1)In case the calculation of plane was not successful by the measured three points, error information displays. Start measuring over again from the first point.</p> <p>*2)Data display is the mode beforehand of offset measurement mode.</p>		

- *3)Error will be displayed when collimated to the direction which does not cross with the determined plane.
- *4)The reflector height of the target point P0 is set to zero automatically.





7.3.4 Column Offset Measurement

If it is possible to measure circumscription point (P1) of column directly, the distance to the center of the column (P0), coordinate and direction angle can be calculated by measured circumscription points (P2) and (P3).
 The direction angle of the center of the column is 1/2 of total direction angle of circumscription points (P2) and (P3).



Operating procedure	Operation	Display
①Press[F3](MEAS)key	[F3]	<div> PT# → PT-11 PCODE : GOWIN R.HT : 1.200 m INPUT SRCH MEAS ALL <hr/> VH *SD NEZ P1↓ <hr/> OFFSET PTL P2↓ </div>

<p>②Press[F4](P1↓)key, [F1](OFFSET)key</p>	<p>[F4] [F1]</p>	<div data-bbox="784 177 1216 354"> <div>OFFSET1/2</div> <div>F1: ANG. OFFSET</div> <div>F2: DIST. OFFSET</div> <div>F3: PLANE OFFSET P↓</div> </div> <div data-bbox="784 437 1216 609"> <div>OFFSET2/2</div> <div>F1: COLUMN OFFSET</div> <div>P↓</div> </div> <div data-bbox="784 664 1216 837"> <div>COLUMN OFFSET</div> <div>Center</div> <div>HD : m</div> <div>MEAS --- --- ---</div> </div> <div data-bbox="784 891 1216 1066"> <div>COLUMN OFFSET</div> <div>Center</div> <div>HD* [n] <<m</div> <div>>Measurement.....</div> </div> <div data-bbox="784 1108 1216 1279"> <div>COLUMN OFFSET</div> <div>Left</div> <div>HR : 120°30'40"</div> <div>--- --- --- SET</div> </div> <div data-bbox="784 1353 1216 1538"> <div>COLUMN OFFSET</div> <div>Right</div> <div>HR : 180°30'40</div> <div>--- --- --- SET</div> </div>
<p>③Press[F4](P↓)key</p>	<p>[F4]</p>	
<p>④Press[F1] (COLUMNOFFSET) key</p>	<p>[F1]</p>	
<p>⑤Collimate the center of the column (P1) and press the [F1](MEAS) key. Measuring will start.</p>	<p>Collimate P1 [F1]</p>	
<p>After the measurement, angle measuring display of the left side (P2) will be shown.</p>		
<p>⑥Collimate the left side point (P2) of column and press[F4] (set)key. After the measurement, angle measuring display of the right side (P3) will be shown.</p>	<p>Collimate P2 [F4]</p>	

<p>⑦Collimate the right side of the column (P3) and press the [F4](SET) key. The distance between the instrument and center of the column (P0) will be calculated</p> <p>To show the relative elevation (VD), press the[] key. Each time pressing the [] key, horizontal distance, relative elevation and slope distance are shown in sequence. To show coordinate of point P0, press the [] key.</p> <p>⑧press[F3](yes)key, The display will be back to next measurement point number Under data Collection mode</p>	<p>Collimate P3 [F4]</p> <p></p> <p>[F3]</p>	<div data-bbox="786 199 1216 371"> <p>COLUMN OFFSET</p> <p>HR : 150°30'40"</p> <p>HD : 43.321 m</p> <p>>OK? [YES] [NO]</p> </div> <div data-bbox="786 561 1216 733"> <p>COLUMN OFFSET</p> <p>HR : 150°30'40"</p> <p>HD : 2.321 m</p> <p>>OK? [YES] [NO]</p> </div> <div data-bbox="786 866 1216 1037"> <p>PT# → PT-12</p> <p>PCODE : GOWIN</p> <p>R.HT : 1.200 m</p> <p>INPUT SRCH MEAS ALL</p> </div>
--	---	--

7.4 NEZ Auto Calculation

As measured data is collected, coordinates are calculated and stored for traverse or topo collection. Automatic making out function of coordinate data sets up in CONFIG of data collect. Refer to Section 7.7 “Setting Parameter of Data Collect [CONFIG.]”.

As a default, coordinate data calculated will be saved in a file of the same name as the measurement data file.

When the coordinate data file of the same name as the measurement data file does not exist, it will be generated automatically. It is possible to change a file for saving coordinate data in the DATA COLLECT Menu 2/2 (F1:SELECT A FILE). To calculate a coordinate data, it is necessary to add a point number in Data Collect execution.


When a coordinate data of the same point number exist already, it can be replaced with the new data by confirming display.

- **Coordinates will be calculated using the grid factor.**

To set the grid factor, see Section 6.2 ”Setting the GRID FACTOR”.

7.5 Point to Line Measurement

In this mode, a offsetting point from a certain determined line can be measured.



7.5.1 To change to the point to line measurement

Operating procedure	Operation	Display
<div> <input type="checkbox"/>Press[F3](MEAS) Press[F4] </div> <div> <input type="checkbox"/>press[F2](PTL) </div>	<div>[F3]</div> <div>[F4]</div>	<div> PT# → PT-01 PCODE : GOWIN R.HT : 1.500 m INPUT SRCH MEAS ALL </div>
		<div> PT# →PT-01 PCODE: GOWIN R.HT.: 1.500 m VH * SD NEZ P1↓ ----- OFSET PTL P2↓ </div>
	[F2]	<div> POINT TO LINE MODE [F1:ON] F2:OFF ENTER </div>

<input type="checkbox"/> Press the [F1](ON) key and press the [F4](ENTER) key. The input screen of a reference point 1 will appear.	[F4]	<div>REF. Point 1 PT# : _____</div> <div>INPUT LIST ENTER</div>
<input type="checkbox"/> Enter the point 1 data and press the [F4](Enter). The input screen of a reference point 2 will appear.	Input data [F4]	<div>REF. Point 2 PT# : _____</div> <div>INPUT LIST ENTER</div>
<input type="checkbox"/> Enter the point 2 data and press the [F4](Enter). The screen will return to data collect measurement. If the PTL measurement mode is available, 'PTL' will appear next to PT#.	Input data [F4]	<div>PT# PLT→ PT-01 PCODE : GOWIN R.HT : 1.500 m INPUT SRCH MEAS ALL</div>

7.5.2 Execute “Measurement from point to line”

Operating procedure	Operation	Display
Conduct data measurement according to the same procedure as with ordinary FS/SS (ALL can also be selected). However, when you conduct observation in the angle mode, PTL data will not be displayed (only the raw data will be recorded, upon which the operation will end).		<div>PT# PLT→ PT-01 PCODE : GOWIN R.HT : 1.500 m INPUT SRCH MEAS ALL</div>

<p>□press[F3](MEAS)</p>	<p>[F3]</p>	<div>PT# PLT→ PT-01 PCODE : GOWIN R.HT : 1.500 m VH *SD NEZ</div>
<p>□Press the [F2](SD) key. If the PTL mode is on, then, after the coordinate data is calculated, the PTL data will be displayed regardless of the coordinate check setting, etc.</p>	<p>[F2]</p>	<div>V : 90°30'20" HR : 120°30'40" SD * <m >Measurement.....</div>
<p>□ PTL measurement data will display. Confirm the data and press [F3](YES) key. The recorded data are measured data and coordinate data generated at the same time as a PTL data.</p>	<p>[F3]</p>	<div> <div>L: 44.789m O: 33.456m E: 2.321m >REC? [YES][NO]</div> <div>PT# PLT→ PT-02 PCODE : GOWIN R.HT : 1.500 m INPUT SRCH MEAS ALL</div> </div>
<p>• In the PTL measurement mode, NEZ Auto Calculation will be turned on compulsorily and the coordinate data will be stored into a coordinate file.</p>		

7.6 EDIT PCODE LIBRARY [PCODE INPUT]

PCODE data can be entered into PCODE Library in this mode.

A PCODE is linked with a number of 1 to 50.

PCODE can be edited with same method under Memory Manager menu 2/3

Operating procedure	Operation	Display
<div><div><input type="checkbox"/> Press the [F2](PCODE INPUT) key from Data Collect menu 2/2.</div><div><input type="checkbox"/> By pressing the following keys, the list will increase or decrease. [▲]or[▼]:Increase or Decreasing one by one [▶]or[◀]By ten Increasing or Decreasing.</div><div><input type="checkbox"/> press[F1](EDIT)key</div><div><input type="checkbox"/> Input PCODE, press[F4] (ENT)key*1)</div></div>	[F2]	<div>DATA COLLECT 2/2 F1: SELECT A FILE F2: PCODE INPUT F3: CONFIG P ↓</div>
		<div>→001:GOWIN 002:BEIJING EDIT --- CLR ---</div>
		<div>011:URAH →012:AMIDAT 013:HILLTO EDIT --- CLR ---</div>
	[F1]	<div>011:URAH →012:AMIDAT 013:HILLTO 1234 5678 90.-[ENT]</div>
	Input code [F4]	<div>011:URAH →012:AMIDAT 013:HILLTO [ALP] [SPC] [CLR] [ENT]</div>

*1) Refer to Section 2.5 “How to Enter Alphanumeric characters”

7.7 Setting Parameter of Data Collect [CONFIG.]

In this mode, the following settings of data collect mode are possible.

● Setting Items

Menu	Choose items	Contents
F1:DIST MODE	FINE / CRS(1) / CRS(10)	Select Fine /Coarse(1) /Coarse(10) mode in distance measurement mode. The unit to be displayed is as follows. Fine mode: 1mm (0.2mm) Coarse (1) mode: 1mm Coarse (10) mode: 10mm
F2:HD/SD	HD/SD	Select the distance measurement mode Horizontal distance or Slope distance.
F3:MEAS. SEQ.	N-TIMES / SINGLE / REPEAT	Select to set measurement mode for distance measurement.
F1:DATA CONFIRM	YES/NO	It is possible to confirm the result of measuring data before the data is recorded.
F2:COLLECT SEQ.	[EDIT→MEAS] / [MEAS→EDIT]	Select the procedure of data collection. [EDIT→MEAS] :Measurement is carried out after entering other data. [MEAS→EDIT] :Measurement is carried out before entering other data.
F3:NEZ AUTO. CALC	ON/OFF	It is possible to calculate coordinate value of data collected and store it into coordinate data file in every data collection.

●How to Set Items

Example Setting: DATA CONFIRM : YES

Operating procedure	Operation	Display
<input type="checkbox"/> Press the [F3] (CONFIG.) key from the data collect menu 2/2. The CONFIG menu 1/2 is shown. <input type="checkbox"/> Press the [F4](P↓) key to display the CONFIG menu 2/2. <input type="checkbox"/> press[F1](data confirm) key [] indicating the paraters currently set. <input type="checkbox"/> press[F1](YES)key. <input type="checkbox"/> press[F4](Enter)key.	[F3]	DATA COLLECT 2/2 F1: SELECT A FILE F2: PCODE INPUT F3: CONFIG P↓
		CONFIG 1/2 F1: DIST A FILE F2: HD/SD F3: MEAS. SEQ P↓
	[F4]	CONFIG 2/2 F1: DATA CONFIRM F2: COLLECT SEQ F3: NEZ AUTO. CALC P↓
	[F1]	DATA CONFIRM 1/2 F1:YES [F2:NO] ENTER
	[F1]	DATA CONFIRM 1/2 [F1:YES] F2:NO ENTER
	[F4]	

8. LAYOUT

LAYOUT mode has two functions which are setting of layout points and setting new points using coordinate data in the internal memory.

Also, if the coordinate data is not stored in the internal memory, this can be input from key board. The coordinate data is loaded from PC to the internal memory via RS-232C.

- The coordinate data

The coordinate data is memorized into a file.

For the internal memory, refer to Chapter 9 “MEMORY MANAGER MODE”.

TKS-200 can memorize the data into internal memory and dividing it into measurement data and coordinate data for layout.

- **The number of coordinate data**

(In case not using the internal memory in the data collect mode)

MAX. 24,000 POINTS


Because the internal memory covers both data collection mode and layout mode, the number of coordinate data will be decreased when the data collection mode is used.

- | |
|---|
| <ol style="list-style-type: none">1) When turning off the power, ensure that the instrument is in the main menu display or angle measurement mode, this ensures completion of the memory access process and avoids possible loss of the stored data.2) It is recommended for safety to charge the battery (BT-L1W) beforehand and prepare fully charged spare batteries.3) When recording new point data, remember to consider the amount of internal memory available |
|---|

• Layout menu operation

Press[MENU]key, the instrument enters menu NEMU1/3 mode.

Press[F2](LAYOUT)key, key show layout menu 1/2.



8.1 Preparation

8.1.1 Setting the GRID FACTOR

• Calculation Formula

1) Elevation Factor

$$\text{Elevation Factor} = \frac{R}{R + \text{ELEV.}}$$

R : The average radius of the earth
 ELEV. : The elevation above mean sea level

2) Scale Factor

Scale Factor: *Scale Factor at the surveying station*

3) Grid Factor

Grid Factor = Elevation Factor X Scale Factor

Distance Calculation

1) Grid Distance

$$\text{HDg} = \text{HD} \times \text{Grid Factor}$$

HDg : Grid Distance

HD : Ground distance

2) Ground Distance

$$\text{HD} = \frac{\text{HDg}}{\text{Grid Factor}}$$

•How To Set Grid Facto

Operating procedure	Operation	Display
<input type="checkbox"/> Press the [F3](GRID FACTOR) key from the Layout menu 2/2.	[F3]	<div> LAYOUT 2/2 F1:SELECT A FILE F2:NEW POINT F3:GRID FACTOR P↓ </div> <div> GRID FACTOR =0.998843 >MODIFY? [YES][NO] </div>

<p><input type="checkbox"/>press[F3](YES)key</p> <p><input type="checkbox"/>Enter Elevation. *1) Press the [F4](ENT) key.</p> <p><input type="checkbox"/>Enter Scale Factor in the same way. Grid Factor is displayed for 1 to 2 second and display returns to Layout menu 2/2.</p>	<p>[F3]</p> <p>Input ELEV [F4]</p> <p>input SCALE [F4]</p>	<div data-bbox="850 167 1214 337"> GRID FACTOR ELEV.= 1000 m SCALE=0.999000 --- --- [CLR] [ENT] </div> <div data-bbox="850 380 1214 550"> GRID FACTOR ELEV.= 2000 m SCALE=1.001000 --- --- [CLR] [ENT] </div> <div data-bbox="850 555 1214 750"> GRID FACTOR =1.000686 </div>
<p>*1) Refer to Section 2.5 “How to Enter Alphanumeric characters”.</p> <ul style="list-style-type: none"> Input range, elevation: -9,999 to +9, 999m(-32, 805+32, 805ft, ft +in) Scale factor: 0.990000 to 1.010000 		

8.1.2 Selecting Coordinate Data File

You can execute a Layout from selected coordinate data file, also you can record New point measured data into the selected coordinate data file.

- The only coordinate data file existing can be selected and you can not create a new file in this mode.For more information about file, refer to Chapter 9 “MEMORY MANAGER MODE”
- When LAYOUT MODE is begun, a file can be selected in the same way.

Operating procedure	Operation	Display
		<div data-bbox="834 1424 1223 1593"> LAYOUT 2/2 F1:SELECT A FILE F2:NEW POINT F3:GRID FACTOR P ↓ </div>

<p>□ Press the [F1](SELECT A FILE) key from the Layout menu 2/2.</p> <p>□ Press the [F2](LIST) key to display the list of coordinate data file.*1)</p> <p>□ Scroll file list by pressing the [▲]or[▼] key and select a file to use. *2),3)</p> <p>□ Press the [F4](ENTER) key. The file will be set .</p>	<p>[F1]</p> <p>[F2]</p> <p>[▲]or[▼]</p> <p>[F4]</p>	<div data-bbox="834 144 1220 316"> SELECT A FILE FN: _____ INPUT LIST --- ENTER </div> <div data-bbox="834 354 1220 525"> COORDDATA /C0123 →*TOKBDATA /C0345 TOPCDATA /C0789 --- SRCH --- ENTER </div> <div data-bbox="834 563 1220 734"> *TOKBDATA /C0345 →TOPCDATA /C0789 SATIDATA /C0456 --- SRCH --- ENTER </div> <div data-bbox="834 773 1220 944"> LAYOUT 2/2 F1:SELECT A FILE F2:NEW POINT F3:GRID FACTOR P ↓ </div>
<p>*1) If you want to input file name directly, press the [F1](INPUT) key and enter a file name.</p> <p>*2) When a file has been selected already, '*' mark is indicated on left of current file name. For the file discrimination mark (*, @, &), refer to Section 9.3 "FILE MAINTENANCE".</p> <p>*3) Data in a file shown with arrow can be searched by pressing the [F2](SRCH) key.</p>		

8.1.3 Setting Occupied Point

There are two methods to set the occupied points as follows

- 1) Setting from the coordinate data file stored in the internal memory
- 2) Direct key input of coordinate data
 - Example: setting :Setting the occupied point from the internal coordinate data file.


Operating procedure	Operation	Display
<input type="checkbox"/> Press the [F1] (OCC.PT INPUT) key from the Layout menu 1/2.	[F1]	<div>OCC.PT PT# : _____ INPUT LIST NEZ ENTER</div>
<input type="checkbox"/> Press the [F1] (INPUT) key , enter PT# and press the [F4](ENT) key. *1)	[F1] Input PT# [F4]	<div>INSTRUMENT HEIGHT INPUT INS.HT = 0.000 m --- --- [CLR] [ENT]</div>
<input type="checkbox"/> press[F2](invoke) key to show data file directory*1	Input INS.HT [F4]	<div>LAYOUT 1/2 F1: OCC.PT INPUT F2: BACKSIGHT F3: LAYOUT P↓</div>
*1) Refer to Section 2.5 “How to Enter Alphanumeric characters”		

●Example setting :Setting Instrument point coordinates directly

Operating procedure	Operation	Display
<input type="checkbox"/> Press the [F1](OCC.PT INPUT) key from the Layout menu 1/2.	[F1]	<div>OCC.PT PT# : _____ INPUT LIST NEZ ENTER</div>
<input type="checkbox"/> press[F3](NEZ) key	[F3]	<div>N→ 0.000m E: 0.000m Z: 0.000m INPUT --- PT# ENTER</div>
<input type="checkbox"/> press[F1](input)key,input coordinate value press[F4] (ENT)key *1)、*2)	[F1] Input coord [F4]	<div>COORD.DATA INPUT PT# : INPUT --- --- ENTER</div>

*1) Refer to Section 2.5 “How to Enter Alphanumeric characters”

- Whenever press[F3]key, the method to backsight point varies in turn.



Operating procedure	Operation	Display
<input type="checkbox"/> From layout menu1/2 press[F2](backsight)key to show original data	[F2]	<div>BACKSIGHT PT# : _____ INPUT LIST NE/AZ ENTER</div>
<input type="checkbox"/> press[F3](NE/AZ)key	[F3]	<div>N→ 0.000 m E : 0.000 m INPUT --- AZ ENTER</div>
<input type="checkbox"/> press[F1](input)key,input coordinate value press[F4] (ENT)key*1)、*2)	[F1] Input coord [F4]	<div>BACKSIGHT H(B) = 0° 00' 00" >SIGHT? [YES] [NO]</div>

<input type="checkbox"/> Sight the backsight point <input type="checkbox"/> Press[F3](yes)key Display backs to layout menu 1/2	Sight BK [F3]	<div> LAYOUT 1/2 F1: OCC.PT INPUT F2: BACKSIGHT F3: LAYOUT P ↓ </div>
*1) Refer to Section 2.5 “How to Enter Alphanumeric characters” *2)The coordinate value can be memorized into instrument, refer to 16 “Selecting mode”		

8.2 Executing a Layout

Two methods can be selected for executing a Layout:

- 1) Recalling points from internal memory by point number.
- 2) Direct key input of coordinate values

Example:Recalling point from internal memory.

Operating procedure	Operation	Display
<input type="checkbox"/> Press the [F3](LAYOUT) key from the layout menu 1/2. ②Press the [F1](INPUT) key, and enter PT#. *1) Press the [F4](ENT) key. *2)	[F3] [F1] Input PT# [F4]	<div> LAYOUT 1/2 F1: OCC.PT INPUT F2: BACKSIGHT F3: LAYOUT P ↓ </div> <div> LAYOUT PT#: _____ INPUT LIST NEZ ENTER </div> <div> REFLECTOR HEIGHT INPUT R.HT= 0.000 m --- --- [CLR] [ENT] </div>

- Enter reflector height in the same way.

When the layout point is set, the instrument will start layout calculation.

HR: Calculated horizontal angle of the layout point

HD: Calculated horizontal distance from the instrument to the layout point

- Collimate prism, press [F1] (angle) key.

PT#: Layout point

HR: Measured (Actual) horizontal angle.

dHR: Horizontal angle to be turned to the layout point = Actual horizontal angle – Calculated horizontal angle.

Correct direction when
dHR = 0°00'00"

- ⑤ Press the [F1](DIST) key.

HD: Measuring (Actual) horizontal distance

dHD: Horizontal distance to be turned to the layout point = Actual horizontal distance – Calculated horizontal distance.

dZ: Vertical distance to be turned to the layout point = Actual vertical distance – Calculated vertical distance.

Input R.HT
[F4]

Colimate P
[F1]

[F1]

CALCULATE

HR= 90°10'20"

HD= 123.456 m

ANGLE DIST --- ---

PT# : LP-100

HR= 6°20'40"

dHR= 23°40'20"

DIST --- NEZ ---

HD* [t] <m

dHD : m

dZ: m

MODE ANGLE NEZ NEXT



HD* 143.84 m

dHD : -13.34 m

Dz : -0.05 m

MODE ANGLE NEZ NEXT

<p>⑥press[F1](mode)key to carry out fine mode</p> <p>⑦When display value dHR, dHD and dZ are all 0, the measurement and setting of layout point has been completed *3)</p> <p>□ Press the [F3](NEZ) key. The coordinate data is shown.</p> <p>□ Press the [F4](NEXT) key to set next layout point . PT# is automatically incremented.</p>	[F1]	<div> HD* [r] <m dHD : m dZ : m MODE ANGLE NEZ NEXT </div> <div>↓</div> <div> HD* [r] 156.835 m dHD : -3.327 m dZ: -0.046 m MODE ANGLE NEZ NEXT </div>
	[F3]	<div> N * 100.000 m E : 100.000 m Z : 1.015 m MODE ANGLE --- NEXT </div>
	[F4]	<div> LAYOUT PT# : LP-101 INPUT LIST NEZ ENTER </div>

*1) Refer to Section 2.5 “How to Enter Alphanumeric characters”.

*2) Point number could not be entered when data to comply with the coordinate value does not exist in the file.


*3) Cut & Fill displaying function is available . Refer to Chapter 16 “SELECTING MODE”.

8.2.1 Layout of Coordinates of Point to Line

The coordinate data of point to line can be used during execution of layout. When a point name including PTL coordinates (including ‘From’ and ‘To’ data) is specified, the mode will change to PTL mode automatically.

There are two ways to enter the PTL coordinate data, Direct key input and Data transfer.

Refer to 9.4.2 “PTL (Point to Line) data input” and 9.7 “Data Communications”.



Operating procedure	Operation	Display
<div> <input type="checkbox"/> Press the [F1](INPUT) key, and enter PT#. Press the [F4](ENT) key. </div> <div> <input type="checkbox"/> Enter reflector height in the same way. when the layout point is set, the instrument will start layout calculation. The function key is designated as [F3](PTL)key. </div>	<div> [F1] Input PT# [F4] </div> <div> Input R.HT. [F4] </div>	<div> LAYOUT PT# : PT-21 INPUT LIST NEZENTER </div> <div> REFLECTOR HEIGHT INPUT R.HT : 1.500 m --- --- [CLR] [ENT] </div> <div> CALCULATE HR = 45°10'20" HD = 1.500 m ANGLE DIST PTL --- </div>


<p><input type="checkbox"/> Collimate the prism, and press the [F1](ANGLE) key.</p> <p><input type="checkbox"/> Press the [F1](DIST) key. HD: Measuring (Actual) horizontal distance dHD: Horizontal distance to be turned to the layout point = Actual horizontal distance – Calculated horizontal distance. dZ: Vertical distance to be turned to the layout point = Actual vertical distance – Calculated vertical distance.</p> <p><input type="checkbox"/> press[F2](PTL)key to show the coordinate difference between collimating point and layout point which is corresponding to selected reference line reference frame. NEZ:coordinate data PTL:Point To Line Coordinate Data</p>	<p>Collimate P [F1]</p> <p>[F1]</p> <p>[F2]</p>	<div data-bbox="833 133 1223 295"> PT# : LP-100 HR : 45°00'00" dHR : 0°00'00" DIST --- PTL --- </div> <div data-bbox="833 409 1223 571"> HD : 143.8 m dHR : -13.34 m dz: -0.05 m MODE PTL NEXT </div> <div data-bbox="833 932 1223 1094"> dL: 0.005 m dO: 0.327 m dE: 0.046 m MODE ANGLE NEXT </div>
--	---	---

8.3 Setting a New Point

New point is required for example when a layout point cannot be sighted from existing control points.

8.3.1 Side Shot Method

Set up the instrument at a known point, and measure the coordinate of the new points by the side shot method



Operating procedure	Operation	Display
<input type="checkbox"/> Press the [F4](↓) key from the layout menu 1/2 to get the layout menu 2/2.	[F4]	LAYOUT 1/2 F1: OCC.PT INPUT F2: BACKSIGHT F3: LAYOUT P↓
<input type="checkbox"/> PRESS[F2](NEW POINT)KEY	[F2]	LAYOUT 1/2 F1: SELECT A FILE F2: NEW POINT F3: GRID FACTOR P↓
<input type="checkbox"/> PRESS[F1](SIDE SHOT)KEY	[F1]	NEW POINT F1: SIDE SHOT F2: RESECTION
<input type="checkbox"/> Press the [F2](LIST) key to display the list of coordinate data file. *1)	[F2]	SELECT A FILE FN : _____ INPUT LIST --- ENTER
		COORDDATA /C0123 →*TOKBDATA /C0345 TOPCDATA /C0789 --- SECH --- ENTER

<p>□ Press[▲]or[▼]key, the file list can roll up and down to choose a file*2)*3)</p>	<p>[▲]or[▼]</p>	<div>*TOKBDATA/ C0345 →TOPCDATA /C0789 SATIDATA /C0456 --- SECH --- ENTER</div>
<p>□ Press the [F4](ENTER) key. The file will be set .</p>	<p>[F4]</p>	<div>SIDE SHOT PT# : _____ INPUT SRCH --- ENTER</div>
<p>□ Press[F1](INPUT)key to input new point name.*4) Press[F4](ENT)key</p>	<p>[F1] Input PT# [F4]</p>	<div>REFLECTOR HEIGHT INPUT R.HT : 1.235 m --- --- [CLR] [ENT]</div>
<p>□ Enter reflector height with the same method</p>	<p>Input R.HT [F4]</p>	<div>REFLECTOR HEIGHT INPUT R.HT : 1.235 m >Sight ? [YES] [NO]</div>
<p>□ Collimate the new point, and press the [F3](YES) key. Distance measuring starts.</p>	<p>Collimate [F3]</p>	<div>HR : 123°40'20" HD* [n] <m VD : m >Measurement... ----- <complete></div>
<p>□ Press the [F3](YES) key.*5) The name and coordinate value are stored into COORD.DATA. The input menu for next new point is displayed. PT# is automatically incremented.</p>	<p>[F3]</p>	<div>↓ N : 1234.567 m E : 123.456 m Z : 1.234 m >REC ? [YES] [NO]</div> <div>SIDE SHOT PT# : NP-101 INPUT SRCH --- ENTER</div>


- *1) If you want to input file name directly, press the [F1](INPUT) key and enter a file name.
- *2) For the file discrimination mark (*, @, &), refer to Chapter 9.3 "FILE MAINTENANCE" When a file has been selected already, a "*" mark is indicated on left of current file name.
- *3) Data in a file shown with arrow can be searched by pressing [F2](SRCH) key.
- *4) Refer to Section 2.5 "How to Enter Alphanumeric characters"
- *5) An error will be displayed when the internal memory is full.

8.3.2 Resection Method

Set up the instrument at a new point, and calculate the coordinate of the new point using the coordinate data of maximum seven known points and the measurements made to these points. By following observation, resection is possible.

- Resection by distance measurement: 2 or more points must be measured
- Resection by angle measurement only: 3 or more points must be measured

In case that 3 known points are measured by angle measurement only, the value would not be calculated by the method of least squares.



Operating procedure	Operation	Display
1 From layout menu 1/2 press[F4] (P↓), enter layout menu 2/2	[F4]	LAYOUT 1/2 F1: OCC.PT INPUT F2: BACKSIGHT F3: LAYOUT P↓
2 Press[F2](NEW POINT)key	[F2]	LAYOUT 1/2 F1: SELECT A FILE F2: NEW POINT F3: GRID FACTOR P↓
3 Press[F2](RESECTION)key	[F2]	NEW POINT F1: SIDE SHOT F2: RESECTION
4 Press the [F1](INPUT) key, and enter the new point name. *1) ,2) Press the [F4](ENT) key.	[F1] Input PT# [F4]	NEW POINT PT#: _____ INPUTSRCH SKP ENTER
5 Enter instrument height in the same way.	Input INS.HT [F4]	INSTRUMENTHEIGHT INPUT INS.HT = 0.000 m --- --- [CLR] [ENT]
6 Enter the known point A number. *3)	[F1] Input PT#	N001# PT# : _____ Input List NEZ Enter
7 input reflector height	Input R.HT [F4]	REFLECTOR HEIGHT INPUT R.HT = 0.000 m --- --- [CLR] [ENT]
		REFLECTOR HEIGHT INPUT R.HT = 0.000 m >Sight ? ANG DIST

Known point B entering display will be shown.

When two points have been measured by the [F4](DIST) key, the RESIDUAL ERROR will be calculated. *4)

Example: [F1]

11 Press the [F1](NEXT) key to measure other points.
Maximum seven points can be measured.

12 Same as procedure **6** to **8**
proceed to the known point C.

Collimate A
[F4]

```

HR :      123°40'20"
HD*                <m
VD :                m
>Measurement...
-----
<complete>

```

↓

N002#
PT#:

Input List NEZ Enter

Select Grid Factor
F1: USE LAST DATA
F2: CALC MEASDATA

[F1]

```
RESIDUAL ERROR
dHD=    0.015 m
dZ =    0.005 m
NEXT --- G.F. CALC
```

[F1]

N003#
PT# :

Input List NEZ Enter

```

HR : 123°40'20"
HD*          <m
VD :         m
>Measurement...
-----
<complete>

```

→

coordinate of the new point calculated from known point B)

*5) [F1:USE LAST DATA]; RESIDUAL ERROR is calculated with GRID FACTOR already set.

[F2:CALC MEAS.DATA]; RESIDUAL ERROR is calculated without GRID FACTOR already set. In this case, new GRID FACTOR is calculated from measured data and reset."

•To see the GRID FACTOR value, press the [F3](G.F.) key.

*6) In case that the all points are measured by angle measurement only, the following display will be shown.

You can select Z coordinate calculation.

CALC. Z COORD F1:YES F2:NO

F1(YES) : :N,E,Z coordinates will be calculated with measured angle data.

F2(NO) : :N and E coordinates will be calculated with measured horizontal angle data. Z coordinate would not be calculated. (Z coordinate value =0.000m)

When the distance measurement is done even one point, Z coordinate will be calculated as a mean value of relative distance (vertical distance data).

*7)The display shows ">SET ?" when [F3](SKP) key pressed in step 4. In this case, the new point data is not stored into the coordinate data file, only the value of occupied coordinate data changes to that of the calculated NEW POINT.

● **Viewing PT# LIST**

You can see the PT# List and enter the data from the List, also you can see coordinate data of a point. [Example: Executing Layout Mode]

Operating procedure	Operation	Display
<div>□ While executing the LAYOUT mode, press the [F2](LIST) key. The arrow (→) indicates selected data.</div> <div>□ By pressing the following keys, the list will increase or decrease [▲]or[▼]: Increasing or Decreasing one by one. [◀]or[▶]: By ten Increasing or Decreasing.</div> <div>□ To show the coordinate of the selected data, press the [F1] (VIEW) key. It is still possible to scroll the PT# data by pressing [▲]or[▼] key.</div> <div>□ Press the [ESC] key. The display returns to the List.</div> <div>□ Press the [F4] (ENTER) key. The selected point number is set as PT#.</div>		<div>LAYOUT PT# : _____ Input List Nez enter</div>
	[F2]	<div>[GOWIN] →DATA-01 DATA-02 VIEW SRCH --- ENTER</div>
	[▲]or[▼]	<div>DATA-49 →DATA-50 DATA-51 VIEW SRCH --- ENTER</div>
	[F1]	<div>PT# ┘ DATA-50 N┘ 100.234 m E┘ 12.345 m Z┘ 1.678 m</div>
	[ESC]	<div>DATA-49 →DATA-50 DATA-51 VIEW SRCH --- ENTER</div>
	[F4]	<div>REFLECTOR HEIGHT INPUT R.HT = 0.000 m --- --- [CLR] [ENT]</div>
<div>● The operation of [F2](SRCH) is same as the "SEARCH" in the MEMORY MANAGER MODE. For details please refer to 9"Memory Manager Mode".</div>		

9. MEMORY MANAGER MODE


The following items for internal memory are available in this mode.

- 1) **FILE STATUS:** Checking the number of stored data / Remaining internal memory capacity.
- 2) **SEARCH:** See the recorded data.
- 3) **FILE MAINTAN. :** Deleting files / Editing file name
- 4) **COORD. INPUT :** Inputting and storing coordinate data into Coord. data file.
- 5) **DELETE COORD. :** Deleting coordinate data from Coord. data file
- 6) **PCODE INPUT :** Inputting PCODE DATA into PCODE Library
- 7) **DATA TRANSFER:** Sending measured data or coordinate data or PCODE Library data /Uploading coordinate data or PCODE Library data / Setting communication parameters
- 8) **INITIALIZE:** Initializing internal memory.

- Memory Manager Menu operation

By pressing the [MENU] key, the instrument will be in MENU 1/3 mode.

Press the [F3](MEMORY MGR.) key, the menu of MEMORY MGR. 1/3 will be shown.



9.1 Display Internal Memory Status

This mode is used to check internal memory status

Operating procedure	Operation	Display
① Press the [F3](MEMORY MGR.) key from the menu 1/3.	[F3]	<div> <div>MEMORY MGR1/3</div> <div>F1:FILE STATUS</div> <div>F2:SEARCH</div> <div>F3:FILE MAINTEN P↓</div> </div>
② Press the [F1](FILE STATUS) key. The total number of stored measured data files and coordinate files are shown.	[F1]	<div> <div>FILE STATUS1/2</div> <div>MEAS FILE : 3</div> <div>COORD. FILE : 6</div> <div>[.] P↓</div> </div> <div>↑</div> <div>Remaining memory capacity</div>
③ Press the [F4](P↓) key. The total number of stored measured data and coordinate data in all files are shown.*1)	[F4]	<div> <div>DATA STATUS2/2</div> <div>MEAS. DATA : 0100</div> <div>COORD. DATA: 0050</div> <div>[.] P↓</div> </div>
*1) Each coordinate file has one extra data for working area <ul style="list-style-type: none"> • The FILE/DATA STATUS display will change alternately by pressing [F4](P↓) key. • To return to MEMORY MGR. Menu, press [ESC] key. 		

9.2 Searching Data

This mode is used to search the recorded file data in the DATA COLLECT or LAYOUT mode.

The following 3 search methods in each type of files can be selected:

- 1: First data search
- 2: Last data search
- 3: Point number search(MEAS.DATA, COORD.DATA)
Number search (PCODE LIB.)

MEAS. DATA : Measured data in the data collect mode.

COORD. DATA : Coordinate data for layout, control points and new point data measured in the layout mode.

PCODE LIB. : The data which was registered with a number from 1 to 50 in Point code library.

Point name (PT#, BS#) , ID, PCODE and Height data (INS.HT, R.HT) can be corrected in the searching mode, measured value can not be corrected.

9.2.1 Measured Data Searching

Example:search as per point number

Operating procedure	Operation	Display
①Press the [F3](MEMORY MGR.) key from the menu 1/3.	[F3]	<div>MEMORY MGR 1/3</div> <div>F1:FILE STATUS</div> <div>F2:SEARCH</div> <div>F3:FILE MAINTEN P↓</div>
□Press the [F2](SEARCH) key.	[F2]	<div>SEARCH</div> <div>F1: MEAS. DATA</div> <div>F2: COORD. DATA</div> <div>F3: PCODE LIB. P ↓</div>
□PRESS THE [F1](MEAS. DATA) KEY.	[F1]	<div>SELECT A FILE</div> <div>FN:_____</div> <div>INPUT LIST --- ENTER</div>
④Press the [F1](INPUT) key and enter File Name. Press the [F4](ENT) key. *1),2)	[F1] Input FN [F4]	<div>MEAS. DATA SEARCH</div> <div>F1: first data</div> <div>F2: Last data</div> <div>F3: PT# DATA</div>
□Press the [F3](PT# DATA) key.	[F3]	<div>PT# DATA SEARCH</div> <div>PT# : _____</div> <div>INPUT --- --- ENTER</div>

<p>□ Press the [F1](INPUT) key and enter PT#. Press the [F4](ENT) key. *1)</p> <p>□ Press the [F4](↓) key to scroll data for selected point.</p>	<p>[[F1] Input PT# [F4]</p> <p>[F4]</p>	<div data-bbox="811 167 1224 335"> PT# TOP-104 2/2 V] 98°36'20" HR] 160°40'20" TILT] 0°00'00" ↓ </div> <div data-bbox="811 415 1224 582"> PT# TOP-104 1/2 PCODE] R.HT.] 1.200 m EDIT ↓ </div>
<p>*1) Refer to Section 2.5 “How to Enter Alphanumeric characters”</p> <p>*2) Press[F2](invoke)key to show file directory·</p> <ul style="list-style-type: none"> • “] ” indicates that the shown data is the one that memorized already • press[▲]or[▼]key to show the next or last point • To search the measurement data with same point number, press[◀]or[▶] 		

● **To edit the data in searching mode**

Point name (PT#, BS#) , ID, PCODE and Height data (INS.HT, R.HT) can be corrected in the searching mode,but the measurement value can not be modified.

Operating procedure	Operation	Display
<p>□ Press the [F1](EDIT) key from last page of displayed data.</p> <p>□ Select the item to correct by pressing [▲]or[▼] key.</p>	<p>[F1]</p> <p>▲ or ▼</p>	<div data-bbox="794 1062 1233 1252"> PT#] TOP-104 2/2 PCODE] R.HT] 1.000 m EDIT ↓ </div> <div data-bbox="794 1306 1233 1473"> PT# →TOP-104 PCODE : R.HT → 1.000 m INPUT --- --- ENTER </div> <div data-bbox="794 1527 1233 1694"> PT# : TOP-104 PCODE : R.HT → 1.000 m INPUT --- --- ENTER </div>

<p>□ Press the [F1](INPUT) key and enter data. *1) Press the [F4](ENT) key.</p> <p>□ Press[F4](ENTER)key</p> <p>□ Press[F3](YES)key</p>	<p>[F1] Input data [F4] [F4]</p> <p>[F3]</p>	<div data-bbox="794 167 1233 337"> PT# →TOP-104 PCODE : R.HT → 1.200 m >SAVE ? [YES] [NO] </div> <div data-bbox="794 396 1233 565"> PT#] TOP-104 2/2 PCODE] R.HT] 1.200 m EDIT ↓ </div>
<p>*1)Refer to Section 2.5 “How to Enter Alphanumeric characters”.</p> <ul style="list-style-type: none"> • During editing, ID and PCODE are not related with the PCODE Library. • Though the height data(INS.HT., R.HT.)can be corrected, the measurement value can not be changed. 		

9.2.2 Coordinate Data Searching

Example searching :Point number searching

Operating procedure	Operation	Display
<p>□ Press the [F3](MEMORY MGR.) key from the menu 1/3.</p>	[F3]	<div data-bbox="794 944 1233 1113"> MEMORY MGR 1/3 F1:FILE STATUS F2:SEARCH F3:FILE MAINTAN P↓ </div>
<p>□ Press[F2](SEARCH)key</p>	[F2]	<div data-bbox="794 1146 1233 1315"> SEARCH F1: MEAS. DATA F2: COORD. DATA F3: PCODE LIB. P↓ </div>
<p>□ Press the [F2](COORD. DATA) key.</p>	[F2]	<div data-bbox="794 1342 1233 1511"> SELECT A FILE FN: _____ INPUT LIST --- ENTER </div>
<p>④ Press the [F1](INPUT) key and enter File Name. Press the [F4](ENT) key. *1)</p>	<p>[F1] Input FN [F4]</p>	<div data-bbox="794 1544 1233 1713"> PCOORD. DATA SEARCH F1: FIRST DATA F2: LAST DATA F3: PT# DATA </div>

<input type="checkbox"/> Press the [F3](PT# DATA) key.	[F3]	<div>PT# DATA SEARCH</div> <div>PT#: _____</div> <div>INPUT --- --- ENTER</div>
<input type="checkbox"/> Press the [F1](INPUT) key and enter PT#. Press the [F4](ENT) key. *1)	[F2] Input Point number [F4]	<div>Point number] TOP-104</div> <div>N] 100.234m</div> <div>E] 12.345m</div> <div>Z] 1.678m ↓</div>
⑦ Press the [F4](↓) key to get the next page.	[F4]	<div>PCODE] <input type="checkbox"/> TOPS 2/2</div> <div>STR.]</div> <div>↓</div>
*1) Refer to Section 2.5 “How to Enter Alphanumeric characters” • “] ”indicates that the shown data is the memorized data • press[▲]or[▼]key to show the next or last point • To search the measurement data with same point number, press[◀]or[▶]key.		

9.2.3 Searching of PCODE library

Example: search as per PCODE number

Operating procedure	Operation	Display
<input type="checkbox"/> From menu 1/3 press[F3] (MEMORY MGR)key	[F3]	<div>MEMORY MGR 1/3</div> <div>F1:FILE STATUS</div> <div>F2:SEARCH</div> <div>F3:FILE MAINTAN P↓</div>
<input type="checkbox"/> Press[F2](SEARCH)key	[F2]	<div>SEARCH</div> <div>F1: MEAS. DATA</div> <div>F2: COORD. DATA</div> <div>F3: PCODE LIB. P↓</div>


<div> <div>□Press[F3](PCODE LIB.)key</div> <div>□Press the [F3](No. SEARCH) key.</div> <div>□Enter number.Press the [F4](ENT) key. *1) The number and linked data will be shown. *2)</div> </div>	[F3]	<div>PCOORD. DATA SEARCH</div> <div>F1: FIRST DATA</div> <div>F2: LAST DATA</div> <div>F3: No. SEACH</div>
	[F3]	<div>PCODE No.SEARCH</div> <div>No. =</div> <div>---</div> <div>--- [CLR] [ENT]</div>
	Input PT# [F4]	<div>011:NAKADAI</div> <div>→012:HILLTOP</div> <div>013:ITABASH</div> <div>EDIT --- CLR ---</div>

*1) Refer to Section 2.5 “How to Enter Alphanumeric characters”
 • press[▲]or[▼]key to show the next or last PCODE data.
 *2) To correct the PCODE data, press [F1](EDIT) key.
 To delete PCODE data, press[F3](Clear)key.

9.3 File Maintenance

In this mode, the following items are available.
Renaming file name / Searching data in a file / Deleting files

- File Maintan. menu



Pressing [F3](FILE MAINTAN.) key from MEMORY MANAGER menu 1/3, file list will be shown.

- File discrimination mark(*、@、&)
File discrimination mark before the file name indicates the status of this file.
For measurement data file,
“*”: the file chosen under data collection mode
For coordinate data file,
“*”: the file chosen under layout mode
“@”: the coordinate file chosen under data collection mode
“&”: the coordinate file chosen used for layout and data collection mode
- Data type discrimination mark(M,C)
Data type discrimination mark before 4-digit number indicates the type of this data
“M” Measurement data
“C” coordinate data
- Four-digit number indicates the total of data in the file
(Each coordinate file has one extra data for working area)
Press[▲]or[▼]key to show the next or last point

9.3.1 Rename a File

An existing file in internal memory can be renamed.

Operating procedure	Operation	Display
<input type="checkbox"/> Press the [F3](FILE MAINTAN.) key from the Memory manager menu 1/3.	[F3]	<div>→MEASD1 /M0123 COORD1 /C0056 REN SRCH DEL ---</div>
<input type="checkbox"/> Select a file by pressing [▲]or[▼] key.	[▲]or[▼]	<div>MEASD1 /M0123 →COORD1 /C0056 COORD2 /C0098 REN SRCH DEL ---</div>
<input type="checkbox"/> Press the [F1](REN) key.	[F1]	<div>MEASD1 /M0123 →COORD1 /C0056 COORD1 /C0098 [ALP] [SPC] [CLR] [ENT]</div>

<input type="checkbox"/> Enter new file name. Press the [F4](ENT) key. *1)	Input FN [F4]	<div> →MEASD1 /M0123 →COORD1 /C0056 COORD1 /C0098 REN SRCH DEL --- </div>
*1) Refer to Section 2.5 “How to Enter Alphanumeric characters” • Existing file name can not be used. • press[ESC]key to back to file maintenance menu.		

9.3.2 Search the Data in the File

An existing file in internal memory can be searched.

Operating procedure	Operation	Display
<input type="checkbox"/> Press the [F3](FILE MAINTAN.) key from the Memory manager menu 1/3.	[F3]	<div> →MEASD1 /M0123 COORD1 /C0056 REN SRCH DEL --- </div>
<input type="checkbox"/> Select a file to search by pressing [▲]or[▼] key.	[▲]or[▼]	<div> MEASD1 /M0123 →COORD1 /C0056 COORD2 /C0098 REN SRCH DEL --- </div>
<input type="checkbox"/> Press the [F2](SRCH) key.	[F2]	<div> SEARCH [COORD1] F1: FIRST DATA F2: LAST DATA F3: PT# DATA </div>
<input type="checkbox"/> Select searching method by pressing the [F1] to [F3] key. *1)	[F1]to[F3]	
*1) Because procedures from next are same as procedures of Section 9.2 "Searching Data", refer to Section 9.2 “Searching Data” To return to the FILE MAINTAN. Menu , press the [ESC] key.		

9.3.3 Deleting a File

This mode erases a file from internal memory. Only one file can be erased at a time.

Operating procedure	Operation	Display
<div>□ Press the [F3](FILE MAINTAN.) key from the Memory manager menu 1/3.</div>	[F3]	<div>→MEASD1 /M0123 COORD1 /C0056 Change name Search Delete - - -</div>
<div>②press[▲]or[▼]key to choose the file to be deleted</div>	[▲]or[▼]	<div>MEASD1 /M0123 →COORD1 /C0056 COORD2 /C098 Change name Search Delete - - -</div>
<div>□press[F2](delete)key</div>	[F3]	<div>MEASDI /M0123 →COORDI /C0056 COORD2 /C098 >Delete [no] [yes]</div>
<div>□If it is confirmed to delete this file, press[F4](yes)key</div>	[F4]	<div>MEASD1 /M0123 →COORD2 /C0098 COORD3 /C0321 Change name Search Delete - - -</div>
<div>·press[ESC]key to back to file maintenance menu</div>		

9.4 Coordinate Data Direct Key Input

9.4.1 Coordinate data input

Coordinate data for the layout point or control point can be input directly from the keyboard. This data can be stored into a file in the internal memory.

Operation procedure	Operation	Display
<input type="checkbox"/> Press the [F3](MEMORY MGR.) key from the menu 1/3.	[F3]	<div> MEMORY MGR. 1/3 F1:FILE STATUS F2:SEARCH F3:FILE MAINTAN P↓ </div>
<input type="checkbox"/> Press[F4](P↓)key.	[F4]	<div> MEMORY MGR. 2/3 F1:COORD. INPUT F2:DELETE COORD. F3:PCODE INPUT P↓ </div>
<input type="checkbox"/> Press[F1](COORD. INPUT)key	[F1]	<div> SELECT A FILE FN:_____ INPUT LIST --- ENTER </div>
<input type="checkbox"/> Press the [F1](INPUT) key and enter File Name you want to input. Press the [F4](ENT) key. *1)	[F1] Input FN [F4]	<div> COORD. DATA INPUT F1:NEZ F2:PTL </div>
<input type="checkbox"/> Select the kind of coordinates. NEZ: Coordinate data PTL: The coordinate data for point to line	[F1]	<div> COORD. DATA INPUT PT#:_____ INPUT --- --- ENTER </div>
<input type="checkbox"/> Press[F1](input)key to input PT#. Press[F4](Enter)key.	[F1] Input PT# [F4]	<div> N → 100.234 m E: 12.345 m Z: 1.678 m INPUT --- --- ENTER </div>
<input type="checkbox"/> Enter Coordinate data. Press the [F4](ENT) key. *1)	Input data [F4]	<div> COORD. DATA INPUT PCODE:_____ INPUT LIST --- ENTER </div>

<input type="checkbox"/> Enter PCODE and press the [F4](ENTER). Next input display is shown, point number (PT#) is automaticall incremented.	[F1] Input PCODE [F4]	<div style="border: 1px solid black; padding: 5px;"> COORD. DATA INPUT PT#:GOWIN-102 INPUT --- --- ENTER </div>
*1) Refer to Section 2.5 “How to Enter Alphanumeric characters”		

9.4.2 PTL(Point To Line) data input

The PTL coordinate data of layout point or control point can be directly input by keyboard and can be memorized into a file in internal memory

Operation procedure	Operation	Display
<input type="checkbox"/> Press the [F3](MEMORY MGR.) key from the menu 1/3.	[F3]	<div style="border: 1px solid black; padding: 5px;"> MEMORY MGR. 1/3 F1:FILE STATUS F2:SEARCH F3:FILE MAINTAN P↓ </div>
<input type="checkbox"/> Press[F4](P↓)key.	[F4]	<div style="border: 1px solid black; padding: 5px;"> MEMORY MGR. 2/3 F1:COORD. INPUT F2:DELETE COORD. F3:PCODE INPUT P↓ </div>
<input type="checkbox"/> Press[F1](COORD.INPUT) key.	[F1]	<div style="border: 1px solid black; padding: 5px;"> SELECT A FILE FN:_____ INPUT LIST --- ENTER </div>
<input type="checkbox"/> Press the [F1](INPUT) key and enter File Name you want to input. Press the [F4](ENT) key. *1)	[F1] Input FN [F4]	<div style="border: 1px solid black; padding: 5px;"> COORD. DATA INPUT F1:NEZ F2:PTL </div>
<input type="checkbox"/> Select the kind of coordinates. NEZ: Coordinate data PTL: The coordinate data for point to line	[F2]	<div style="border: 1px solid black; padding: 5px;"> COORD. DATA INPUT PT# : _____ INPUT --- --- ENTER </div>

9.5 Deleting the Coordinate Data in the File

The coordinate data in the file can be deleted.

Operation procedure	Operation	Display
<div>□ Press the [F3](MEMORY MGR.) key from the menu 1/3.</div>	[F3]	<div>MEMORY MGR.1/3 F1:FILE STATUS F2:SEARCH F3:FILE MAINTAN P↓</div>
<div>□ Press[F4](P↓)key.</div>	[F4]	<div>MEMORY MGR.2/3 F1:COORD. INPUT F2:DELETE COORD. F3:PCODE INPUT P↓</div>
<div>□ Press the [F2](DELETE COORD.) key.</div>	[F2]	<div>SELECT A FILE FN:_____ INPUT LIST --- ENTER</div>
<div>□ Press the [F1](INPUT) key and enter File Name. Press the [F4](ENT) key. *1)</div>	[F1] Input FN [F4]	<div>DELETE COORD. PT# :_____ INPUT LIST --- ENTER</div>
<div>□ Press the [F1](INPUT) key and enter PT#. Press the [F4](ENT) key. *1)</div>	[F1] Input PT# [F4]	<div>N: 100.234 m E: 13.345 m Z: 1.678 m >DELETE? [YES] [NO]</div>
<div>□ Confirm the data and press the [F3](YES) key. Deleting starts. The display will return to the previous display.</div>	[F3]	
*1)Refer to 2.5 “How to Enter Alphanumeric characters”		

9.6 Editing PCODE Library

PCODE data can be input into PCODE Library in this mode.

A PCODE is linked with a number of 1 to 50.

PCODE can be also edited in DATA COLLECT menu 2/3 in the same way.

Operation procedure	Operation	Display
<input type="checkbox"/> Press the [F3](MEMORY MGR.) key from the menu 1/3.	[F3]	<div>MEMORY MGR. 1/3</div> <div>F1:FILE STATUS</div> <div>F2:SEARCH</div> <div>F3:FILE MAINTAN P↓</div>
<input type="checkbox"/> Press[F4](P↓)key	[F4]	<div>MEMORY MGR. 2/3</div> <div>F1:COORD. INPUT</div> <div>F2:DELETE COORD.</div> <div>F3:PCODE INPUT P↓</div>
<input type="checkbox"/> Press the [F3](PCODE INPUT) key.	[F3]	<div>→001:GOWIN</div> <div>002:TOKYO</div> <div>EDIT --- CLR ---</div>
<input type="checkbox"/> Press following arrow key to make PCODE number increase or decreases [▲]or[▼]: increase or decrease every 1 [◀]or[▶]:increase or decrease every 10	[▲]or[▼] [◀]or[▶]	<div>011:URAH</div> <div>→012:AMIDAT</div> <div>013:HILLTO</div> <div>EDIT --- CLR ---</div>
<input type="checkbox"/> Press[F1](EDIT)key	[F1]	<div>011: URAH</div> <div>→012=AMIDAT</div> <div>013: HILLTO</div> <div>[ALP] [SPC] [CLR] [ENT]</div>
<input type="checkbox"/> Input PCODE, press[F4] (ENT) key*1)	Input PCODE [F4]	<div>011: URAH</div> <div>→012: AMIDAT</div> <div>013: HILLTO</div> <div>EDIT --- CLR ---</div>

*1)Refer to 2.5 “How to Enter Alphanumeric characters”

9.7 Data Communications

You can send a data file stored in the internal memory to a computer directly. Also, you can directly load a coordinate data file and PCODE Library data to the internal memory from the computer.

9.7.1 Sending Data

Example: Sending a Measured data file

Operation procedure	Operation	Display
<div>□ Press the [F3](MEMORY MGR.) key from the menu 1/3.</div>	[F3]	<div>MEMORY MGR. 1/3 F1:FILE STATUS F2:SEARCH F3:FILE MAINTAN P↓</div>
<div>□ Press[F4](P↓)key twice</div>	[F4] [F4]	<div>MEMORY MGR. 3/3 F1: DATA TRANSFER F2: INITIALIZE P↓</div>
<div>□ Press[F1](DATA TRANSFER) key</div>	[F1]	<div>DATA TRANSFER F1: GTS FORMAT F2: SSS FORMAT</div>
<div>□ Select data format. GTS format: The conventional data SSS format: Including PCODE data , ‘From’ and ‘To’ data for Point to Line.</div>	[F1]	<div>DATA TRANSFER F1: SEND DATA F2: LOAD DATA F3: COMM..PARAMETERS</div>
<div>□ Press[F1]key</div>	[F1]	<div>SEND DATA F1:MEAS. DATA F2:COORD. DATA F3:PCODE DATA</div>
<div>□ Select the type of data to send by pressing [F1]-[F3] key. Example : [F1](MEAS. DATA)</div>	[F1]	<div>SELECT A FILE FN:_____ INPUT LIST --- ENTER</div>

<input type="checkbox"/> Press the [F1](INPUT) key and enter File Name you want to send. Press the [F4] (ENT) key. *1),2) <input type="checkbox"/> Press the [F3](YES) key .*3) The sending starts. The display will return to menu.	[F1] Input FN [F4]	SEND MEAS. DATA >OK? --- --- [YES] [NO]
	[F3]	SEND MEAS. DATA <SENDING DATA !> STOP
*1) Refer to Section 2.5 “How to Enter Alphanumeric characters”. *2) To scroll the data, press the[▲]or[▼] key. • To show the file list, press the [F2](LIST) key. *3) To cancel the sending, press the [F4](STOP) key.		

9.7.2 Loading Data

Coordinate data files and PCODE Library data can be loaded from PC.
Example: Loading a coordinate data file

Operation procedure	Operation	Display
<input type="checkbox"/> Press the [F3](MEMORY MGR.) key from the menu 1/3. <input type="checkbox"/> Press[F4](P↓)key twice <input type="checkbox"/> Press[F1](DATA TRANSFER) key <input type="checkbox"/> Press[F1](GTS FORMAT) key	[F3]	MEMORY MGR. 1/3 F1:FILE STATUS F2:SEARCH F3:FILE MAINTAN P↓
	[F4] [F4]	MEMORY MGR. 3/3 F1: DATA TRANSFER F2: INITIALIZE P↓
	[F1]	DATA TRANSFER F1: GTS FORMAT F2: SSS FORMAT
	[F1]	DATA TRANSFER F1:SEND DATA F2:LOAD DATA F3:COMM..PARAMETERS

<p>□ Press[F2]key</p>	<p>[F2]</p>	<div data-bbox="787 163 1224 333"> LOAD DATA F1: COORD. DATA F2: PCODE DATA. </div>
<p>□ Select the type of data to load by pressing [F1] or [F2] key. Example : [F1](COORD. DATA)</p>	<p>[F1]</p>	<div data-bbox="787 401 1224 571"> COORD. FILE NAME FN:_____ </div> <div data-bbox="787 529 1224 571"> INPUT --- --- ENTER </div>
<p>□ Press the [F1](INPUT) key and enter New File Name you want to receive. Press the [F4](ENT) key. *1)</p>	<p>[F1] Input FN [F4]</p>	<div data-bbox="787 653 1224 843"> LOAD COORD. DATA >OK ? --- --- [YES] [NO] </div>
<p>□ Press the [F3](YES) key. *2) The loading starts. The display will return to menu.</p>	<p>[F3]</p>	<div data-bbox="787 957 1224 1127"> LOAD COORD. DATA <LOADING DATA!> STOP </div>
<p>*1) Refer to 2.5 “How to Enter Alphanumeric characters” *2) To delete loading data, press[F4](Stop)key.</p>		

9.7.3 Setting of Data Communication Parameters

- Items of the Parameter

ITEM	Selecting Item	Contents
F1: Protocol	[ACK/NAK], [ONE WAY]	Setting Protocol [ACK/NAK] or [ONE WAY] communication
F2: Baud rate	1200, 2400, 4800, 9600, 19200,38400	Setting transfer speed 1200/2400/4800/9600 /19200/ 38400 baud rate
F3: Char./ Parity	[7/EVEN], [7/ODD], [8/NON]	Setting data length and parity. [7bit, even], [7bit, odd], [8bit,none]
F1: Stop Bits	1, 2	Setting Stop 1 bit or 2bits

- Example Setting** Baud rate : 19200

Operation procedure	Operation	Display
<input type="checkbox"/> Press the [F3](MEMORY MGR.) key from the menu 1/3.	[F3]	<div>MEMORY MGR. 1/3 F1:FILE STATUS F2:SEARCH F3:FILE MAINTAN P↓</div>
<input type="checkbox"/> Press[F4](P↓)key twice	[F4] [F4]	<div>MEMORY MGR. 3/3 F1: DATA TRANSFER F2: INITIALIZE P↓</div>
<input type="checkbox"/> Press[F1](DATA TRANSFER) key	[F1]	<div>DATA TRANSFER F1: GTS FORMAT F2: SSS FORMAT</div>

<p>□ Press[F1](GTS FORMAT) key</p> <p>□ Press the [F3](COMM. PARAMETERS) key.</p> <p>□ Press the [F2](BAUD RATE) key. [] indicates present setting.</p> <p>□ Select the items by pressing [▲]or[▼] , [▶] and [◀] keys. *1)</p> <p>□ Press[F4](Enter)key</p>	<p>[F1]</p> <p>[F3]</p> <p>[F2]</p> <p>[▶] [▼]</p> <p>[F4]</p>	<div data-bbox="792 167 1229 335"> DATA TRANSFER F1:SEND DATA F2:LOAD DATA F3:COMM..PARAMETERS </div> <div data-bbox="792 396 1229 563"> COMM. PARAMETERS 1/2 F1: PROTOCOL F2: BAUD RATE F3: CHAR./PARITY P ↓ </div> <div data-bbox="792 614 1229 782"> BAUDRATE [1200] 2400 4800 9600 19200 38400 ENTER </div> <div data-bbox="792 839 1229 1007"> BAUDRATE 1200 2400 4800 9600 [19200] 38400 ENTER </div> <div data-bbox="792 1049 1229 1231"> COMM. PARAMETERS 1/2 F1: PROTOCOL F2: BAUD RATE F3: CHAR./PARITY P ↓ </div>
*1 To delete setting, press[Enter]key		

9.8 Initialization

This mode is used to initialize the internal memory. Following data can be initialized.

FILE DATA :All files of measuring data and coordinate data

PCODE DATA: PCODE LIST.

ALL DATA: FILE DATA and PCODE DATA

Note that the following data are not initialized even if initialization is executed.

: Coordinates of the instrument, Instrument height and Reflector height.

Example:Initialization: ALL DATA (FILE data and PCODE data)

Operation procedure	Operation	Display
<div><input type="checkbox"/> Press the [F3](MEMORY MGR.) key from the menu 1/3.</div> <div><input type="checkbox"/> Press[F4](P↓)key twice</div> <div><input type="checkbox"/> Press[F2] (INITIALIZE)key</div> <div><input type="checkbox"/> Select the data to initialize by pressing one of the [F1] to [F3] key. Example : [F3](ALL DATA)</div> <div><input type="checkbox"/> Confirm the erase data, press the [F4](YES) key. Initializing will start. The display returns to menu.</div>	[F3]	<div>MEMORY MGR. 1/3 F1:FILE STATUS F2:SEARCH F3:FILE MAINTAN P↓</div>
	[F4] [F4]	<div>MEMORY MGR. 3/3 F1: DATA TRANSFER F2: INITIALIZE P↓</div>
	[F2]	<div>INITIALIZE F1: FILE AREA F2: PCODE LIST F2: ALL DATA</div>
	[F3]	<div>INITIALIZE DATA ERASE ALL DATA ! >0K? [NO][YES]</div>
	[F4]	<div>INITIALIZE DATA 〈INITIALIZING ! 〉</div>
		<div>MEMORY MGR. 3/3 F1: DATA TRANSFER F2: INITIALIZE P↓</div>

10. SET AUDIO MODE

The light acceptance quantity level for the EDM (SIGNAL), the atmospheric correction value (PPM) and correction value of prism constant (PSM) are displayed in this mode.

When reflected light from the prism is received a buzzer sounds. This function is good for easy collimation when the target is difficult to find.

Operation procedure	Operation	Display
<div><div><div><div><div><div></div><div>Make sure the mode is in the distance measurement mode on page 1.</div></div></div><div><div></div><div>Pressing the [F3](S/A) key, mode changes to set audio mode.</div></div></div><div><div>The display indicates correction value of prism constant (PSM), atmospheric correction (PPM) and reflection light level (SIGNAL).</div><div><div>When receiving reflected light, buzzer sounds. It is possible to stop the sound, see Chapter 16 “SELECTING MODE” .</div><div>The [F1] to [F3] keys are used for setting atmospheric correction and prism constant.</div><div>To return to normal measuring mode, press the [ESC] key.</div></div></div></div></div>	<div>[F3]</div>	<div><div><div>HR : 120°30'40"</div><div>HD : 123.456 m</div><div>VD : 5.678 m</div><div>MEAS MODE S/A P1↓</div></div><div><div>SET AUDIO MODE</div><div>PSM:0.0 PPM 0.0</div><div>SIGNAL: [■ ■ ■ ■ ■]</div><div>PRISM PPM T-P ---</div></div></div>

11. SETTING THE PRISM CONSTANT VALUE

The prism constant value of GOWIN is set to zero. When using prisms other than GOWIN, it is necessary to set the prism constant correction value of that specific prism. Once you set the correction value for prism constant, it is retained after power is OFF.

Operation procedure	Operation	Display
<div><div><input type="checkbox"/> Press the [F3](S/A) key from distance measurement or coordinates measurement mode.</div><div><input type="checkbox"/> Press[F1](PRISM)key</div><div><input type="checkbox"/> Input the Prism constant correction value. *1) The display returns to set audio mode.</div></div>	<div><div>[F3]</div><div>[F1]</div><div>Input data [F4]</div></div>	<div><div>SET AUDIO MODE PSM:0.0 PPM 0.0 SIGNAL: [■ ■ ■ ■ ■] PRISM PPM T-P ---</div><div>SET AUDIO MODE PRISM: 0.0 mm --- --- [CLR] [ENT]</div><div>SET AUDIO MODE PSM:14.0 PPM 0.0 SIGNAL: [■ ■ ■ ■ ■] PRISM PPM T-P ---</div></div>
<div><div>*1)Refer to 2.5 “How to Enter Alphanumeric characters”</div><div>• Input range: -99.9mm to +99.9mm 0.1mm step</div></div>		

12. SETTING ATMOSPHERIC CORRECTION

The velocity of light through air is not constant and depends on the atmospheric temperature and pressure, This instrument can carry out atmospheric correction to distance measurement result automatically once the atmospheric correction value is set, the standard atmospheric status of this instrument is temp.15□/59□, air pressure 1013.25hPa/760mmHg / 29.9inHg, atmospheric correction is 0ppm. The values are kept in the memory even after power is OFF.

12.1 Calculation of Atmospheric Correction

Correction formula is as follows:

Calculation unit: meter

$$K_a = \{279.85 - \frac{79.585 \times p}{273.15 + t}\} \times 10^{-6}$$

Ka:Atmospheric correction value

P:ambient atmospheric pressure(hPa)

t:ambient atmospheric temperature(□)

Distance L(m) after atmospheric correction is obtained from following formular:

$$L = 1(1 + K_a) \quad l$$
 l:Distance measurement value without atmospheric correction

Example: set air temperature as +20□, air pressure is 847hPa, l=1000m

$$K_a = \{279.85 - \frac{79.585 \times 847}{273.15 + 1}\} \times 10^{-6}$$

$$\approx 50 \times 10^{-6} (50ppm)$$

$$L = 1000(1 + 50 \times 10^{-6}) = 1000.050m$$

12.2 Setting of the Atmospheric Correction

• How to Set Temperature and Pressure Value Directly

Measure the temperature and air pressure surrounding the instrument beforehand.

Example:Temperature:+26□, Pressure:1017hPa

Operation procedure	Operation	Display
□ Press the [F3](S/A) key to set Set Audio Mode from distance or coordinate measurement mode.	[F3]	<div>SET AUDIO MODE PSM:0.0 PPM 0.0 SIGNAL: [■ ■ ■ ■ ■] PRISM PPM T-P ---</div>

<input type="checkbox"/> Press[F3](T-P)key	[F3]	<div>TEMP. & PRES. SET TEMP. = 15.0 °C PRES. : 1013.2 hPa --- --- [CLR] [ENT]</div>
<input type="checkbox"/> Input Temp.value and Pressure value.*1) Mode returns to Set Audio mode.	Input Temp.,pres.	<div>TEMP. & PRES. SET TEMP. = 26.0 °C PRES. : 1017.0 hPa --- --- [CLR] [ENT]</div>
<p>*1)Refer to 2.5 “How to Enter Alphanumeric characters”.</p> <ul style="list-style-type: none"> ● Range: Temp.-30□ to +60□(0.1 step) or -22□to +140□(0.1□step), air pressure 560 to 1066.0hPa(0.1hPa step), 420 to 800mmHg (0.1mmHg step)16.5 or 31.5inHg(0.1inHg step). ● When the atmospheric correction value which is calculated from the input temperature and pressure values exceeds the range 999.9ppm, the operating procedure returns to step 3 automatically. Input values again. 		

●How to Set the Atmospheric Correction Value Directly

Measure the temperature and air pressure to find atmospheric correction value (PPM) from the chart or correction formula.


Operating procedure	Operation	Display
①Press the [F3](S/A) key to set Set Audio Mode from distance or coordinate measurement mode.	[F3]	<div>SET AUDIO MODE PSM:0.0 PPM 0.0 SIGNAL: [■■■■■] PRISM PPM T-P ---</div>
<input type="checkbox"/> Press the [F2](PPM) key. Current setting value is displayed.	[F2]	<div>PPM SET PPM = 0.0 ppm --- --- [CLR] [ENT]</div>
<input type="checkbox"/> Enter atmospheric correction value. *1) Mode returns to Set Audio mode.	Inputdata [F4]	
<p>*1)Refer to 2.5 “How to Enter Alphanumeric characters”</p> <ul style="list-style-type: none"> ●Input range: -999,9ppm to +999.9ppm step 0.1ppm 		


Atmospheric Correction Chart (For your reference)

The atmospheric correction value is obtained easily with the atmospheric correction chart. Find the measured temperature in horizontal, and pressure in vertical on the chart. Read the value from the diagonal line, which represents the required atmospheric correction value.


Example:

The measured temperature is +26°
The measured air pressure is 1013 hPa
then
The correction value is +10ppm






Temperature($^{\circ}$ C)



Temperature($^{\circ}$ C)



13. CORRECTION FOR REFRACTION AND EARTH CURVATURE

The instrument measures distance, taking into account correction for refraction and earth curvature.

13.1 Distance Calculation Formula

Distance Calculation Formula; with correction for refraction and earth curvature taken into account.

Follow the Formula below for converting horizontal and vertical distances.

HD and Height Difference is calculated as per following formula

Horizontal Distance $D=AC(\alpha)$ or $BE(\beta)$

Height Difference $Z=BC(\alpha)$ or $EA(\beta)$

$D=L\{\cos\alpha-(2\theta-\gamma)\sin\alpha\}$

$Z=L\{\sin\alpha+(\theta-\gamma)\cos\alpha\}$

$\theta=L\cos\alpha / 2R$ Earth Curvature Correction Item


$\gamma=KL\cos\alpha / 2R$ Refraction Correction Item...

$K=0.14$ 或 0.2Refraction Coefficient

$R=6372\text{km}$ Earth Curvature Radius...

α (or β) Altitude angle...

LTilt Distance



·if no refraction and earth curvature correction is done, the horizontal distance and height difference calculation formular is

$D=L \cdot \cos \alpha$

$Z=L \cdot \sin \alpha$

Note: the ex-works setting of refraction coefficient is $K=0.14$, if you want to change K value, please see 16 “Selecting mode”

14. POWER SOURCE AND CHARGING

14.1 On-board Battery BT-L1W

•Taking the battery out

It should be confirmed that the power is off before taking the battery out. As shown in following diagram, press battery locking lever to take the on-board battery BT-L1W out.

•Charging of battery

- 1 Plug the charger into the outlet. Use an AC cable compatible with the power supply voltage in use.
- 2 Connect the charger connector to the battery, then charging will start.
(the red light on the charger illuminate),
- 3 Charging will take approximately 3 hours. (The green lamp will illuminate).
- 4 After charging, remove the battery from the charger.
- 5 Remove the charger from the outlet.

15. DETACH/ATTACH OF TRIBRACH


The instrument is easily detached or attached to the tribrach, with a tribrach locking lever loosened or tightened for this purpose.

• Detachment

- Loosen the tribrach locking lever, by revolving it 180° or 200g in the counterclockwise direction (which will point the triangle mark upwards).
- Grip the carrying handle firmly with one hand while holding the tribrach with the other. Then lift the instrument straight upwards and off.

• Attachment

- Hold the instrument by the carrying handle, with one hand, and carefully lower it on top of the tribrach while, at the same time, coinciding the alignment piece with the tribrach alignment groove on the instrument and tribrach respectively.
- When fully seated, revolve the tribrach locking lever 180° or 200g clockwise (which will point the triangle mark downwards again).



• Locking the Tribrach Locking Lever

The tribrach locking lever can be locked, to prevent it be accidentally removed, especially if the upper instrument section is not being detached very often. Simply tighten the securing screw on the locking lever with the accessory screwdriver, found in the case.

16. SELECTING MODE

16.1 Items of the Selecting Mode

The following modes are available.

Menu	Items	Selecting item	Display
1: UNIT SET	TEMP. & PRES.	°C / °F hPa / mmHg / inHg	Select the unit of temperature for atmospheric correction. Select the unit of air pressure for atmospheric correction .
	ANGLE	DEG(360°) / GON(400G) / MIL(6400M)	Choose degree, gon or mil unit for measuring angle.
	DISTANCE	METER / FEET / FEET and inch	Choose measuring unit for distance meter , feet or feet and inch
	FEET	US SURVEY / INTERNATIONAL	Select the meter / feet conversion factor. US SURVEY feet 1m=3.280833333333333 ft. INTERNATIONAL feet 1m=3.280839895013123 ft.
2: MODE SET	POWER ON MODE	ANGLE MEAS./ DISTANCE MEAS.	Select to set the measurement mode for angle or distance when the power is turned on.
	FINE/CRS/ TRK	FINE / COARSE / TRACK	Select Fine /Coarse / Tracking mode in distance measurement mode, when the power is turned on.
	HD&VD/SD	HD&VD /SD	Specify which is displayed first, horizontal and vertical distance or slope distance, when the power is turned on.
	V ANGLE Z0/H0	Zenith 0 / Horizontal 0	Choose the vertical angle reading from zenith or from level.

2: MODE
SET

N-TIMES / REPEAT	N-TIMES / REPEAT	Select the measurement mode for distance when the power is turned on.
TIMES OF MEAS.	0~99	Set N (number of times) for times of distance measurement. When setting number of times as 1, it is single measurement.
NEZ / ENZ	NEZ / ENZ	Select a coordinate displaying order either NEZ or ENZ.
HA MEMORY	ON / OFF	Horizontal angle set can be retained after the power is turned off.
ESC KEY MODE	DATA COLLECT / LAYOUT / REC / OFF	You can select a function of the [ESC] key. DATA COLLECT / LAYOUT: It is possible to enter data input mode (in DATA COLLECT) or Layout Menu from normal measuring mode directly. REC: While executing normal or offset measuring, the measuring data can be output. OFF: Returns to normal function.
COORD. CHECK	ON / OFF	Select coordinate displaying ON or OFF when setting a point.

2: MODE SET	EDM OFF TIME	0-99	The time when EDM is cut off from distance measurement is completed can be changed. This function is effective for shortening the first time measuring time when distance measurement is started from distance measurement completing state. (Default:3minutes) 0 :After completing distance measurement, EDM is cut off immediately. 1-98 :EDM is cut off after 1~98 minutes. 99 :EDM is always switched ON.
	FINE READING	0.2/1mm	Select 1mm or 0.2mm for the minimum reading unit in the distance mode (FINE mode).
	OFFSET V ANG	FREE / HOLD	Select Vertical angle setting in the Angle Offset measurement mode. FREE: Vertical angle varies by the angle of the telescope. HOLD: Vertical angle is fixed even if the angle of the telescope changes.
3: OTHERS SET	H-ANGLE BUZZER	ON / OFF	Specify whether the buzzer sounds or not for every horizontal angle 90° .
	S/A BUZZER	ON / OFF	Specify whether the buzzer sounds or not in the set audio mode.
	W-CORRECTION	OFF / K=0.14 / K=0.20	Set correction for refraction and earth curvature,coefficient of refraction as ; K=0.14, K=0.20 or no correction.

3:
OTHERS
SET

NEZ MEMORY	ON / OFF	It is possible to retain the coordinate of instrument point, the instrument height and prism height after power off.
REC TYPE	REC-A / REC-B	Select REC-A or REC-B for data output. REC-A :The measurement is made again and this new data is output. REC-B : The data being displayed is output.
CR,LF	ON / OFF	It is possible to output the data with carriage return and line feed.
NEZ REC FORM	STANDARD / STANDARD (12dig) / with RAW with RAW (12dig)	Select the format of the record coordinates data STANDARD: 11 digits standard data STASNDARD (12dig):12 digits standard data with RAW:11digits standard data with raw data with RAW (12dig):12digits standard data with raw data
MANUAL NEZ REC	ON/ OFF	In the layout mode or data collect mode, it is possible to record coordinates entered directly from the keyboard.
LANGUAGE *	ENGLISH/ OTHER *	Select the displaying language.
ACK MODE	STANDARD / OMITTED	Set the procedure of the communication with external device. STANDARD:Normal procedure OMITTED:Even though the [ACK] is omitted from the external device, the data is not sent again.
GRID FACTOR	USE G.F. / DON'T USE	Select using GRID FACTOR in calculation of measurement

3: OTHERS SET			data.
	CUT & FILL	STANDARD / CUT&FILL	In the layout mode, CUT & FILL can be displayed instead of dZ.
	ECHO BACK	ON / OFF	It is possible to output the data of echo back type.
	CONTRAST MENU	ON / OFF	When the instrument is turned ON, it is possible to display the screen which you can adjust contrast of the display and confirm the prism constant (PSM) and atmospheric correction

***Language** selection varies along with countries

16.2 How to Set Seleting Mode

<Example> : Setting unit in hPa, °F, NEZ MEMORY:ON

Operating procedure	Operation	Display
<div>□While pressing [F2] key, turn power ON.</div>	<div>[F2] + Power ON</div>	<div>PARAMETERS 2 F1: UNIT SET F2: MODE SET F3: OTHER SET</div>
<div>□Press [F1](UNIT SET) key.</div>	<div>[F1]</div>	<div>UNIT SET1/2 F1: TEMP. & PRES. F2: ANGLE F3: DISTANCEP↓</div>
<div>□Press [F1](TEMP. & PRES.) key.</div>	<div>[F1]</div>	<div>TEMP. & PRES. UNIT TEMP. : °C PRES. : mmHg °C °F --- ENTER</div>
<div>□Press [F2](°F) key, and press F4](ENTER) key.</div>	<div>[F2] [F4]</div>	<div>TEMP. & PRES. UNIT TEMP. : °F PRES. : mmHg hPa mmHg inHg ENTER</div>
<div>□Press [F1](hPa) key, and press [F4] (ENTER) key. Returns to unit set menu.</div>	<div>[F1] [F4]</div>	<div>UNIT SET1/2 F1: TEMP. & PRES. F2: ANGLE F3: DISTANCEP↓</div>

<input type="checkbox"/> Press [ESC] key. Returns to PARAMETERS 2 menu.	[ESC]	<div> PARAMETERS 2 F1: UNIT SET F2: MODE SET F3: OTHER SET </div>
<input type="checkbox"/> Press[F3](OTHER SET) key	[F3]	<div> OTHERS SET 1/5 F1:H-ANGLE BUZZER F2:S/A BUZZER F3:W-CORRECTION P↓ </div>
<input type="checkbox"/> Press [F4](P↓) key, to get the function in page 2 .	[F4]	<div> OTHERS SET 2/5 F1:NEZ MEMORY F2:REC TYPE F3:CR,LF P↓ </div>
<input type="checkbox"/> Press[F1]key	[F1]	<div> NEZ MEMORY [OFF] [ON] [OFF] — ENTER </div>
<input type="checkbox"/> Press [F1](ON) key, and press [F4] (ENTER) key. Returns to OTHERS SET menu.	[F1] [F4]	<div> OTHERS SET 2/5 F1:NEZ MEMORY F2:REC TYPE F3:CR,LF P↓ </div>
11 Power off	Power off	
<ul style="list-style-type: none"> Up or down arrow key can be used when there are four or more selection items. 		

17. CHECKING AND ADJUSTMENT

17.1 Checking and adjusting of instrument constant


Normally, the instrument constant does not have discrepancy. It is recommended you measure and compare with an accurately measured distance at a location where the precision is specifically monitored on a consistent basis. If such a location is not available, establish your own base line over 20m (when purchasing the instrument) and compare the data measured with the newly purchased instrument.

In both cases please note that the setup displacement of the instrument position over the point, the prism, baseline precision, poor collimation, atmospheric correction, and correction for refraction and earth curvature determine the inspection precision. Please keep in mind these points.

Also, when providing a base line in a building, please note that differences in temperature greatly affect the length measured.

If a difference of 5mm or over is the result from the comparative measurement, the following procedure as shown below could be used to change the instrument constant.

- 1) Provide point C on a straight line, connecting straight line AB which is almost level and about 100m long. Measure straight lines AB, AC and BC.



- 2) Obtain the instrument constant by repeating above several times. Instrument constant = $AC + BC - AB$
- 3) When there is error between written instrument constant value and calculated value, refer to Section 17.4 "How to Set the Instrument Constant Value".
- 4) Once again, measure at a calibrated baseline and compare results.


5) If using above procedure and no difference is found from the instrument constant at the factory or a difference of over 5mm is found, contact dealer.

Note: The seal with which the value is written is stuck on the lower part of the instrument, or the battery removal side of the instrument.


17.2 Checking the Optical Axis

To check if the optical axis of EDM and theodolite are matched, follow the procedure below. It is especially important to check after adjustment of the eyepiece reticle is carried out.

- ☐ Position the Instrument and prism with about 2m apart and face them at each other. (At this time, the power is ON.)



- ☐ Sight through the eyepiece and focus to the prism. Then center the prism on the cross hairs.



- ☐ Set to the measure mode to distance measurement or set audio.
- ☐ Sight through the eyepiece and focus the (blinking) red light spot by turning the focusing knob in the direction of infinity (clockwise). If displacement of the reticle

cross hairs is within one-fifth of the diameter of the round red light spot both vertically and horizontally, adjustment will not be required.

Note: If displacement is more than one-fifth in the above case, and still remains so after rechecking the original line of sight, the instrument must be adjusted by competent technicians. Please contact dealer or agent for adjustment.

17.3 Checking and adjusting of theodolite

- **Points on the Adjustment**


- ☐ Adjust the eyepiece of the telescope properly prior to any checking operation which involves sighting through the telescope.
Remember to focus properly, with parallax completely eliminated.
- ☐ Carry out the adjustments in the order of item numbers, as the adjustments are dependent one upon another. Adjustments carried out in the wrong sequence may even nullify previous adjustment.
- ☐ Always conclude adjustments by tightening the adjustment screws securely (but do not tighten them more than necessary, as you may strip the threads, twist off the screw or place undue stress on the parts). Furthermore, always tighten by revolving in the direction of tightening tension.
- ☐ The attachment screws must also be tightened sufficiently, upon completion of adjustments.

- Always repeat checking operations after adjustments are made, in order to confirm results.

- **Notes on the Tribrach**

Note that the angle measuring precision may be effected directly if the tribrach has not been installed firmly.

- If any leveling screw becomes loose and slack or if collimation is unstable due to the looseness of leveling screws, adjust by tightening the adjusting screws (in 2 places) installed over each leveling screw with a screwdriver.
- If there is any slack between the leveling screws and the base, loosen the set screw of the holding ring and tighten the holding ring with adjusting pin, until it is properly adjusted. Re-tighten the set screw on completing the adjustment.




17.3.1 Checking /Adjusting the Plate Level

Adjustment is required if the axis of the plate level is not perpendicular to the vertical axis.

- **Check**


- Place the plate level parallel to a line running through the centers of two leveling screws, say, A and B. Use these two leveling screws only and place the bubble in the center of the plate level.

- Rotate the instrument 180° or $200g$ around the vertical axis and check bubble movement of the plate level. If the bubble has been displaced, then proceed with the following adjustment.



● Adjustment

- Adjust the level adjustment capstan screw, with the accessory adjusting pin and return the bubble towards the center of the plate level. Correct only one-half of the displacement by this method.
- Correct the remaining amount of the bubble displacement with the leveling screws.
- Rotate the instrument 180° or $200g$ around the vertical axis once more and check bubble movement. If the bubble is still displaced, then repeat the adjustment.



17.3.2 Checking / Adjusting the Circular Level

Adjustment is required if the axis of the circular level is not perpendicular to the vertical axis.


- **Check**

Carefully level the instrument with the plate level only. If the bubble of the circular level is centered properly, adjustment is not required. Otherwise, proceed with the following adjustment.


- **Adjustment**

Shift the bubble to the center of the circular level, by adjusting three capstan adjustment screws on the bottom surface of the circular level, with the accessory adjusting pin

Adjustment screw
of circular level



Bottom level




17.3.3 Adjustment of the Vertical Cross-hair

Adjustment is required if the vertical cross-hair is not in a plane perpendicular to the horizontal axis of the telescope (since it must be possible to use any point on the hair for measuring horizontal angles or running lines).

- **Check**


- ☐ Set the instrument up the tripod and carefully level it.
- ☐ Sight the cross-hairs on a well defined Point A at a distance of, at least, 50 meters (160ft.) and clamp horizontal motion.
- ☐ Next swing the telescope vertically using the vertical tangent screw, and check whether the point travels along the length of the vertical cross-hair.
- ☐ If the point appears to move continuously on the hair, the vertical cross-hair lies in a plane perpendicular to the horizontal axis (and adjustment is not required).

- However, if the point appears to be displaced from the vertical cross-hair, as the telescope is swung vertically, then proceed with the following adjustment.



• Adjustment

- Unscrew the cross-hair adjustment section cover, by revolving it in the counterclockwise direction, and take it off. This will expose four eyepiece section attachment screws.



- Loosen all four attachment screws slightly with the accessory screw-driver (while taking note of the number of revolutions). Then revolve the eyepiece section so that the vertical cross-hair coincides to Point A'. Finally, re-tighten the four screws by the amount that they were loosened.
- Check once more and if the point travels the entire length of the vertical cross-hair, further adjustment is not required.

Note: Perform following adjustment after completing the above adjustment, i.e. Section 17.3.4 “Collimation of the Instrument”, Section 17.3.6 “Adjustment of Vertical Angle 0 Datum”.

17.3.4 Collimation of the Instrument

Collimation is required to make the line of sight of the telescope perpendicular to the horizontal axis of the instrument, otherwise, it will not be possible to extend a straight line by direct means.

• Check

□ Set the instrument up with clear sights of about 50 to 60 meters (160 to 200 ft.) on both sides of the instrument.

□ Level the instrument properly with the plate level.

□ Sight Point A at approximately 50 meters (160 ft.) distance.


□ Loosen the vertical motion clamp only, and rotate the telescope 180° or 200° around the horizontal axis, so that the telescope is pointed in the opposite direction.

□ Sight Point B, at equal distance as Point A and tighten the vertical motion clamp.

□ Loosen the horizontal motion clamp and rotate the instrument 180° or 200° around the vertical axis. Fix a sight on Point A once more and tighten the horizontal motion clamp.

□ Loosen the vertical motion clamp only and rotate the telescope 180° or 200° around the horizontal axis once more and fix a sight on Point C, which should coincide with previous Point B.


□ If Points B and C do not coincide, adjust in the following manner



•Adjustment


□ Unscrew the cross-hair adjustment section cover.

□ Find Point D at a point between Points C and B, which should be equal to $\frac{1}{4}$ th the distance between Points B and C and measured from Point C. This is because the apparent error between Points B and C is four times the actual error since the telescope has been reversed twice during the checking operation.



□ Shift the vertical cross-hair line and coincide it with Point D, by revolving the left and right capstan

adjustment screws with the adjusting pin. Upon completing the adjustment, repeat the checking operation once more. If Points B and C coincide, further adjustment is not required. Otherwise, repeat the adjustment.



Note: 1 First, loosen the capstan adjustment screw on the side to which the vertical cross-hair line must be moved. Then tighten the adjustment screw on the opposite side by an equal amount which will leave the stress of the adjustment screws unchanged. Revolve in the counterclockwise direction to loosen and in the clockwise direction to tighten, but revolve as little as possible

2 Perform following adjustment after completing the above adjustment, i.e. Section 17.3.6 "Adjustment of Vertical Angle 0 Datum", 17.2 Checking the Optical Axis

17.3.5 Checking / Adjusting the Optical Plummet Telescope


Adjustment is required to make the line of sight of the optical plummet telescope coincide with the vertical axis (otherwise the vertical axis will not be in the true vertical when the instrument is optically plumbed).

• Check

- ☐ Coincide the center mark and the point. (See Chapter 2 “PREPARATION FOR MEASUREMENT”)
- ☐ Rotate the instrument 180° or 200g around the vertical axis and check the center mark. If the point is properly centered in the center mark, adjustment is not required. Otherwise, adjust in the following manner.

• Adjustment

- ☐ Take off the adjustment section cover of the optical plummet telescope eyepiece. This will expose four capstan adjustment screws which should be adjusted with the accessory adjusting pin to shift the center mark to the point. However, correct only one-half of the displacement in this manner.



Optical Plummet Telescope

- ☐ Use the leveling screws and coincide the point and center mark.
- ☐ Rotate the instrument 180° or 200g around the vertical axis once more and check the center mark. If it is coincided to the point, then further adjustment is not required. Otherwise, repeat the adjustment.

Note: First, loosen the capstan adjustment screw on the side to which the vertical cross-hair line must be moved. Then tighten the adjustment screw on the opposite side by an equal amount which will leave the tension of the adjustment screws unchanged. Revolve in the counterclockwise direction to loosen and in the clockwise direction to tighten, but revolve as little as possible.

17.3.6 Adjustment of Vertical Angle 0 Datum

If when measuring the vertical angle of target A at telescope position normal (direct) and reverse settings, the amount of normal and reverse measurements combined is other than 360° (ZENITH-0), half of the difference from 360 is the error amount from corrected 0 setting. Carry out adjustment. As adjustment for vertical angle 0 setting is the criteria for determining instrument coordinate origin, use special care for adjustment.

Operating procedure	Operation	Display
<div><div><input type="checkbox"/>Level the instrument properly with the plate level.</div><div><input type="checkbox"/>While pressing the [F1]key, turn power switch ON.</div></div>	<div><div>[F1] + Power ON</div></div>	<div><div>ADJUSTMENT MODE F1:V ANGLE 0 POINT F2:INST. CONSTANT F3:FRQ CHECK MODE</div></div>
<div><div><input type="checkbox"/>Press[F1]key</div></div>	<div><div>[F1]</div></div>	<div><div>V0 ADJUSTMENT <STEP-1> FRONT V: 90°00'00" <div>ENTER</div></div></div>
<div><div><input type="checkbox"/>Collimate target A from the telescope properly in normal setting.</div><div><input type="checkbox"/>Press[F4](Enter)key</div></div>	<div><div>Collimate A (telescope direct) [F4]</div></div>	<div><div>V0 ADJUSTMENT <STEP-2> REVERSE V: 270°00'00" <div>ENTER</div></div></div>
<div><div><input type="checkbox"/>Collimate target A in reverse telescope setting.</div><div><input type="checkbox"/>Press the [F4](ENTER) key. Measured value is set and carry out normal angle measurement.</div></div>	<div><div>[F4]</div></div>	<div><div><div><SET!></div><div>↓</div><div>V : 270°00'00" HR: 120°30'40" <div>0SET HOLD HSET P1↓</div></div></div></div>
<div><div><input type="checkbox"/>Check that the total amount of normal and reverse angular travel is 360° collimating the target A by normal and reverse positions.</div></div>		

17.4 How to Set the Instrument Constant Value

To set the Instrument constant which is obtained in Section 17.1 “Check and adjusting of instrument constant”, follow as below.

Operating procedure	Operation	Display
<div><input type="checkbox"/> While pressing the [F1] key, turn power switch ON.</div>	<div>[F1] + Power ON</div>	<div>ADJUSTMENT MODE F1:V ANGLE 0 POINT F2:INST. CONSTANT F3:FRQ CHECK MODE</div>
<div><input type="checkbox"/> Press[F2]key</div>	<div>[F2]</div>	<div>INST. CONSTANT SET INST. CONSTANT = - 0.6 mm --- --- [CLR] [ENT]</div>
<div><input type="checkbox"/> Enter the constant value. *1),2)</div>	<div>Input value [F4]</div>	<div>INST. CONSTANT SET INST. CONSTANT : - 0.7 mm INPUT --- --- ENTER</div>
<div><input type="checkbox"/> Turn power switch OFF</div>	<div>POWER OFF</div>	
<div><div>*1) Refer to Section 2.5 “How to Enter Alphanumeric characters”.</div><div>*2) To cancel the setting, press the [ESC] key.</div></div>		

17.5 Reference frequency check mode


The beam modulated by the reference frequency of EDM is emitted continuously.
This mode is used for frequency test mainly.

Operating procedure	Operation	Display
<div><input type="checkbox"/> While pressing the [F1] key, turn power switch ON.</div> <div><input type="checkbox"/> Press the [F3](FRQ CHECK MODE) key.</div> <div><input type="checkbox"/> Press the [F1](EXIT) key. The display will return to Adjustment mode menu 2/2.</div>	[F1] + Power ON	<div>ADJUSTMENT MODE F1:V ANGLE 0 POINT F2:INST. CONSTANT F3:FRQ CHECK MODE</div>
	[F3]	<div>FRQ CHECK MODE</div> <div>EXIT</div>
	[F1]	<div>ADJUSTMENT MODE F1:V ANGLE 0 POINT F2:INST. CONSTANT F3:FRQ CHECK MODE</div>

18. PRECAUTIONS

1. For transportation, hold by the handle or yoke of the instrument. Never hold by the lens barrel as it can affect the fixing bracket inside and reduce the accuracy of the instrument.
2. Never expose the instrument without a filter to direct sunlight. It may damage the components inside the instrument.
3. Never leave the instrument unprotected in high temperature. The temperature inside instrument may easily reach up to 70°C or above and will reduce the service life.
4. The instrument should be stored in the room temperature range of minus 30°C to plus 60°C.
5. When a high degree of precision is required for measurement, provide shade against direct sunlight for the instrument and tripod.
6. Any sudden change of temperature to the instrument or prism may result in a reduction of measuring distance range, i.e. when taking the instrument out from a heated vehicle.
7. When opening the carrying case and taking out the instrument, place the case horizontally, then open the case.
8. When returning the instrument to its case, be sure to match the white positioning marks provided with the case and place the instrument with the eyepiece upward.
9. For transportation, provide dampening or a cushion appropriately to avoid sudden shock or vibration.
10. For cleaning the instrument after use, remove dust using a cleaning brush, then wipe off with a cloth.
11. For cleaning the lens surface, use a cleaning brush to remove the dust, then use a clean lintless cotton cloth. Moisten it with alcohol (or mixture with ether) to wipe gently in a rotational motion from the center out.
12. Even if any abnormality occurs, never attempt to disassemble or lubricate the instrument yourself. Always consult with GOWIN or your dealer.
13. To remove the dust on the case, never use thinner or benzine. Use a clean cloth moistened with neutral detergent.
14. Check each part of the tripod after extended use. Parts (screws or clamps) may work themselves free.

19. SPECIAL ACCESSORIES




FC-24 interface cable

·Cable for communicating an external instrument and 100N by the serial signal connector



Solar reticle, Model 6


A reticle designed for collimation of the sun, can be used together with Solar Filter. Observation in an easy posture will be provided up to the zenith position



Observation in an easy posture will be provided up to the zenith position




A filter designed exclusively for direct collimation of the sun. Solar filter of flap-up type.




Optical plummet tribrach

This is detachable tribrach having built-in optical plummet telescope



Wide-frame extension leg tripod, Type E (Wood)
 ·Flat top, 5/8 inch, 11 treads per inch connection screw, adjustable tripod leg.



Wide-frame extension leg tripod, Type E (Wood)
 ·Flat top, 5/8 inch, 11 treads per inch connection screw, adjustable tripod leg.


Prism unit case, Model 5
 prisms unit or fixed 3 prisms unit can be stored in this case. Especially, this is a very easy case to carry. Soft material is used.
 ·External dimensions
 200(L)x200(W)x350(H)mm
 ·Weight: 0.5kg




Accessory case, model 1
 The case for storage and carriage various accessories
 ·External dimensions
 300(L)x145(W)x220(H)mm
 ·Weight: 1.4Kg

20. PRISM SYSTEM

It is possible to change the combination according purpose.



It is possible to change the combination according purpose.



Use the above prisms after setting them at the same height as the instruments.
To adjust the height of prism set, change the position of 4 fixing screws.

21. ERROR DISPLAY

Error code	Description	Countermeasures
3 points required	When area calculating, there are less than 3 points coordinate data in selected file.	Confirm the file data and calculate again.
CALC ERROR	Calculation is impossible from the data input.	Confirm the input data.
DELETE ERROR	When deleting coordinate data, it can not be done successful.	Confirm
E35	Displayed when REM measurement carried out to the range from zenith or nadir $\pm 6^\circ$.	Operate in the r zenith or nadir.
E60's	Any abnormality occurs with EDM (distance measuring system).	Repair is required.
E71	Displayed when vertical angle 0 position is set with incorrect procedure.	Confirm
E72	Displayed when Vertical angle -position is adjusted in wrong position.	Repair is required.
E73	The instrument was not leveled when Vertical angle 0-position is adjusted.	Level the instrument then carr adjustment work.
E80's	Mainly at the time data transmission between TKS-200 series and external instrument.	Confirm oper connection cables are correct.
E90's	Abnormality in internal memory system.	Repair is required.
FILE EXISTS	The same file name exists.	Use another file name.
FULL FILES	When making a file, 30 files already exist.	If necessary, send or delete files.

FAILED INITIALIZE	Initializing can not be done successful.	Confirm initializing data and try to initialize again.
LIMIT OVER	Limit of input data exceeded.	Input again.
MEMORY ERROR	Any abnormality occurs with internal memory.	Initialize the internal memory.
MEMORY POOR	Shortage of capacity of the internal memory.	Download data from internal memory to PC.
NO DATA	The data is not found in the search mode	Confirm the data and search again.
NO FILE	There is no file in internal memory.	If necessary, make files.
FILE NOT SELECTED	When using a file, no file is selected.	Confirm the file and select a file.
P1-P2 distance too short	When in point to line measurement, the horizontal distance between first point and second point is within 1m.	The horizontal distance between first point and second point must be more than 1m.
CIRCULAR ERROR	Known points and occupied point are on the same circle at the resection mode.	Take the different point.
PT# EXIST	Same new point name is already memorized in the memory.	Confirm the new point name and input again.
PT# DOES NOT EXIST	When you enter incorrect name or PT# does not exist in the internal memory.	Enter the correct name or enter point in the internal memory.
RANGE ERROR	When setting a new point, calculation is impossible from the measured data.	Measure again.
Tilt Over	Instrument tilts over more than 3 minutes.	Level the instrument properly.
V ANGLE ERROR H ANGLE ERROR VH ANGLE ERROR	Abnormality in angle measuring system.	If this error code continues to display, repair is required.

·If the error information still exist after treatment, you can contact with local dealer.

22. SPECIFICATIONS

Telescope

Length :150 mm
Objective lens :45 mm(EDM50 mm)
Magnification :30x
Image :Erect
Field of view :1°30'
Resolving power :3.0"
Minimum focus :1.3 m

Distance measurement

Measurement range

	Prism	Atmospheric conditions	
		Condition 1	Condition 2
TKS-202	Mini prism	900m(3,000ft)	---
	1 prism	2,000m(6,600ft)	2,300m(7,500ft)
	3 prisms	2,700m(8,900ft)	3,100m(10,200ft)
	9 prisms	3,400m(11,200ft)	4,000m(13,200ft)

Condition 1:Slight haze with visibility about 20km (12.5miles) moderate sunlight with light heat shimmer.

Condition 2:No haze with visibility about 40km(25 miles), overcast with no heat shimmer.

measurement accuracy : ±(2mm +2ppm × D) m.s.e.
D : Measuring distance (mm).

Minimum reading

Fine mode :1mm(0.005ft)/0.2mm(0.001ft)
Coarse mode :10mm(0.02ft)/1mm(0.005ft)
Tracking mode :10mm(0.02ft)
Measurement display : 12 digits, max. display 99999999.9999

Measuring time

Fine measurement mode	:1mm :1.2 sec. (Initial 4 sec.) 0.2mm :2.8 sec. (Initial 5 sec.)
Coarse measurement mode	: 0.7 sec. (Initial 3 sec.)
Tracking measurement mode	: 0.4 sec. (Initial 3 sec.) (The initial time will be different by a condition and setting EDM off time)
Atmospheric Correction Range	:-999.9ppm to+999.9ppm, in 0.1ppm increments
Prism constant correction range	: -99.9mm to+99.9mm, in 0.1mm increments
Coefficient Factor	: Meet / Feet International feet 1m=3.2808398501 ft. US SURVEY feet1m = 3.2808333333 ft.

Electronic Angle Measurement

Method	: Absolute reading
Accuracy (Standard deviation based on DIN 18723)	
TKS-202	: 2"

Tilt Correction (Automatic index)

Tilt sensor	TKS-202	:automatic compensator
Method		:Liquid compensator
Compensating Range		:± 3'
Correction unit		:1" (0.1mgon)

Others

Instrument height	:176mm(6.93 inch), base unit detachable (Height from the tribrach dish to the center of telescope)
-------------------	---

Level sensitivity	
Circular level	: 1 0'/2 m
Plate level	: 30"/2 mm
Optical Plummet Telescope	
Magnification	:3 x
Focusing range	:0.5 m~∞
Image	: Erect
Field of view	:3°
Dimension	:336(H)×184(W)×172(L)mm (13.2H 7.2W 6.8L in)
Weight	
Instrument	
(with battery)	:4.8 kg
(without battery)	:4.6 kg
Plastic carrying case	:3.7 kg
Durability	
Protection against water and dust	:TP54(based on international standard IEC60529)
(with battery: BT-L1W)	
Ambient temp.range	:-20□~+50□(-4□~+122°)
Battery BT-L1W	
Capacity	:3.0AH
Longest use time(fully charged)at +20□(+68□)	
Inclu. Distance measurement	: 14 hrs
Only for angle measurement	: 60 hrs
Weight	:0.2kg
Battery Charger BC-LIW	
Working temp.	:+10□~+40□(50□~104□)
Charging signal	: Red light illumination
Finishing signal	: Green light illumination
Weight	: 0.2kg
• Battery using time will vary depending on environmental conditions and operations done with TKS- 200N series.	